

C & C ASSOCIATES

troubleshooting

guides

SERVICING THE CANON T90

I. CIRCUIT DESCRIPTION

Power Circuit

Battery. Batteries are four AA alkaline or Ni-Cd held in a magazine, V-Bat six volts. Battery power passes directly to DC / DC convertor, MD FPC, Main FPC and magnets MG-1, MG-2.

Standby. With main batteries inserted B+ passes to pin 23, IC-3 through diode D-3 providing 5.5 volts VDD. With batteries removed reset switch SW-3 grounds pin 3, IC-3. One 3 volt lithium battery B-2 provides standby power through diodes D-3, D-1 and capacitor C-6. Capacitor C-6 is VDD to pin 23, IC-3 and VSS pin 59, IC-3.

Main Switch. Moving switch SW-16 to 'A' grounds pin 22, IC-3; DC / DC turns on for two seconds.

Pre-Release. Closing switch SW-1 or exposure preview switch SW-1' grounds pin 7, IC-3. Pin 36, IC-3 switches low to turn on DC/DC convertor. DC/DC sends 6 volts for E-1, E-2 and 15 volts VPP. E-1 powers circuits through diode D-5. E-2 powers lightmeter through coil L-1. VPP powers shutter.

Display. LCD is off with main switch on 'L'. LCD turns on with main switch on 'A'. Finder LED's turn on when release is depressed 1/2 stroke. LCD displays bc and three bars for new batteries.

Battery Check. At 4.25 volts camera will release but mirror doesn't return, below 3.25 volts camera will not release. Battery check button grounds pin 4, IC-3 through switch SW-4. V-Bat is compared to R-Bat voltage by pin 3, IC-4. External battery check uses rewind motor as load, internal battery check uses charge motor.

Logic Check. Switches SW-16, SW-12 must be closed and switches SW-3, SW-13 open or no functions. Cycle switch SW-3 to reset camera. Finder LED will not light if finder switch is set to 'O'.

Notes: Standby battery lives on prism right. Reset switch SW-3 lives in battery chamber. DC/DC lives bottom right. Switch SW-1 connects to pin 7, IC-3 through diode D-9. Switch SW-1' lives at top back right. Switch SW-13 lives on mirror box, bottom left. See Schematics for wires, paths.

Control Dial

Rotating control dial on hand grip sends control

adjustment pulses to IC-6 through switches SW-25, SW-26.

Lightmeter

DC / DC convertor E-2 output powers IC-1 and IC-2 for metering. IC-3 calculates exposure based on light, DX / ISO, lens speed, F stop, shutter speed, exposure compensation and metering mode.

Light. IC-4 reads light through IC-1 on Main FPC or IC-2 on SP FPC. IC-1 used for average and partial readings lives above eye piece. IC-2 used for spot and flash TTL lives under mirror box and reads light through sub-mirror. IC-4 sends light information to IC-5.

DX / ISO. IC-8 reads DX pins SW-43 through D Flex connected to Main FPC and sends it to IC-5. DX is read at the start of film advance, default is last DX / ISO. Pressing ISO button grounds pin 12, IC-3 through switch SW-8 allowing manual ISO selection. Light added to ISO equals Ev / Program.

Lens Speed. IC-5 reads lens speed through Avo switches SW-33, SW-34, SW-35, SW-36. Installing lens sets Avo pin depth, closing switch equaling Avo.

F / Stop. In Av / aperture priority mode, F / Stop is selected through Command Dial. F / Stop subtracted from Ev equals auto shutter speed.

Shutter Speed. In Tv / shutter priority modes, shutter speed is selected through Command Dial. Shutter speed subtracted from Ev equals auto aperture.

Exposure Compensation. Pressing Exposure compensation button grounds pin 13, IC-3 through switch SW-9, compensation is selected through Command Dial.

AE Lock. Exposure reading is locked as long as release is depressed 1/2 stroke.

Metering Mode. Depressing metering mode button grounds pin 9, IC-3 through switch SW-6. Selecting center-weighted average, partial or spot metering is through Control Dial.

One point spot. While in spot metering mode depressing point spot button grounds pin 10, IC-3 through switch SW-7, exposure is memorized for 30 seconds. Selecting two or more spots averages exposure. Depressing highlight button grounds pin 37, IC-5 through switch SW-29 increasing high spot exposure, depressing shadow

C & C ASSOCIATES

button grounds pin 38, IC-5 through switch SW-30 decreasing low spot exposure.

Stop down. Setting lens to manual grounds pin 24, IC-3, LCD displays Moving depth of field preview slide grounds pin 27, IC-3 through switch SW-20 selecting stop down metering mode.

Display. LCD displays ISO speed during first frame advance and when ISO button is pressed. LCD displays meter mode icon. Finder displays lightmeter information. Selecting spot metering turns on finder LCD, depressing one point spot button fixes reference.

In stop down metering LCD displays aperture icon. In 'Av', 'P' or 'Program' modes / lens in manual finder displays shutter speed. In 'Tv' mode / lens in manual finder displays either 'OP' / open aperture, 'OO' / correct exposure or 'CL' / close aperture.

Logic. If DX is not recognized LCD ISO number blinks. If lens in on 'A' when lens is stopped down, LCD displays 'EEE', finder 'Help' no release.

Notes: One point spot button is near release, high-light and shadow buttons live at top back right. Using linear polarization filter will cause incorrect lightmeter readings. See Schematics for wires, paths.

Release

Before release. Shutter is latched mechanically in charged position, diaphragm stop down lever / mirror is held by MG-2.

Mirror Up. Depressing release button fully or shorting three remote contacts closes switches SW-1, SW-2. Switch SW-2 grounds pin 5, IC-3 through diode D-8. Finder display turns off; pin 52, IC-4 pulses low activating hybrid magnet MG-2. MG-2 releases diaphragm stop down lever which frees mirror control levers at the end of its travel. With mirror up switch SW-13 opens disconnecting pin 19, IC-3 ground; 1st curtain is released.

Mirror Down. When 2nd curtain completes its travel switch SW-19 opens disconnecting pin 26, IC-3 from ground. Depending on 'H' or 'L' drive mode, IC-10 controls charge motor M-2 through transistors Q-7, Q-8, Q-9, Q-10. As charge cam rotates switch SW-15 sends pulses to pin 21, IC-3 and pin 41, IC-5 through diode D-12, 13. When mirror, aperture lever and shutter are reset; charge complete switches SW-14 and SW-15 closes, motor M-2 turns off. Switch SW-14 grounds pin 20, IC-3 and pin 40, IC-5 through diode D-10, 11. Switch SW-15 grounds pin 21, IC-3 and pin 41, IC-5 through diode D-12, 13.

Charge Motor Control. Pressing drive mode button selects 'Single', 'H' or 'L'. In 'L' drive mode, IC-10 switches pin 3 low, pin 1 high to turn on transistors Q-8 and Q-9. This applies B- to right motor contact and B+ to left

contact. In 'Single' and 'H' drive mode, IC-10 switches pin 2 low, pin 4 high to turn on transistors Q-7 and Q-10 switching motor polarity. Motor M-2 direction shifts planetary gears which controls 'H' / 'L' speed and keeps charge cam rotating in one direction.

Logic. Charge switches SW-13, SW-14, shutter switches SW-18, SW-19 and with lens set to 'A' AE charge switch SW-12 must start closed, LCD displays 'EEE', finder 'Help'. While charge motor M-2 is running pulses generated by switch SW-15 are counted by pin 41, IC-5 through D-12, 13. If pulses are slow, drive may shift from 'H' to 'L' and/or LCD display blinking bc. No operations in 'EEE', 'Help' or blinking bc.

Notes. Motor M-2 lives in handgrip. Magnet MG-2 and AE charge switch SW-12 live on mirror box right. Charge switches SW-13, SW-14 live bottom left. Shutter switches SW-18, SW-19 live in shutter unit. See Schematics for wires, paths.

Shutter

Before Release. Shutter starts in charged position, held mechanically by latches in shutter unit. During pre-release 15 volts VPP travels to shutter magnets MG-3, MG-4 and capacitors C-19, C-20 through diode D-14, 15.

First frame advance. Shutter remains closed.

Exposure. With mirror up switch SW-13 opens disconnecting pin 19, IC-3 ground. Pin 55, IC-4 releases 1st curtain by pulsing high which momentarily turns on transistor Q-1 giving capacitor C-20 a discharge path through hybrid magnet MG-3. At end 1st curtains travel switch SW-18 opens disconnecting pin 25, IC-3 from ground. This checks curtain movement.

After 1st curtain release IC-3 counts shutter speed then pin 54, IC-4 releases 2nd curtain by pulsing high which momentarily turns on transistor Q-2 giving capacitor C-19 a discharge path through hybrid magnet MG-4. When 2nd curtain completes its travel switch SW-19 opens disconnecting pin 26, IC-3 from ground. This checks curtain movement and starts charge motor M-2 returning mirror.

Display. LCD, finder displays shutter speed. In 'B' LCD displays seconds.

Logic. Shutter switches SW-18, SW-19 must start closed or LCD displays 'EEE', finder 'Help'. Curtains must complete their travel and open switches SW-18 and SW-19 or after exposure cycle is complete LCD displays 'EEE', finder 'Help'; charge motor M-2 cycles once trying to reset camera. No operations in 'EEE', 'Help'

Notes. Magnets MG-3, MG-4, capacitors C-19, C-20, diode D-14, 15, shutter switches SW-18, SW-19 live in shutter unit. See Schematics for wires, paths.

Aperture

Manual. Aperture is selected through lens. During release stop down lever moves aperture to selected stop, auto aperture control lever has full travel because aperture magnet **MG-1** is turned on before stop down lever release and kept on during aperture stop down.

In Av mode lens is set to 'A', aperture selection is made using control dial and auto system.

Auto. Auto aperture control levers starting position closes AE charge switch **SW-12** grounding pin 17, **IC-3**. Setting lens to 'A' depresses auto pin on lens mount. This opens auto / manual switch **SW-17** disconnecting pin 24, **IC-3** from ground.

During release magnet **MG-1** turns on before stop down lever is released. As auto lever in lens pulls auto aperture control lever in body down; pin 45, **IC-3** counts pulses generated by Av code switch **SW-24**. At Av number pin 51, **IC-3** switches high turning off magnet **MG-1**. This ends auto aperture control lever / aperture movement.

Display. LCD displays **M** in manual.

Logic. LCD displays 'EEE', finder 'Help' if switch **SW-12** is not closed when lens is set to 'A'.

Notes. Auto aperture control lever is held mechanically before release. Switch **SW-17** lives on mirror box left. Magnet **MG-1**, switches **SW-12** and **SW-24** live on mirror box right. See Schematics for wires, paths.

Film Transport

Loading. Closing film door opens switch **SW-22** which disconnects pin 28, **IC-3** from ground. With film cassette inserted pressure against DX exposure pad opens cassette switch **SW-21** disconnecting pin 28, **IC-3** from ground. **IC-10** switches pin 7 low, pin 8 high to turn on transistors **Q-3** and **Q-6**. This applies B+ to red motor **M-1** wire and B- to black wire. The wind gears engage sprocket for direct drive. The sprocket cycles film winding switch **SW-31** generating pulses to pin 43, **IC-3**. At the completion of each wind stroke switch **SW-27** grounds pin 88, **IC-6**. At end of film loading; sprocket becomes free wheeling, motor **M-1** reverses direction briefly to check engagement by cycling sprocket / switch **SW-31** through film. In reverse wind, **IC-10** switches pin 7 low, pin 5 high to turn on transistors **Q-4** and **Q-5**.

Advance. Each release repeats cycle with one exception, reverse wind is used only for loading.

Rewind. **IC-8** reads frame numbers from DX pins 6, 7. When exposure count equal frame number rewind begins. **IC-9** switches pin 6 low, pin 8 high to turn on transistors **Q-11** and **Q-14**. This applies B+ to pink motor

M-3 wire and B- to blue wire. Rewind gears engage rewind fork. Rewind ends shortly after switch **SW-31** stops cycling, motor **M-3** briefly reverses direction to reset gears away from rewind fork. In reset, **IC-9** switches pin 7 low, pin 5 high to turn on transistors **Q-12** and **Q-13**.

If frame numbers is not read through DX failure of both switches **SW-27** and **SW-31** signals rewind. Manual rewind is possible after frame #1. Manual rewind button **SW-11** grounds pin 16, **IC-3** through front left connector.

Display. LCD displays cassette icon when cassette switch **SW-21** opens, moving bars as film moves, exposure number, blinking cassette icon at end of rewind. If frame number is read from DX, finder LCD displays 'F' then counts down last nine frames.

Logic. Film door switch **SW-22** and cassette sensing switch **SW-21** must be open or no film loading. Switches **SW-31** and switch **SW-27** must cycle or film will continue winding. If switch **SW-27** and **SW-31** fails to cycle LCD three bars blink, no functions. After rewind LCD displays blinking cassette icon, no functions until film door cycles.

Notes: Sprocket free wheels until film motor starts, at the end of each wind stroke. Wind motor **M-1** lives in spool. Transport gears live bottom left. Rewind motor **M-3** lives front right. Rewind gears live above rewind fork.

Flash

Flash shoe has five contracts; Synch, STSP, AVEF, VC / CCC and FEID. Trail curtain synch can be selected through flash. In flash mode program ranges between 1/60 and 1/250, manual 1/250 and slower. 300 TL flash must be used for TTL and FE-TTL.

Synch. **SW-X** grounds contact when 1st curtain completes its travel triggering flash.

AVEF. Flash sends aperture voltage to pin 2, **IC-4**. Aperture is selected using auto aperture circuit.

STSP. **IC-4** read flash output through **IC-2**. At integration reference voltage pin 59, **IC-4** sends TTL stop pulse. 300 TL flash must be used.

VC / CCC. Lead curtain closes switch **SW-X** turning on transistor **Q-32**. This turns on trigger triac on **Flash Trigger PCB**. Triac grounds PC and hot shoe X contact.

FEID. Pin 60, **IC-4** sends pre-flash trigger signal when flash is set to FE-TTL mode and spot metering button is used. Pre-flash fires, exposure is memorized.

Display. Finder LCD displays exposure of main subject in FEID mode.

Notes. **IC-2** lives on bottom of mirror box.

C & C ASSOCIATES

Self-Timer

Pressing button in right side panel grounds pin 30, IC-3 through switch SW-23, front left connector.

Finder Control

Switch left grounds pin 25, IC-5 through switch SW-28, front left connector. IC-5 tells IC-8 to turn on LCD and finder light. Switch left and centered pin 58, IC-5 is disconnected from ground, finder LEDs turn on. Switch right; pin 58, IC-5 grounds through SW-32, front left connector.

Double Exposure

Depressing both exposure mode and meter mode buttons grounds pins 8, 9, IC-3. LCD displays 'ME', exposure counter changes to 1. 1 through 9 multi-exposure are selectable through control dial.

Safety Shift

Depressing both ISO and exposure compensation buttons grounds pins 12, 13, IC-3. LCD displays 'SS'. Manual speeds are overriden if incorrect.

II. TOOLS AND INFORMATION

A. Tool and Equipment

- Anti-static workmat or strap
- Two 1000 probes
- 3K probe
- DVM
- Oscilloscope
- DC power supply
- Current meter or ZTS Interface
- 0.4 resistor in series with power supply. Current meter or ZTS Interface can substitute.
- Test cassette with DX
- Grounded soldering iron
- Canon 50mm F1.4 Test Lens

B. Service Notes

1. Cycle reset switch in battery chamber or SW-3 solder point to reset camera.
2. In Troubleshooting * Indicates most common problem.
3. Curtain travel times can be adjusted w/o re moving mirror box.
4. Using linear polarization filter will cause in correct lightmeter readings.
5. IC-Reset isn't found on all models.
6. Shutter is no longer available but Canon will rebuild if shutter is sent to them.
7. Check strap lugs for looseness.

C. Battery

Main Battery	4 AA alkaline or Ni-Cd
Battery voltage	6 volts
Standby Battery	3 volt Lithium
Mirror Won't return	4.25 volts
No Release	3 volts

D. Typical Operating Currents

Off	100 μ A or less
ON	100 μ A or less
Pre-Release	150mA
Bulb	65ma then 1ma
Film Transport	1450 mA
Rewind	450 mA peak

E. Coil Resistances

M-1, Film Transport	3.5
M-2, Charge	1.7
M-3, Rewind	3.7
M-1, Auto Aperture	327

MG-2, Release 67

MG-3, 1st Curtain 18

MG-4, Release 18

F. Lens Flange Focal Distance

44.14mm \pm 0.02mm To Pressure Plate Rail
 \pm 0.02mm Parallelism

G. Film Leader

Bridge film leader solder lands prism left to leave leader out after rewind.

H. Adjustments

Battery Check

Adjust R-Bat in pre-release until voltage is 3.6 volts.

Shutter

Curtain Travel	2.7ms
1st Curtain Adjust	Access Bottom
2nd Curtain Adjust	Access Top Right, 3rd layer
1/4000 (294 μ s)	VR-8, front left
K factor	12.5

X Synch

X-Synch Delay, front left 3rd layer.

Lightmeter

*AE SPDs

* Skip if IC-1 and IC-2 have not been changed.

1. Mask Light Box with 12mm hole in center
2. Select Program
3. Set lens to F/5.6, closest focus, stop down lens.
4. Position lens square to light box, hole in focus.

IC-1 Average, Partial SPD

1. Adjust eccentrics right of IC-1 so light source spot is within outer micro prism circle

IC-2 Spot SPD centering

1. Read Shutter speed.
2. Move camera vertically, compare off center readings. Should be \pm 1 Ev.
3. Adjust sub-mirror eccentric, shutter open on 'B'.

Set Adjustment Mode

1. Desolder Solder Bridge A, top left
2. Solder jumper between Test Land A (top left) and Test Land B, E-1 (prism left, 2nd layer).

3. Replace top cover, depress release 1/2 stroke.
4. Ground Test C (bottom Command Back Contact near spool) until F/ Stop LEDs display correct number. One number change each time Test C is grounded.

5. Finder LEDs:

1. F/Stop LEDs = meter mode

03 = spot, 02 = partial, 01 = Average

2. Shutter Speed LEDs = AR-1 and AR-2.

AR-1 = Right 2 digits, AR-2 = Left 2 digits

Adjust

Spot

1. Set finder F/Stop LED for '03'.
2. Adjust VR-2 until AR1 LEDs read 'd2' at Ev 12.

Partial

1. Set F/ Stop LEDs, display '02'.
2. Adjust VR-3 until AR1 LEDs?? read 'd0' at Ev 12.

Average

1. Ground Test C (bottom Command Back Contact) until F/ Stop LEDs display '01'.
2. Adjust VR-4 until AR1 LEDs read 'CE' at Ev 12.

Gain

1. Set F/ Stop LEDs display '02'.
2. Adjust VR-1 until AR2 LEDs?? read '68' at Ev 6.

Aperture

1. Set Av mode, F/5.6.
2. Measure with shutter tester.
3. A-1, A-2, B-, A-3 lands, top prism left.

Adjust

Normal = A-1, A-2, B- solder bridged.

+ 1/8 = A-2, B- solder bridged.

+ 2/8 = A-3, B- solder bridged.

- 1/8 = A-1, B- solder bridged.

- 2/8 = A-1, A-3, B- solder bridged.

- 3/8 = A-1, A-2, B- solder bridged.

- 4/8 = A-1, A-2, A-3, B- solder bridged.

Flash

Aperture Selection

1. Ground VC / CCC contact through 3KΩ.
2. Connect VC / CCC to AVEF contact.
3. Check finder for F/4.
4. Adjust VR-5, front left.

TTL Stop

1. Use 300 TL flash.
2. Test against 18% gray card, 2 meters.
3. Adjust VR-7, front left. ±0.5 Ev.

FEL Exposure:

1. Use 300 TL flash, FEL mode, 35mm position.
2. Test against 18% gray card, 2 meters.
3. Set 1/250, F/5.6, ISO100, stop down mode.
4. Push spot meter button for pre-flash.
3. Adjust VR-6, front left. ±0.5 Ev.

III. DISASSEMBLY AND REASSEMBLY

Front Apron: 3 screws; 1 top, 2 bottom. Loosen 2 film door latch screws, right.

Top Cover: 2 screw, front. 1 screw top right, above strap lug. 2 screws, back near eye piece. Unsolder 9 top cover wires from FPC, Bk, W, Pk, Bl, Pu, Gn, Or, Gr, flash shield cable/wh. 2 buttons, rewind.

Bottom Battery Chamber: Rubber cover. 2 screws under brass cover plates, long screw front. 2 screws far right, silver screw front. 2 bk. screws far left. Retaining ring around tripod socket. Lift bottom of hand grip rubber, remove battery chamber. **Note:** small compression spring near hand grip. Unsolder 6 wires; Bk, Bl, Gn, Rd, Bk, Y.

IC-3 Access: Top Right, under LCD. Remove front apron, top cover. Lift LCD, 3 screws (silver screw, back right).

Release Magnet Access: Remove front apron. Use 45° pick and syringe to clean magnet.
Note: Magnet Shield is open on bottom.

DX FPC Access: Top Left, under Main FPC. Remove front apron, top cover. Desolder Film Door switch. 2 screws.

Shutter FPC Access: Remove front apron, top cover. Front left connector, 2 screws. Lift top 2 FPCs. Plastic plate, 2 screws.

Transport Motor Wires Access: Remove front apron, top cover. Front left connector, 2 screws. Lift top 2 FPCs. Plastic plate, 2 screws.

Release Switch Block: Unsolder 6 wires bottom left; Bk, R, Pk, Y, W, Bl. Remove hand grip rubber, tape. 3 screws, top of handgrip. Lift release unit from top.

C & C ASSOCIATES

Rewind Motor: Remove Covers. 2 screws.

Charge Gears: **Bottom :** Unsolder most wires from bottom. Remove plate, DC/DC, 2 screws each. Remove shutter charge lever #1 (loose bushing), mirror charge lever, charge cam/gear. Remove charge plate; 4 screws (not switch plate screws, 2 plastic thread screws at lower left and upper right. **Note :** Loose spring under plate. Remove spring, gears. **Note :** Position of clutch spring under gear.
Reassembly Tips : Rotate charge gears or cam to check shutter / mirror charge levers; shutter should charge.

Remove Release Switch Block .

Right Side Panel Switch Plate: Film door, clip. Door hinge, 2 screws. Plate, 2 screws, disengage panel door spring.

Handgrip: Remove Release Switch Block, Right Side Panel Switch Plate. 2 Bk screws top, 1 Bk screw bottom.

Charge Motor , Gears: Remove Release Switch Block, Right Side Panel Switch Plate, Handgrip. Desolder 2 top connections. Motor, 2 screws. **Note :** access 1 screw through access hole.

Film Advance Motor, Gears:

Front Left: Unsolder R, Gr Self-LED wires. Mirror Box ground Gr wire, 1 screw. Unsolder 6 wires; Bk, Bk, Bl, W, Y, R. Desolder V-Bat pin. FPC Connector, 2 screws. Separate top two FPCs, SP FPC, Main FPC **Note:** FPC pads.

Top Right : LCD, 3 screws (silver screw, back right); unsolder Bk, R LCD wires from Main FPC; unfold LCD; unsolder 3 sprocket wires, Y, Bk, Lt. Bl near Clk. Lift FPC unsolder R, Bk motor wires.

Remove Release Switch Block, Right Side Panel Switch Plate, Handgrip. Desolder Data Contacts. Remove Charge Motor (don't desolder), gears.

Bottom : Unsolder Or, Bk, Gn, SW-14, SW-15 wires. Remove 2 FPC screws, spacer. Fold back MD FPC. Remove plate, 2 screws. Remove shutter charge lever #1 (loose bushing), mirror charge lever, charge cam/gear. Remove charge plate; 4 screws (not switch plate screws, 2 plastic thread screws at lower left and upper right. **Note :** Loose spring under plate. Remove spring, gears. **Note :** Position of clutch spring under gear. Top: Remove sprocket shaft screw. Remove Transport plate, motor. Unscrew motor.

Reassembly Tips : Rotate charge gears or cam to check shutter / mirror charge levers; shutter should charge.

MD FPC:

Front Left: Unsolder R, Gr Self-LED wires. Mirror Box ground Gr wire, 1 screw. Unsolder 6 wires; Bk, Bk, Bl, W, Y, R. Desolder V-Bat pin. FPC Connector, 2 screws. Separate FPCs. **Note :** FPC pads.

Top Right : LCD, 3 screws (silver screw, back right); unsolder Bk, R LCD wires from Main FPC; unfold LCD; unsolder 3 sprocket wires, Y, Bk, Lt. Bl near Clk. Lift FPC unsolder R, Bk motor wires.

Remove Release Switch Block, Right Side Panel Switch Plate, Handgrip. Desolder Data Contacts. Remove Charge Motor, gears.

Bottom : Unsolder all wires from MD FPC. Remove 2 FPC screws, spacer. Desolder DC / DC.

Removing Mirror Box.

Remove Covers.

Top Left: Unsolder 8 wires; Gr, Lt. Bl, Or, W, Y, Gn, Bn, Pk. 2 screws. Desolder Film Door Switch. Remove plastic plate. Unsolder DX FPC from FD FPC. Desolder film door switch from FD FPC.

Top Center: Eye piece; 2 vertical screws left & right of AE SPD. **Note :** Left screw remains with eye piece.

Top Right: LCD, 3 screws (silver screw, back right). Unsolder Bk, R LCD wires from Main FPC. Unfold LCD. Unsolder 3 sprocket wires, Y, Bk, Lt. Bl near Clk.

Continued

Continued

Prism Right: Desolder Shutter FPC from Main FPC. **Note:** Main FPC has pins which sit into holes in Shutter FPC.

Front Left: Unsolder R, Gr Self-LED wires. Mirror Box ground Gr wire, 1 screw. Unsolder 6 wires: Bk, Bk, Bl, W, Y, R. Desolder V-Bat pin. FPC Connector, 2 screws. Separate top two FPCs, SP FPC, Main FPC **Note:** FPC Pads

Bottom: Center. Remove stop down spring, bottom spring.

Mirror Box Screws: 2 screws, left & right of eye piece. 2 screws, bottom center of mirror box.

Reassembly Tips: Check engagement of stop down lever, depth of field slide. Remember: stop down spring, Bk & Gr wire from Shutter FPC. **Shutter cocked.**

Mirror Box Removed

Shutter: Remove Mirror Box. Unsolder R, Bk wires near V-Bat. Plastic plate, 2 screws. Unsolder Or wire from shutter unit. 3 screws; 2 top left & right, 1 bottom left. **Note:** Shutter is sealed to body, reapply seal.

IV. SWITCH CHART

Power

Symbol	Function	Location / Wires	Symptoms of Malfunction
SW - 16	On / Off	Bottom Center White, Black Wires	Shorted: Won't turn off. Open: No functions.
SW - 1	Pre - release	Handgrip White, Black Wires	Shorted: Finder display stays on. Open: No functions.
SW - 1'	Exposure Preview	Top Right Back White, Black Wires	Shorted: Finder display stays on. Open: No Exposure Preview
SW - 3	Reset	Battery Chamber Yellow Wire	Shorted: On functions. Open: No reset.
SW - 4	Battery Check	Right Side Panel Front Left Connector	Shorted: Only Battery Check function. Open: No Battery Check.

Control Dial

SW - 25 SW - 26	Control Modes	Hand Grip Yellow, Pink, Black Wires	Shorted or Open: No Control of Modes.
--------------------	---------------	--	--

Light Meter

SW - 6	Meter Mode	Top Left	Open: No Meter Mode Change.
SW - 7	Spot Meter	Handgrip Red Wire	Shorted: Always Spot Meter. Open: No Spot Meter.
SW - 9	Exposure Compensation	Bottom Brown Wire	Shorted: Stays in Compensation. Open: No Compensation.

C & C ASSOCIATES

IV. SWITCH CHART (continued)

Light Meter (continued)

Symbol	Function	Location / Wires	Symptoms of Malfunction
SW - 20	Stop Down Metering	Front Right Bottom White Wire	Shorted: Stop Down Metering only. Open: No Stop Down Metering.
SW - 28	LCD, Finder Illumination	Right Side Panel Front Left Connector	Open: No Illumination.
SW - 29	Highlight Control for Spot	Top Right Back Blue, Black Wires	Shorted or Open: No Highlight Function.
SW - 30	Shadow Control for Spot	Top Right Back Pink, Black Wires	Shorted or Open: No Shadow Function.
SW - 32	Finder LED Control	Right Side Panel Front Left Connector	Shorted: Finder LEDs OFF. Open: Finder LEDs won't turn off.
SW - 33, 34, 35, 36	AVO Input	Front Right Bottom Yellow, Brown, Red, Gray Wires	Shorted or Open: Metering, Av Mode Problems.
SW - 37, 38 39, 40, 41, 42, 43	DX	Film Chamber	Shorted or Open: Metering or Rewind Problems.

Release

SW - 2	Release	Hand grip Blue Wire	Shorted: Continuous Release. Open: No Release.
SW - 13	Checks Mirror Position	Mirror Box Left Front Left Connector	Shorted: Shutter doesn't release, mirror stays up. Open: No functions.
SW - 14	Charge Completion Check	Bottom Left Orange Wire	Shorted or Open: Charge motor runs on after mirror return.
SW - 15	Check Speed of Charge	Bottom Left Green Wire	Shorted or Open: Charge motor runs on after mirror return, possibly LCD displays bc.

Shutter

SW - 18	Checks 1st Curtain Movement	Shutter Unit Front Left Connector	Shorted or Open: 'EEE'.
SW - 19	Checks 2nd Curtain Movement	Shutter Unit Front Left Connector	Shorted or Open: 'EEE'.

Aperture

SW - 24	Av Code Switch	Mirror Box Right Purple Wire	Shorted or Open: Lens stops down completely in auto.
SW - 12	AE Charge Switch	Front Right, Bottom White Wire	Open: 'EEE' with lens in 'A'.
SW - 17	Auto Aperture	Lens Flange Left Front Left Connector	Shorted: Manual Aperture only. Open: Auto Aperture only.

IV. SWITCH CHART (continued)

Film Transport

Symbol	Function	Location / Wires	Symptoms of Malfunction
SW - 21	Checks for Cassette	Film Chamber Gray Wire	Shorted: No Film Transport. Open: Film Motor runs without film.
SW - 22	Check Film Door	Above Rewind Fork	Shorted: No Film Transport. Open: Film Motor runs with door open.
SW - 27	Check Wind Completion	Top Right Yellow, Black Wire	Shorted or Open: Film wind doesn't stop.
SW - 32	Checks Sprocket Movement	Above Sprocket Yellow, Black Wire	Shorted or Open: Film wind doesn't stop.
SW - 41,42	Checks Frame Count from DX	Film Chamber	Shorted or Open: No autor rewind by frame count.
SW - 11	Manual Rewind	Right Side Panel	Open: No manual rewind.

Flash

SW - X	Triggers Flash	Shutter Unit	Shorted: Flash always fires. Open: Flash won't fire.
--------	----------------	--------------	--

Self Timer

SW - 23	Self-timer	Right Side Panel	Open: No Self-timer
---------	------------	------------------	----------------------------

Illuminator

SW - 28	LCD, Finder Lamps	Right Side Panel	Open: No Lamps
---------	-------------------	------------------	-----------------------

V. EXTERNAL TESTS

- * Check visually for signs of drop damage, sand or liquid intrusion.

1. **Test power circuit.** Set power supply to 6 volts / 2 Amp. Main switch 'L'; standby current 10 μ A \leq 100 μ A, LCD blank. Main switch 'A'; current switches to 63mA for two seconds, LCD turns on,. Viewfinder LED should turn on when release is depressed 1/2 stroke, current 70mA.

Camera operates with battery voltage above 4.5 volts. Battery check button is in right side compartment.

Note: If finder LEDs do not turn on, check finder switch in right side panel. If LCD displays blinking bc but manual battery check displays two or three bars see release malfunctions. If LCD displays 'EEE' see release malfunctions.

2. **Test control dial.** Main switch 'A'. Select Tv

or Av mode, rotate control dial on handgrip. LCD information should change.

3. **Test lightmeter, display.** Lens installed. Depress meter button and rotate control dial, LCD should change between average, partial and spot icons. Select average or partial, depress release 1/2 stroke several times checking finder for change with light. Select spot, re-check finder for changes with light. While in spot, depress one point spot button near release button, LCD should show fixed point. Use highlight and shadow buttons top back right, LCD fixed point should increase and decrease. Depress ISO button and select ISO different than test cassette, LCD displays ISO. Insert test cassette, LCD displays cassette ISO during first frame advance. Remove lens, select 'Av' mode rotate control dial; LCD should display Av no faster than F 5.6. Install lens and in 'Av'

C & C ASSOCIATES

mode rotate control dial; LCD displays Av up to lens speed. Select 'Tv' mode rotate control dial; finder displays auto corresponding to Tv changes. Depress exposure compensation button and rotate control dial, LCD compensation should change.

Set lens from 'A' to manual, LCD displays M. Move depth of field preview slide, LCD displays aperture icon. In 'Av', 'P' or 'Program' modes finder displays shutter speed. In 'Tv' mode finder displays either 'OP' / open aperture, 'OO' / correct exposure or 'CL' / close aperture.

Note: If lens is in 'A' when depth of field preview is used; LCD displays 'EEE'.

4. **Test release.** Remove lens depress release fully; mirror should cycle, finder LEDs turn off. Select 'L' and then 'H' drive mode; check release in each mode, charge is quicker in 'H' drive. Install lens set on manual, check release.

Note: Drive mode switch is in right side panel. If LCD displays flash cassette icon cycle film door.

5. **Test Shutter.** Select 'Tv' mode and open film door. Release camera, observe shutter at slow and high speeds.
6. **Test Aperture.** Remove lens. Move depth of field preview slide; stop down lever moves completely left, check auto aperture lever manually for free travel. Without lens LCD displays M. Install lens release camera, check manual aperture selection. Set lens to 'A', M turns off. Release camera, check auto aperture selection.
7. **Test film transport.** With film door open press frame number sensing pad, LCD should display cassette icon. Close film door without film, wind

motor should not run. Load test roll and close film door; LCD should display cassette icon, bar icons show advance, exposure advances to '1'. Advance film within 12 frames from end of roll, check finder LCD for 'F'. Continue advancing film while watching finder LCD, 'F' changes to nine and counts down. Auto rewind starts as finder count reaches '0'. Repeat test advance film several frames, depress manual rewind button in right side panel. Film should rewind.

8. **Test Flash / Shoe.** Connect VC / CCC contact to ground through 3K Ω , release camera in program. Shutter speed should be 1/250. Short VC / CCC to AVEF while grounding VC / CCC through 3K Ω , finder displays F/4. Exposure should be 1/250 at F/4. Use DVM Ω mode read between X contact and ground, release on 'B' mode. Resistance should be near infinite before release and near 0 Ω with shutter open. Install 300TL flash, use tester to check flash exposure at several distances. Select FE-TTL on flash and press stop meter button, check for pre-flash

9. **Test remaining Bells and Whistles.** Right side panel; self-timer, finder control (illuminator, finder on, finder off). Double Exposure (depress mode and meter button top left); LCD displays 'ME' frame count changes to '1', exposures are selectable through control dial. Safety Shift (depress Exposure Compensation and ISO); LCD displays SS, manual shutter speeds are overridden if incorrect.

Note: For malfunctions not specifically covered in Troubleshooting see circuit discretions and schematics.

VI. TROUBLESHOOTING

1. Power	Page 10
2. Control Dial	Page 13
3. Light Meter	Page 14
4. Release	Page 16

5. Shutter	Page 20
6. Aperture	Page 22
7. Film Transport	Page 24
8. Flash	Page 27

1. Power Circuit Malfunctions

A. External Observations

LCD stays Blank with main switch on 'A'.



Current remains $0\mu A < 20\mu A$ with main switch on 'L' or 'A'.

No Functions

Note : Do External Test #1 to define malfunctions

Remove Battery Chamber

Note : Ground / unground TP-7 between tests.



C. External Observations

Viewfinder LED's do not turn on in Pre-Release.
LCD turns on when main switch is moved to 'A'.
No functions.

Depress Exposure Preview Button:
• Check for Viewfinder LED's to turn on.

No

- Resolder pin 7, IC-3. Retest.
- Use schematic to check pin 7, IC-3 paths. Repair Main FPC if defective.
- IC-3 may be defective. Replace Main FPC.

Remove Battery Chamber:

- Resolder W, Bk wires at TP-4, TP4A. Retest.
- Check SW-1, W and Bk wires, soldering. Repair if defective.
- Check diode D-9. Replace if defective.

D. External Observations

Current above 160mA in Pre-Release.
LCD turns on when main switch is moved to 'A'.
Functions may be normal, erratic or no functions.


Remove Battery Chamber

Unsolder Or wire at TP-5:
• Recheck Pre-Release current.

Not Typical

- Check C-1 for short. Replace if defective.
- Unsolder R wire from Reset FPC. Re-check current. Replace Reset FPC if current normal.
- Main FPC may be defective. Replace Main FPC.

Bottom Right



- Check C-19, C-20, Q-1 and Q-2 on Shutter Unit for short. Replace if defective.
- IC-4 may be defective. Replace Main FPC.

Bottom Left

TP-14A D-8

TP-4 SW-1 W

SW-2 Bk

SW-25 Y

SW-7 R

SW-26 Pk

TP-4A Bk to Release Switch Unit

TP-15A Bk to SW-14, SW-15

TP-15C SW-15 Or

TP-15B SW-14 Gn

SW-2 to Main FPC Front Left

SW-1 to Main FPC Front Left

First Curtain Travel Adjustment

Q-14 NPN

Q-12 PNP

Q-11 PNP

Q-13 NPN

Vcc to Main FPC Front Left

Bk to Main FPC Front Left, Shutter FPC

E-1 to Main FPC Front Left

Bottom Center

TP-2A DC/DC Ground

TP-2 DC/DC Output

SW-2 Remote Socket

D-3

D-4

B+ from DC/DC

B+ to MD FPC Front Left, Second Layer

B- from DC/DC

B- from DC/DC

1. Control Dial Malfunctions

A. External Observations

LCD information doesn't change when command dial is rotated.
Power, Pre-Release normal.
Other functions normal.

Remove Battery Chamber

- Resolder PK, Y SW-25, SW-26 wires. Retest.
- Check SW-35, SW-26, wires, soldering between Y & Pk wires and Bk wire at TP-4A. Repair if defective.
- Check, clean, align front left connector. Retest.
- IC-6 or IC-3 may be defective. Replace Main FPC.

Note: Do External Test #1, 2 to define malfunctions.

C & C ASSOCIATES

3. Lightmeter Malfunctions


A. External Observations

Finder does not show changes with light in either Average or Spot modes.


Finder shows changes with light in one meter mode.

Power, Control Dial normal.

Note : Do External Tests #1, 2, 3 to define Lightmeter Malfunctions.



Top Left




B. External Observations

LCD does not display ISO number when ISO button is pressed.

Power, Control Dial normal.

Remove Front, Top Covers.



C. External Observations


ISO number does not reset during 1st frame advance.

ISO number may blink or show incorrect number.

Manual ISO selection normal.

Power, Control Dial normal.

Note : Film Transport must operate to reset ISO



D. External Observations

With lens removed, LCD can display Av faster than F 5.6 or can not display F 5.6. Or with lens installed LCD can display Av faster than lens wide open aperture or cannot display wide open aperture.

Lightmeter display incorrect or does not correspond to lens Av changes.

Control dial normal.

ISO selection normal.

Power normal.

Remove Front, Top Covers

With release depressed 1/2 stroke, slowly depress Avo pin:


- Check **TP-11A** to switch from low to high.
- Check **TP-11B** to switch from high to low.
- Check **TP-11C** to switch from low to high to low.
- Check **TP-11D** to switch high, low, high, low.
- * Typical high = 5 volts, typical low = near 0 volts

Yes

• **IC-5** may be defective. Replace **Main FPC**.

No • Use schematic to check bad Avo switch paths. Repair Avo switch if defective.

Top Prism Left,
Second Layer



E. External Observations

Does not lightmeter correctly in stop down meter mode. LCD may display 'EEE' when using stop down metering.

Open metering normal.

Power, control dial is normal.

Remove Front, Top Covers

• Check for LCD to display  with lens in manual.

Yes

• Check for LCD to display aperture icon when depth of field preview slide is depressed.




Yes

With depth of field preview slide depressed:
• Check for lens to be stopped down.

Yes

• **IC-5** may be defective. Replace **Main FPC**.

Lift LCD, ground pin 24, **IC-3** through 0Ω:

- Check for display to display .
- * If LCD displays , **SW-17**, front left connector, or paths may be defective. Use schematic to check, repair **SW-17**, connector or paths.
- * If LCD does not display , **IC-3** may be defective. Replace **IC-3** or **Main FPC**.

Ground **TP-13** through 0Ω:

- Check for LCD to display aperture icon:
- * If LCD displays aperture icon, **SW-20**, **Bn** wire, or soldering may be defective.
- * If LCD does not display aperture icon:
- Resolder pin 27, **IC-3**. Retest.
- Use schematic to check pin 27, **IC-3** paths. Repair **Main FPC** if defective.
- **IC-3** may be defective. Replace **IC-3** or **Main FPC**.

No • Check stopped down lever, mechanical system.



C & C ASSOCIATES

4. Release Malfunctions

Note : Do External Tests #1, 2, 3, 4 to define Release Malfunctions

A. External Observations

No Release when release button fully depressed, lens off.
Display stays on when release button fully depressed.
No current increase when release button fully depressed.
Power, control dial, lightmeter normal.



B. External Observations

No Release when release button fully depressed, lens off.
Display turns off when release button fully depressed.
Power, control dial, lightmeter normal.

Remove Covers
Briefly ground TP-15 through 0Ω.
• Check for click from MG-2 or mirror release.

No

If you hear click but no mirror release:

• Remove mirror box. Check diaphragm stop down system, mirror levers, springs, mirror up latch left side of mirror box.

If mirror releases:

• * Clean MG-2 . Retest.

Note : MG-2 shield is open on bottom and can be accessed w/o removal of mirror box.

• IC-4 or IC-3 may be defective. Replace Main FPC .

• * Clean MG-2 . Retest.


Note : MG-2 shield is open on bottom and can be accessed w/o removal of mirror box.

• Check TP-15 for 6 volts. Check MG-2 for typical 67Ω from prism wires and path to V-Bat if defective.


Remove Mirror Box:

• Check MG-2 . Clean, reseal spring, repair or replace MG-2 if defective.

Top, Prism Left



Handgrip, Charge
Motor Removed



C. External Observations

Mirror stays up or starts up, tested with lens off.
LCD may display blinking 'bc'

Gently Pull mirror down:

• Check for mirror to return to viewing position.

Yes

• Mirror bumper near viewing screen may be sticky, replace.

No

• Check focal plane to see if shutter is charged or released.

Charged

• See Shutter Malfunctions.

Released

Remove Covers, Battery Chamber, Handgrip

• Resolder M-2 wires. Retest.

Apply battery power directly to M-2 solder points. Reverse leads between tests.:

• Check for motor to turn in both directions, planetary gears shift in and out.

No
Movement

• Remove M-2. Retest motor. If motor does not turn or turns slowly, replace M-2 .

• Check gears / cam for obstruction. Repair or Replace if defective.

Motor Runs in both directions
Gears Turn

Remove M-2 :

Apply B- through 1KΩ probe to base Q-8

and B+ through 1KΩ probe to base Q-9 :

• Check for M-2 to run.

No

• Resolder Q-8 , Q-9 . Retest.

• Use schematic to check Q-8 , Q-9 paths. Repair if defective.

• Test PNP Q-8 . Replace if defective.

• Test NPN Q-9 . Replace if defective.

Yes

With M-2 removed:

Apply B- through 1KΩ probe to base Q-7

and B+ through 1KΩ probe to base Q-10 :

• Check for M-2 to run.

No

• Resolder Q-7 , Q-10 . Retest.

• Use schematic to check Q-7 , Q-10 paths. Repair if defective.

• Test PNP Q-10 . Replace if defective.

• Test NPN Q-7 . Replace if defective.

Yes

• IC-10, IC-5 or IC-3 may be defective. Replace IC-10 or MD FPC and retest.

C & C ASSOCIATES

D. External Observations

LCD displays 'EEE' or blinking **bc**. Finder displays 'Help' Release tested with lens off.

Camera may release once and / or charge motor may cycle once or twice.

In manual battery check LCD displays three bars or power is know good 6 volt / 2 Amp.

No functions in 'EEE' or blinking **bc**.

• Check for bad batteries or power pack not set to 6 volts / 2A with 0.4Ω.

No

• Replace batteries or reset power pack.

Yes

Remove Covers, Battery Chamber, Handgrip

Reset by grounding **SW-3** solder point. Depress Release 1/2 stroke:
• Check **VPP** output of **DC/DC** for typical 15 volts.

No

• **DC/DC** may be defective. Replace or repair **DC/DC**.

Yes

• Check for typical 0Ω between **TP-15A** and **B-**.
• Check for typical 0Ω between **TP-15A** and **TP-15B**.
• Check for typical 0Ω between **TP-15A** and **TP-15C**.
• Use schematic, illustrations to check **SW-14**, **SW-15** wires, paths to **IC-3**.
• Resolder **SW-14**, **SW-15** wires, **D-10**, **11** and **D-12**, **13** pins 20, 21, **IC-3**. Retest after grounding **SW-3** solder point.
• Test diodes **D-10**, **11** and **D-12**, **13**.

No

Use schematic:

• Repair path between **TP-15A** and **B-**.
• Check **SW-14**, soldering, wires. Repair if defective.
• Check **SW-15**, soldering, wires. Repair if defective.
• Repair **SW-14**, **SW-15** paths, wires to **IC-3**.
• Replace **D-10**, **11** or **D-12**, **13**.

Yes

Lift LCD:
• Check between pin 19, **IC-3** and **B-** for typical 0Ω.

No

• Check, clean align front right connector. Retest.
Remove mirror box:
• Use schematic to check mirror **SW-13**, soldering, paths. Repair or replace **SP FPC** or **Main FPC**.

Yes

• Resolder **Shutter FPC**, **Main FPC** connectors prism right. Retest after grounding **SW-3** solder point.
With shutter cocked:
• Check for 0Ω between **TP-16A** and **B-**.
• Check for 0Ω between **TP-16B** and **B-**.

No

• Use schematic to check for open **SW-18**, soldering, paths. Repair **SW-18** or **Shutter FPC**.
• Use schematic to check for open **SW-19**, soldering, paths. Repair **SW-19** or **Shutter FPC**.


Yes

Unsolder Or **VPP** wire at **DC/DC**. Remove **B+** from battery wire and connect to Or **VPP** wire. Release 1st Curtain by applying **B+** through 1KΩ to **TP-17A**:
• Check for near infinite Ω between **TP-16A** and **B-**.
Release 2nd Curtain by applying **B+** through 1KΩ to **TP-17B**:
• Check for near infinite Ω between **TP-16B** and **B-**.
Note: If shutter does not release see Shutter Malfunctions.

No


• Repair **SW-18**.
• Repair **SW-19**.

Continued Yes




Continued Yes

- Remove Handgrip:
- Resolder M-2, Q-7, Q-8, Q-9, Q-10. Retest.
- Check charge M-2 gears, shutter charging system, * shutter for smooth low drag operation.
- IC-3 may be defective. Replace IC-3 or Main FPC.



Top, Prism Left



E. External Observations

Drive mode switches from 'H' to 'L' spontaneously. Release tested with lens off.
Release normal.
Power, control dial, lightmeter normal.


Remove Covers, Battery Chamber,

- Resolder SW-14, SW-15 wires, D-10, 11 and D-12, 13 pins 20, 21, IC-3. Ground SW-3 solder point, Retest.
- Rotate Charge Cam Gear:
- Check for SW-15 to open and close between TP-15A and TP-15C. Repair SW-15 if defective.
- Test diodes D-10, 11 and D-12, 13. Replace D-10, 11 or D-12, 13 if defective.

Remove Handgrip:

- Resolder M-2, Q-7, Q-8, Q-9, Q-10. Retest.
- Check charge M-2 gears, shutter charging system and * shutter for smooth low drag operation.
- Motor M-2 may be defective. Replace M-2 and Retest.

Handgrip,
Charge Motor
Removed



F. External Observations

Charge motor runs continuously after mirror returns or with batteries inserted.

Remove Covers, Battery Chamber

With Shutter, Mirror and Charge Cam Gear at charged position:

- Check for typical 0Ω between TP-15A and B-.
- Check for typical 0Ω between TP-15A and TP-15B.
- Check for typical 0Ω between TP-15A and TP-15C.
- Rotate Charge Cam Gear:
- Check for open between TP-15A and TP-15B.
- Check for open between TP-15A and TP-15C.

No

Use schematic:

- Repair path between TP-15A and B-.
- Check SW-14, soldering, wires. Repair if defective.
- Check SW-15, soldering, wires. Repair if defective.
- Repair SW-14, SW-15 paths, wires to IC-3.
- Replace D-10, 11 or D-12, 13.

Yes


Continued

C & C ASSOCIATES

Continued ¹
Yes

Rotate Charge Cam Gear:

- Check for **SW-15** to open and close between **TP-15A** and **TP-15C**. Repair **SW-15** if defective.
- Use schematic, illustrations to check **SW-14**, **SW-15** wires, paths to **IC-3**.
- Resolder **SW-14**, **SW-15** wires, **D-10**, **11** and **D-12**, **13** pins 20, 21, **IC-3**.
- Test diodes **D-10**, **11** and **D-12**, **13**. Replace **D-10**, **11** or **D-12**, **13** if defective.
- **IC-3** or **IC-5** may be defective. Replace **Main FPC**.



G. External Observations

No Release with customers lens set to manual. LCD displays 'EEE'.
Release normal without lens and with test lens.
Power, control dial, lightmeter normal.


- Check for off brand lens. Repair diaphragm stop down pressure, may not be repairable.
- If Canon lens. Check diaphragm stop down pressure and see Release Malfunctions G.

5. Shutter Malfunctions


A. External Observations

Mirror goes up but shutter does not release.
Power, control dial, lightmeter, release normal.


Note : Do External Tests #1, 2, 3, 4, 5 to define Shutter Malfunctions.




Shutter Cooked from Focal Plane



Shutter Released from Focal Plane




Trail Curtain Release from Front




B. External Observations

No shutter opening.
LCD displays 'EEE', finder 'Help' after mirror cycles.
Power, control dial, lightmeter, release normal.




Front Left,
Third Layer



C. External Observations

Shutter doesn't close.
1st curtain closes focal plane as mirror returns.
LCD displays 'EEE', finder 'Help' after mirror cycles.
Power, control dial, lightmeter, release normal.



C & C ASSOCIATES

D. External Observations


LCD displays 'EEE', finder 'Help' after mirror cycles.
Shutter operates for one cycle before 'EEE'.
Power, control dial, lightmeter, release normal.

Unsolder Or VPP wire at DC/DC. Remove B+ from battery wire and connect to Or VPP wire.
Release 1st Curtain by applying B+ through 1K Ω to TP-17A :
• Check for near infinite Ω between TP-16A and B- .
Release 2nd Curtain by applying B+ through 1K Ω to TP-17B :
• Check for near infinite Ω between TP-16B and B- .

No — • Repair SW-18 .
• Repair SW-19 .

Yes

• IC-3 may be defective. Replace IC-3 or Main FPC .



6. Aperture Malfunctions

Note : Do External Tests #1, 2, 3, 4, 5, 6 to define Aperture Malfunctions.


A. External Observations


Stop down lever doesn't move or auto aperture lever doesn't have free travel when depth of field preview slide is used
Manual and auto aperture incorrect.
Lens functions correctly.
Power, control dial, lightmeter, release, shutter normal.

Remove Mirror Box:

• Check stop down lever, springs, gears, MG-1 keeper, control levers.

B. External Observations

LCD does not display  when lens is off or with lens in manual.
Power, control dial, lightmeter, release, shutter normal.

Remove Covers, Left LCD. Ground pin 24, IC-3 through 0 Ω .
• Check for LCD  to turn off.

No

• Resolder pin 24, IC-3 . Retest.
• IC-3 may be defective. Replace IC-3 or Main FPC .

Yes

• Resolder pin 24, IC-3 . Retest.
• Check, clean, align Front Left Connector.
• Check SW-17 . Repair if defective.
• Use schematic to check SW-17 path. Repair path if defective.

C. External Observations

Manual aperture always stays open or erratic. Lens good.

Stop down lever and auto aperture lever move correctly and have free travel when depth of field preview slide is used.

Power, control dial, lightmeter, release, shutter normal.

Remove Covers

Ground **TP-22A** though 0Ω while release camera, lens in manual
• Check for normal manual apertures.

Yes

• **IC-4** may be defective. Replace **Main FPC**.

No


• Check for near **B+** at **TP-22B**.

No


• Check for typical 327Ω between **TP-22A** and **TP-22B**. Check **MG-1** wires, soldering if defective.
• Check path between **TP-22B** and **V-Bat**. Repair if defective.

Yes

• Check, clean, repair **MG-1**, keeper, wires spring.



Top, Prism Left, Second Layer



D. External Observations

LCD display **M** does not turn off when lens is set to 'A'.

Auto aperture incorrect.

Power, control dial, lightmeter, release, shutter normal.

• Check lens auto pin to extend in 'A'. Repair lens if defective.
Remove Covers:

• Check **SW-17** for short. Repair if defective.

• **IC-3** may be defective. Replace **IC-3** or **Main FPC**.

E. External Observations

No Release when lens is switched to 'A'. LCD displays 'EEE'.

Release normal without lens and with lens in manual diaphragm.

Power, control dial, lightmeter normal.

Remove Covers, Battery Chamber

Set lens to manual. Reset camera by grounding reset switch **SW-3** solder point. Ground **TP-18** while setting lens to 'A'.
• Check for normal operation.

Yes

• Check **SW-12**, soldering, wires, control levers. Repair if defective.


No

• Resolder pin 5, **IC-3**. Retest.
• Use schematic to check path between **TP-18** and pin 5, **IC-3**. Repair if defective.
• **IC-3** may be defective. Replace **IC-3** or **Main FPC**.


C & C ASSOCIATES

E. External Observations


Auto aperture always closes completely or erratic.
Lightmeter correct.
Manual aperture correct.
Power, control dial, release, shutter normal.



Top Left



Top, Prism Left




7. Film Transport Malfunctions

A. External Observations


LCD does not display cassette icon when frame number sensing pad is depressed.
Power, release normal.

Remove Covers




B. External Observations

Film transport motor runs when film door is closed without film.
Power, release normal.




C. External Observations


Film does not transport when film door is closed with film in camera.
LCD displays cassette icon when frame number sensing pad is depressed.
Power, release normal.




Top Right, Third Layer



Top Right, Second Layer




Top Left



D. External Observations

Film does not advance correctly to 1st frame or film spacing problems or film runs through without stopping.
Power, release normal.



Continued

C & C ASSOCIATES

Continued

- Check LCD to display moving film bar icons as sprocket turns.


Note : Improper spacing can be caused by noise on film advance switch **SW-31** even if icons are correct.

No


- Resolder **SW-27**, **SW-31** wires. Retest.
- Use schematic to check **SW-27**, **SW-31** paths. Repair if defective.
- Check **SW-27**, **SW-31**. Repair if defective.
- **IC-6**, **IC-5** or **IC-3** may be defective. Replace **Main FPC**.

Yes

- Check **SW-27**. Repair if defective.
- Use schematic to check **SW-27** path. Repair if defective.
- **IC-6**, **IC-5** or **IC-3** may be defective. Replace **Main FPC**.



Top Right, Second Layer



E. External Observations

Finder LCD does not count down last '9' frames.
Power, release normal.

- Check Cassette light seal and pressure plate.


Bad

- Repair or replace light seal or pressure plate.

Good

Remove Front, Top Covers, bottom center switch block, access **D FPC** under **Main FPC** Top Left:

- Use schematic to check **DX** paths for Ω . Repair or replace **DX FPC** if defective.
- Resolder **D FPC** / **DX FPC** Top Left, Prism Left. Retest.
- **IC-8** may be defective. Replace **D FPC**.



F. External Observations

No Auto Rewind.
Film Advance, Frame count normal.
Power, release normal.

- Advance film several frames. Press manual rewind button:
- Check for motor sound or 2 sec. current increase.

Yes

- Check rewind gears, rewind fork.

No

Continued

Continued

No

- Resolder M-3 wires. Retest.
- Apply battery power directly to M-3.
- Reverse leads between tests.
- Check for motor to turn in both directions.

No

- Check rewind gears. Repair or replace if defective.
- Check M-3. Replace if defective.

Yes


- Apply B- through 1KΩ probe to base Q-11 and B+ through 1KΩ probe to base Q-14.
- Check for M-3 to run.

No

- Resolder Q-11, Q-14. Retest.
- Use schematic to check Q-11, Q-14 paths. Repair if defective.
- Test PNP Q-11. Replace if defective.
- Test NPN Q-14. Replace if defective.

Yes

- IC-9 may be defective. Replace IC-9 or MD FPC and retest.



8. Flash Malfunctions.

A. External Observations

Shutter speed does not set to 1/250 when VC / CCC contact is grounded through 3KΩ.
Power, lightmeter, release, shutter, aperture normal.

- Check VC / CCC contact, Gr wire. Clean, repair, resolder if defective.
- IC-4 may be defective. Replace IC-4 or Main FPC.


Note : Do External Tests #1, 3, 4, 5, 6, 8 to define Flash Malfunctions.

B. External Observations

Finder doesn't display F/4, lens doesn't select F/4 when VC / CCC is shorted to AVEF while grounding VC / CCC through 3KΩ.
Power, lightmeter, release, shutter, aperture normal.

- Check AVEF contact, Pu wire. Clean, repair, resolder if defective.
- IC-4 may be defective. Replace IC-4 or Main FPC.

Hot Shoe




C. External Observations

Resistance between X contact and ground low with shutter closed or high with shutter open on 'B'.
Power, lightmeter, release, shutter, aperture normal.


- Check SW-X wires, soldering between hot shoe and prism right. Repair if defective.
- Check SW-X, path. Repair if defective.

C & C ASSOCIATES


Power




Release




Control Dial




Lightmeter




Shutter




Aperture




Flash




Film Transport



Wind




Rewind




C & C ASSOCIATES


Top Left




Top, Prism Left




Top, Prism Right




Top Right




Top Right, Bottom of LCD




Top Left, Second Layer




Top, Prism Left, Second Layer




Top, Prism Right, Third Layer




Top Left, Third Layer




Top Right, Third Layer




Front Left




Front Left, Second Layer




Handgrip, Charge Motor Removed




Front Left Connector Stack




DX Contacts




Hot Shoe



Bottom



Release Button Unit



C & C ASSOCIATES

VII. PARTS LIST

Name	Part Number	Name	Part Number
Top Cover Unit	CG1-0851-000	Release Button Unit	CG9-2677-000
Screen E, focusing	CG1-0860-000	Release Button	CA1-6349-000
Screw, top front	XA1-7170-307	Brush, control dial	CA1-6345-000
Screw, top right	X99-0561-000	Tripod socket	CA1-6369-000
Screw, top back	X91-1737-880	LCD, external	AF7-5002-000
Lever, eyepiece	CA1-6382-000	Eyepiece	CG9-2680-000
Cap, eyepiece lever	CA1-6383-000	Eyepiece, shutter unit	CG9-2681-000
Screw, eyepiece lever	X91-1436-910	Reset FPC	CG9-2691-000
Switch, H.S. Control	CA1-6506-000	LCD, lamp	WG1-0275-000
Shoe, flash	CA1-6504-000	Backup Battery	WK1-9022-000
Screw, flash shoe	XA1-3170-509	Main FPC	CY1-1252-000
Spring plate, flash	CA1-3385-000	Main Switch Unit	CG9-2678-000
Base, flash shoe	CA1-6505-000	Rewind Motor	WL1-9061-000
Base, flash shoe under top	CA1-6506-000	Rewind Gear Unit	CY1-1232-000
Screw, film door latch	X99-0561-000	MD FPC	CG1-087-000 0857
Cover, film door latch	CA1-6362-000	Finder FPC	CY1-1253-000
Button, film door latch	CA1-6365-000	LED, finder lamp	CH4-0152-000
Spring, film door button	CS1-5690-000	SP FPC	CY1-1234-000
Knob, film door	CA1-6443-000	AE Unit, with MG-1	CG1-0869-000
Lock, film door	CA1-6363-000	Mirror, reflex	CN1-5303-000
Spring, film door lock	CS1-5780-000	Mirror Unit	CG9-2689-000
Front Cover, apron	CG9-2684-000	Sprocket	CA1-4174-000
Screw, front apron	X91-1737-980	Charge Motor	WL1-9060-000
Sheet, rubber bottom	CA1-6305-000	Gear, charge	CS1-0826-000
Battery Pack Unit	CG9-2683-000	Gear, charge	CS1-0825-000
Cap, remote	CA4-1847-000	Gear, charge	CS1-0829-000
Screw, bottom	X91-1737-930	Film Wind Motor	WL1-9059-000
Screw, bottom	X91-1737-900	Shutter Unit, with FPC	CG1-0871-000
Screw, bottom	XA1-7170-257	Shutter FPC	CY1-1250-000
Spring, handgrip bottom	CS1-5893-000	Shutter Magnet Unit	CY1-1251-000
Spring, handgrip top	CS1-5894-000	Shutter Curtain, 1st	CF1-1721-000
Screw, film door hinge	XA-8200-707	Shutter Curtain, 2nd	CS1-6733-000
Film door hinge	CA1-6414-000	DC / DC	CH3-0021-000
Rubber, handgrip	CA1-6340-000	IC-1	CH4-0161-000
Film Door	CG1-0852-000	IC-3	CH4-0153-000
Sponge, cassette	CA1-6527-000	IC-9	CH4-0159-000
Pressure Plate	CF1-0423-000	IC-10, same as IC-9	CH4-0159-000
Latch, on film door	CA1-6522-000		

Preparation and Editorial Director, Chuck Bertone. Artwork and layout, Michael Johnson

©1994 C & C Associates


11112 S. Spotted Rd., Cheney, WA 99004

All rights reserved. No part of this publication may be reproduced, by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written consent of the publisher. While every precaution has been taken in the preparation of this manual, the publisher assumes no responsibility for any errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained herein. C & C Associates reserves the right to make changes or improvements in this manual at any time without notice.

Let's talk straight. If you have purchased this manual, you are a valued customer. If you are using a copy, you are a thief. Our business exists only because repair people see value in these publications and purchase them. If you are not paying for the benefits derived, then you are cheating those who do as well as those who make their living producing service manuals.


CG1-0852-000 FILM
BACK ASSEMBLY * SOLD WITH
BACK ASSEMBLY

CANON T 90



CANON T.90

N.S. - NOT SOLD SEPARATLY



CANON T 90

