

FOTON



FOTOVERSCHLÜSSE

**HINWEISE
FÜR
REPARATURWERKSTÄTTEN**



INSTRUCTIONS FOR REPAIR SHOPS

PHOTOGRAPHIC SHUTTERS

Service Instructions for PRONTOR Shutters

Models: PRONTOR-PRESS I-10p; p1; p2

1. General Introductory Remarks

The purpose of these service instructions is to assist repairmen in handling repairs rapidly, efficiently, reliably and without any appreciable difficulties. The instructions start with a description of the operation of the shutter and it is advisable to read this paragraph carefully, because knowledge of the functions of the individual components is the basis for understanding the co-ordinated operation of all components in the PRONTOR-PRESS shutter.

Notes

- a) The PRONTOR-PRESS shutter can only be dismantled after it has previously been removed from the camera.
- b) The numbers used in the text are the line item numbers in the spare parts list.
- c) A reference to right or left in the service instructions refers to the position shown in the illustrations in the spare parts list.

All parts shown in the spare parts list are shown in the position as assembled in the shutter, so that in case of doubt they can be used as reference.

A) Tools for the Repair

Except for the front plate wrench MV 100 and the lever bending tool A2 there are no other special tools required for dismantling and repairing a shutter.

In selecting the screwdrivers it is important, however, to select the right size for the various screws. Wherever screwdrivers of improper size are used, chances are that the slots in the screws will be damaged.



INSTRUCTIONS FOR REPAIR SHOPS

PHOTOGRAPHIC SHUTTERS

b) Lubricants

The manufacturer lubricates the shutter by means of special pastes at all positions requiring lubrication and this lubrication can be regarded as a life-time lubrication. In doing repair work lubrication is only necessary where parts have been washed or have been replaced by new ones.

From the attached lubrication diagram it can be seen at what points the shutter components have to be lubricated and what lubricant is to be used.

Note

In lubricating the shutter, lubricants other than those indicated in the lubrication diagram must not be used. Oil or grease must not be used in the shutter. The repairman must see that there will be no accumulation of lubricants on edges, in openings and holes. If necessary, the excessive lubricant must be wiped off.

c) Spare Parts

If in repairing a shutter it is necessary to replace parts, only

factory-made spare parts

should be used. These parts can be ordered by using the attached spare parts list as reference. In this respect it is necessary to indicate the exact designation and the part number given in the spare parts list. This is the only way to insure that the correct replacement parts will be supplied.



INSTRUCTIONS FOR REPAIR SHOPS

PHOTOGRAPHIC SHUTTERS

2. Mode of Operation

Depending upon the respective exposure time set, the single-action pre-set shutter provided with two cable release sockets 16 and 26 can be opened by use of the cable release socket 16 for a longer or a shorter time interval. On the other hand the cable release socket 26 merely serves to simultaneously open the shutter blades 46 and diaphragm blades 49 for pre-viewing.

a) Opening the Shutter and Diaphragm Blades

By actuating a cable release fitted into the cable release socket 26, the shutter blade ring 45 is rotated by the tripping pin 27 striking the lug 108. With the drive ring 44 held in position by spring action, a rotation of the shutter blade ring 45 causes the shutter blades to open and simultaneously the diaphragm opening rivet 109 displaces the diaphragm lever 111 resting against the diaphragm disc 50 thus opening the diaphragm fully.

When the shutter blade ring 45 returns to its original position, the shutter blades 46 close, the diaphragm lever 111 becomes disengaged and the diaphragm disc 50 is rotated by the action of the diaphragm spring 56 - the diaphragm stops down to the aperture set. The integral cam of the diaphragm index ring 58, against which the diaphragm lever 111 rests, governs the size of the diaphragm opening (aperture).

b) Instantaneous Speeds

When actuating the shutter by means of the cable release socket 16, the release lever 24 is displaced so that the long locking rivet moves in front of the locking lug 110 of the shutter blade ring 45 and holds the latter in position, while the cocking latch 102 in positive engagement with the tripping lever initiates the shutter cycle.



INSTRUCTIONS FOR REPAIR SHOPS

PHOTOGRAPHIC SHUTTERS

The cocking latch 102 strikes the downward lug of the driving lever 35 and displaces this lever radially toward the rim of the shutter, while the braking latch 104 is moved toward the nozzle.

The driving latch 103 in positive engagement with the driving lever 35 is pressed against the ring lever 29 and a recess of this latch accepts the driving rivet of the ring lever. Before the cocking latch 102 disengages the driving lever 35, the latter strikes the star-shaped locking lever 31b, moves this lever toward the wall of the housing and disengages the ring lever 29 so far locked in position.

After the driving lever 35 has become disengaged by the cocking latch 102, it is displaced by the action of the driving spring 36 toward the nozzle. Simultaneously the driving ring 44 is displaced by the ring lever 29 in engagement with the latter and the shutter blades open. The rest of the shutter cycle is delayed by the braking latch 104 resting against the brake lever 40, until this latch has displaced the brake lever 40 and is permitted to slip past (please also see speed setting system). At the same time the ring lever 29 and the driving ring 44 connected to the latter are returned to their starting positions by the driving latch 103 and the action of the driving spring 31 - the shutter blades 46 close.

c) Setting B

When the shutter is set to "B", the B lever 10, a lug of which rests against the setting ring 3, is disengaged, so that it comes to rest against the long locking rivet of the release lever 24. When the shutter completes its cycle, the B lever 10 moves toward the nozzle and locks the drive ring at the moment of the maximum opening of the shutter blades.



INSTRUCTIONS FOR REPAIR SHOPS

PHOTOGRAPHIC SHUTTERS

When the pressure on the tripping pin is eased off, the release lever 24 returns to its original position carrying along the B lever 10; the drive ring 44 becomes disengaged and the shutter blades 46 close.

3. Dismantling and Re-assembling the Shutter

a) Dismantling the Shutter

After removing the four fixing screws 51;55 of the bottom 57, this part can be lifted off together with the diaphragm assembly. (For further details please see diaphragm system).

The shutter mechanism is now accessible. The shutter blades 46 can be lifted off directly, the shutter blade ring spring 22 can be unhooked and the shutter blade ring 45 and the drive ring 44 can be removed. The removal of the other parts is relatively simple and only where it is deemed necessary are detailed instructions given in the descriptions of the individual systems.

Note

Should it be necessary to replace the front plate 2, the setting ring 3 or the click-stop spring 4, the front plate ring 1 must first be unscrewed by use of the front plate retaining ring wrench MV 100.

b) Re-assembling the Shutter

Note

In general the repairman has to see to it that in re-assembling the shutter no levers are bent out of position and no springs are stretched, as otherwise there will be no assurance of a proper shutter function. Particular attention must be given to the position of the tripping pin 27, as this part becomes disengaged when the shutter blade ring 45 is removed from the shutter and may slip out of



INSTRUCTIONS FOR REPAIR SHOPS

PHOTOGRAPHIC SHUTTERS

the drilled hole of the cable release socket. The driving spring 36 must be hooked onto the spring rivet 105 of the adjusting lever 38.

Detailed instructions on how to re-assemble the shutter are given in the descriptions of the individual systems.

4. Cocking and Tripping System

The function of the cocking and tripping system has already been described in section 2. The following section contains instructions on how to replace parts, on the assembly and on the correction of defects.

a) Replacing Parts

In order to remove the release lever 24 together with the cocking latch 102, the B lever 10 and the bearing bridge 20 have to first be removed. To facilitate the work in re-assembling the shutter, we also recommend the removal of the driving lever 35.

b) Re-assembling the Release Lever 24

Fit the cocking latch spring 21 on the bushing in such a manner that the long spring arm rests against the nozzle and the short arm against the wall of the housing. Place the release lever 24 into the bearing hole provided in the housing, place one arm of the tripping spring 23 against the nozzle and the other arm against the short rivet of the release lever 24, fit on the bearing bridge 20 and screw it in position. Use a pair of pincers to pull the cocking latch spring 21 toward the wall of the housing, lift it a little bit and place it against the spring rivet of the cocking latch 102.



INSTRUCTIONS FOR REPAIR SHOPS

PHOTOGRAPHIC SHUTTERS

<u>Defect</u>	<u>Cause of the Defect</u>	<u>Correction</u>
1. Shutter does not trip.	1. Release lever spring 23 does not press the release lever 24 against the tripping pin 17.	1. Fit in the release lever spring 23 as described under 4b, so that the release lever 24 is pressed against the tripping pin 17.
	2. Cocking latch 102 does not strike the lug of the driving lever 35.	2a. Fit in the cocking latch spring 21 as described under 4b, so that the cocking latch 102 is pressed against the nozzle. 2b. Bend the supporting lug of the cocking latch 102 in such a manner that the driving lever 35 is displaced and becomes disengaged in the cocking position.
	3. Ring lever 29 does not engage the driving latch 103.	3. Place one arm of the driving latch spring 32 against the spring rivet for the driving spring 36 and insert the other one into the spring hole provided in the driving latch.



INSTRUCTIONS FOR REPAIR SHOPS

PHOTOGRAPHIC SHUTTERS

5. Slow Speed Assembly and Speed Setting System

Rotating the setting ring 3 controls both the engagement of the brake lever 40 and the engagement and disengagement of the escapement. When the shutter is set for either of the speeds 1, 1/2, 1/4 and 1/8 sec. the escapement is in engagement, whereas the other shutter speeds are controlled by the relative position of the brake lever 40 and the resultant retarding action exerted by the slow speed assembly 8.

After removal of the brake lever 40 and after unscrewing the fixing screws 6 + 7, the slow speed assembly can be removed from the shutter.

Installing the Slow Speed Assembly

Rotate the setting ring 3 to the 1 sec. position, fit in the slow speed assembly 8 and screw it in position. Slip the draw lever of the brake lever 40 on the stud of the gear segment, place the washer 41 on the threaded hole, slide the brake lever 40 over it and screw it in position. After the brake spring 101 is hooked up on the rivet of the gear segment and on the brake lever screw 39, the slow speed assembly 8 is ready for operation.

Note

When assembling the setting ring 3, the repairman has to see to it that the escapement rocker arm and the control rivet of the gear segment, which project through the bottom of the housing, are accepted in the recesses provided in the setting ring 3.



INSTRUCTIONS FOR REPAIR SHOPS

PHOTOGRAPHIC SHUTTERS

<u>Defect</u>	<u>Cause of the Defect</u>	<u>Correction</u>
1. When set for slower speeds the shutter completes its cycle without any retarding action exerted by the slow speed assembly.	1. The brake lever 40 is not in engagement; brake spring 101 is unhooked.	1. Hook up brake spring 101.
2. The shutter speeds are slower than indicated by the relative positions of the speed setting ring.	2a. Brake lever 40 does not move easily; washer 41 has been forgotten. 2b. Slow speed assembly is dirty.	2a. Remove brake lever 40 and re-install it together with the washer 41. 2b. Replace slow speed assembly.

Adjusting the Shutter Speeds

The shutter speeds can be adjusted by swaging or filing the control cam of the speed setting ring 3.

6. Shutter Blade SystemAssembly Instructions

The red mark on the setting ring 3 must be set to "B". Slide the drive ring 44 with the recess under the ring lever 29 in such a manner that its rivet will get into the proper place and the drive ring 44 will be seated on the nozzle. In doing so attention must be given that the lug of the slow speed assembly 106 will rest against the rivet of the escapement rocker arm and that when the drive ring 44 is rotated the



INSTRUCTIONS FOR REPAIR SHOPS

PHOTOGRAPHIC SHUTTERS

contact arm 107 presses the contact spring 100 against the flash contact pin (please see flash contact system).

Use a pair of pincers to seize the drive ring spring 31 and place it against the spring rivet of the drive ring 4.

Before the shutter blade ring 45 is fitted in position, the spring 22 of the shutter blade ring must be hooked up on the opening lug 108 and verify that the tripping pin is in the cable release socket. Rotate the shutter blade ring 45 in such a manner that the opening lug 108 will be in front of the tripping pin and place it on the nozzle. For mounting the shutter blades 46 the shutter must be set to "B", opened and arrested in that position. The shutter blades are now fitted clockwise. With the diaphragm fully opened, the bottom 57 must be aligned with the drilled holes for the fixing screws in the housing, placed in position and secured by means of four screws 51;55.

<u>Defect</u>	<u>Cause of the Defect</u>	<u>Correction</u>
1. Shutter blades do not close.	1a. Shutter blade ring spring 22 has not been hooked up.	1a. Hook up the shutter blade ring spring 22.
	1b. The drive ring spring 31 is not placed against the drive ring.	1b. Place the drive ring spring 31 against the drive ring.
2. Shutter blades do not open for preview control.	2. Tripping pin 27 is missing, or not in the cable release socket 26.	2. Fit in the tripping pin 27.



INSTRUCTIONS FOR REPAIR SHOPS

PHOTOGRAPHIC SHUTTERS

Note

Shutter blades 46 and diaphragm blades 49 must be treated with particular care. Bent parts must be replaced by new ones. Shutter blades and diaphragm blades must be protected from fingerprints which tend to cause corrosion. In general, parts that are not in perfect working condition should be replaced by new ones and only in such cases where replacement parts are not available, the shutter and diaphragm blades should be placed on a flat surface to wipe off the fingerprints by use of a clean cloth.

Oil or grease should never be used neither on the shutter blades nor on the diaphragm blades.

7. Diaphragm System

After unscrewing the three fixing screws 47, the diaphragm covering disc 48, the diaphragm blades 49 and the diaphragm disc 50 can be lifted off from the bottom. The diaphragm index ring 58 carried on a shoulder of the bottom 57 is secured in position by use of the heads of the retaining screws 52.

Re-assembly

The bottom 57 must be placed on the worktable as shown in the spare parts list. In fitting the diaphragm disc 50 the repairman has to see to it that the two rivets come to rest in the two recesses provided in the bottom 57 and that the diaphragm opening lever will be to the left of the rivet. Fit on the diaphragm blades 49 in a counterclockwise direction so that their edges will be aligned with the outside edge of the diaphragm disc, place the flat spring into the slot provided for this spring in the bottom, fit on the diaphragm covering disc 48 in the position shown in the spare parts list and rotate it slightly so that the rivets will come to rest



INSTRUCTIONS FOR REPAIR SHOPS

PHOTOGRAPHIC SHUTTERS

in the holes. This can more easily be done by use of a pair of pincers or a scriber. Align the diaphragm covering disc 48 with the screw holes and secure it by means of the three screws 47.

Fit the diaphragm spring 56 on the bearing rivet, place the long arm against the rivet of the diaphragm disc and the short arm against the bottom rivet.

The diaphragm blades 49 and the diaphragm disc 50 must move so easily that they can be moved by the action of the diaphragm spring.

8. Flash Contact System

The shutter is X synchronized, i. e. the contact is closed at the position when the shutter blades in opening have to travel another 1.5 to 2 mm to clear the aperture. When the shutter completes its cycle, the contact arm 107 of the drive ring 44 presses the contact spring 100 against the flash contact pin riveted into the wall of the housing and forms a live connection.

<u>Defect</u>	<u>Cause of the Defect</u>	<u>Correction</u>
1. Although the flash equipment is in proper working condition, the flash is not fired.	1a. The contact is not closed, as the contact arm 107 of the drive ring 44 is bent out of position.	1a. Adjust the contact arm 107 or replace the drive ring 44.



INSTRUCTIONS FOR REPAIR SHOPS

PHOTOGRAPHIC SHUTTERS

<u>Defect</u>	<u>Cause of the Defect</u>	<u>Correction</u>
	1b. Drive ring 44 is not properly fitted into position; contact arm 107 is located between the contact spring 100 and the flash contact pin.	1b. Fit in the drive ring 44 in such a manner that the contact arm 107 in being displaced presses the contact spring 100 against the flash contact pin.
2. Contact making does not occur at the proper position of the opening travel of the shutter blades.	2. Contact arm 107 is bent out of position.	2. See 1a.

ALFRED GAUTHIER G.m.b.H.

Calmbach/Enz

Liste best aus Blatt 1 - 8

Anz der Änd. Bl.

Gefertigt 9. 3. 65 *fe.*

Geprüft


Blatt Nr.

1

Ersatzteilliste


Grundmodell I-10


PRONTOR - PRESS




2

3







Ersatzteilliste				Gefertigt	9. 3. 65 <i>fe</i>
PRONTOR - PRESS I - 10				Geprüft	Blatt Nr. 5
Pos.	Teil - Nr.	Stück	Benennung		
1	IJR5p - 239.1	1	<u>Frontplattenring</u> front plate ring		
2	I - 10 - 143	1	<u>Frontplatte</u> front plate	<u>ohne Bild</u> without illustration	
3	I - 10 - 137	1	<u>Einstellring</u> speed setting ring	<u>ohne Bild</u> without illustration	
4	0376y - 362	1	<u>Rastenfeder</u> notch spring		
5	I - 10 - U 1	1	<u>Kapsel</u> housing	<u>wird nicht abgegeben</u> cannot be supplied	
6	7 000 884	1	<u>Hemmwerkschraube</u> screw for slow speed assembly		
7	7 002 002	1	<u>Hemmwerkschraube</u> screw for slow speed assembly		
8	I - 12 - G 20	1	<u>Hemmwerk</u> slow speed assembly	<u>wird nur als Ganzes abgegeben</u> only complete unit can be supplied	
9	7 002 787	1	<u>Zeithebellagerschraube</u> B - lever bearing screw		
10	I - 10 - 119	1	<u>Zeithebel</u> B - lever		
11	I - 10 - 121	1	<u>Zeithebelfeder</u> B - lever spring		
12	7 002 139	1	<u>Sektorenringschraube</u> shutter blade ring screw		
13	IJR5p3 - 127	1	<u>Anschlagplatte</u> stop plate		
14	IJR5p - 73	1	<u>Gewindestift</u> threaded pin		
15	7 002 977	1	<u>Auslösrohrschraube</u> cable release socket screw		
16	I - 12 - 123.1	1	<u>Auslösrohr " A "</u> cable release socket " A "		
17	I - 12 - U124	1	<u>Auslösstift</u> cable release socket pin		
18	7 000 985	1	<u>Lagerbrückenschraube</u> bearing bridge screw		
19	7 002 228	1	<u>Lagerbrückenschraube</u> bearing bridge screw		
ALFRED GAUTHIER G.m.b.H. Calmbach / Enz					

Gefertigt 9. 3. 65 *de.*

Geprüft

Blatt Nr.
6

Pos.	Teil - Nr.	Stück	Benennung
20	I - 10 - U361	1	<u>Lagerbrücke</u> bearing bridge
21	I - 10 - 682	1	<u>Spannklinkenfeder</u> cocking latch spring
22	IJR5p - 133	1	<u>Sektorenringfeder</u> shutter blade ring spring
23	I - 10 - 150	1	<u>Auslöserfeder</u> release spring
24	I - 10 - U 85	1	<u>Auslöser</u> release
25	IJR5p - 73	2	<u>Gewindestift</u> threaded pin
26	IJR5q - 72a	1	<u>Auslösrohr " B "</u> cable release socket " B "
27	IJR5p - 74a	1	<u>Auslösstift " B "</u> cable release socket pin " B "
28	7 002 294	1	<u>Ringhebelschraube</u> ring lever screw
29	I - 12 - U 67	1	<u>Ringhebel</u> ring lever
30	7 002 457	1	<u>Zuziehfederschraube</u> closing spring screw
31	IJR5 - 107	1	<u>Antriebringfeder</u> drive ring spring
32	IJR5 - 70	1	<u>Treibklinkenfeder</u> driving latch spring
33	QJR10 - 102.1	1	<u>Treibhebelschraube</u> drive lever screw
34	JRI - 64	1	<u>Brmsklinkenfeder</u> brake latch spring
35	IJR5p - U 63	1	<u>Treibhebel</u> drive lever
36	IJR5 - 103	1	<u>Treibfeder</u> drive spring
37	7 001 416	1	<u>Regulierhebelschraube</u> adjusting lever screw
38	IJR5 - U 45	1	<u>Regulierhebel</u> adjusting lever

ALFRED GAUTHIER G.m.b.H. Calmbach / Enz

Ersatzteilliste				Gefertigt	9. 3. 65	e.
PRONTOR - PRESS				I - 10	Geprüft	Blatt Nr. 7
Pos.	Teil - Nr.	Stück	Benennung			
39	3114-20-3220	1	<u>Bremshelbschraube</u> brake lever screw			
40	IJRX5 - U 34.1	1	<u>Bremshetel</u> brake lever			
41	OJRX5 - 78	1	<u>Unterlegscheibe für Bremshetel</u> washer for brake lever			
42	7 000 073	2	<u>Einstellbogenschraube</u> scale band screw			
43	I - 10 - 134	1	<u>Einstellbogen</u> scale band	ohne Bild without illustration		
44	I - 10 - U 80	1	<u>Antriebsring</u> drive ring			
45	I - 10 - U 625	1	<u>Sektorsring</u> shutter blade ring			
46	IJRX5 - 61	5	<u>Sektor</u> shutter blade			
47	7 002 941	3	<u>Irisdeckscheibenschraube</u> diaphragm covering disc screw			
48	I - 10 - 10	1	<u>Irisdeckscheibe</u> diaphragm covering disc			
49	I - 10 - U 5	5	<u>Blenden Sektor</u> diaphragm shutter blade			
50	I - 10 - U 8	1	<u>Irischeibe</u> diaphragm disc			
51	7 001 428	2	<u>Bodenschraube</u> bottom screw			
52	7 001 431	3	<u>Halteschraube für Iriszeigerring</u> holding screw for diaphragm pointer ring			
53	I - 10 - 15	1	<u>Frictionsfeder</u> friction spring			
54	7 002 876	2	<u>Anschlösschraube für Iriszeigerring</u> stop screw for diaphragm pointer ring			
55	7 002 002	2	<u>Bodenschraube</u> bottom screw			
56	I - 10 - 766	1	<u>Blendenfeder</u> diaphragm spring			
57	I - 10 - U 2	1	<u>Boden</u> bottom	wird nicht abgegeben cannot be supplied		
ALFRED GAUTHIER G.m.b.H. Calmbach / Enz						

PRONTOR - PRESS I-10

Geprüft

Blatt Nr.
8

[illegible]

ALFRED GAUTHIER G.m.b.H. Calmbach / Enz

Ersatzteilliste

PRONTOR-PRESS I-10p

Fa. Polaroid USA

Kamera :

Optik/Lens: Ysaron 1:4,5 / 75

Liste best. aus Blatt 1 - 4



Anz. der Änd. Bl.



Geteiltigt 9. 3. 65 /

Geprüft

Blatt Nr.

1






12



16



25




44




43





46



48



50a



Ersatzteilliste				Gefertigt 9.3.65 <i>fc</i>	
PRONTOR - PRESS I - 10p				Geprüft	Blatt Nr. 4
Pos.	Teil - Nr.	Stück	Benennung		
2	I - 10p - 143	1	<u>Frontplatte</u> front plate	an Stelle von I - 10 - 143 inst. of I - 10 - 143	
3	I - 10p - 137	1	<u>Einstellring</u> speed setting ring	an Stelle von I - 10 - 137 inst. of I - 10 - 137	
5	I - 10p - U 1	1	<u>Kapsel</u> ohne Bild wird nicht abgegeben housing without illustration cannot be supplied	an Stelle von I - 10 - U1 inst. of I - 10 - U1	
12	7 002 445	1	<u>Sektorenringschraube</u> shutter blade ring screw	an Stelle von 7 002 139 inst. of 7 002 139	
16	I - 12p - 123	1	<u>Auslößrohr " A "</u> cable release socket " A "	an Stelle von I - 12 - 123,1 inst. of I - 12 - 123,1	
26	IJR5p - 72a	1	<u>Auslößrohr " B "</u> cable release socket " B "	an Stelle von IJR5q - 72a inst. of IJR5q - 72a	
43	I - 10p - 134	1	<u>Einstellbogen</u> scale band	an Stelle von I - 10 - 134 inst. of I - 10 - 134	
44	I - 10p - U 80	1	<u>Antriebring</u> drive ring	an Stelle von I - 10 - U 80 inst. of I - 10 - U 80	
46	IJR5p - 61	5	<u>Sektor</u> shutter blade	an Stelle von IJR5 - 61 inst. of IJR5 - 61	
48	I - 10p - 10	1	<u>Irisdeckscheibe</u> diaphragm covering disc	an Stelle von I - 10 - 10 inst. of I - 10 - 10	
50	I - 10p - U 8	1	<u>Irisscheibe</u> diaphragm disc	an Stelle von I - 10 - U 8 inst. of I - 10 - U 8	
50a	7 002 953	1	<u>Fixierschraube</u> locating screw		
57	I - 10p - U 2	1	<u>Boden</u> ohne Bild wird nicht abgegeben bottom without illustration cannot be supplied	an Stelle von I - 10 - U2 inst. of I - 10 - U2	
58	I - 10p - 7	1	<u>Iriszeigerring</u> diaphragm pointer ring	an Stelle von I - 10 - 7 inst. of I - 10 - 7	
59	IJR5p - 164	1	<u>Anschraubring</u> flange		
			Die übrigen Teile nach Grundmodell I - 10 The remaining parts as per basic model I - 10		
ALFRED GAUTHIER G.m.b.H. Calmbach / Enz					

Ersatzteilliste

PRONTOR - PRESS I-10p1

Fa. Polaroid USA

Kamera :

Optik/Lens: Ysaron 1:4.5 / 105

Liste best. aus Blatt 1 - 4



Anz. der Änd. Bl.




Gefertigt 9. 3. 65 *fe.*

Geprüft

Blatt Nr.

1







43





45



K 17 / 2



50a



Ersatzteilliste			Gefertigt 9. 3.65 /e		
PRONTOR - PRESS I-10p1			Geprüft	Blatt Nr. 4	
Pos.	Teil - Nr.	Stück	Benennung		
2	I - 10p - 143	1	<u>Frontplatte</u> front plate	an Stelle von I - 10 - 143 inst. of I - 10 - 143	
3	I - 10p - 137	1	<u>Einstellring</u> speed setting ring	an Stelle von I - 10 - 137 inst. of I - 10 - 137	
5	I - 10p - U 1	1	<u>Kapsel</u> ohne Bild housing without illustration	wird nicht abgegeben cannot be supplied	an Stelle von I - 10 - U1 inst. of I - 10 - U1
12	7 002 445	1	<u>Sektorenringschraube</u> shutter blade ring screw	an Stelle von 7 002 139 inst. of 7 002 139	
16	I - 12p - 123	1	<u>Auslösrohr " A "</u> cable release socket " A "	an Stelle von I - 12 - 123.1 inst. of I - 12 - 123.1	
26	IJRX5p - 72a	1	<u>Auslösrohr " B "</u> cable release socket " B "	an Stelle von IJRX5q - 72a inst. of IJRX5q - 72a	
43	I - 10p1 - 134	1	<u>Einstellbogen</u> scale band	an Stelle von I - 10 - 134 inst. of I - 10 - 134	
44	I - 10p - U 80	1	<u>Antriebring</u> drive ring	an Stelle von I - 10 - U 80 inst. of I - 10 - U 80	
46	IJRX5p - 61	5	<u>Sektor</u> shutter blade	an Stelle von IJRX5 - 61 inst. of IJRX5 - 61	
48	I - 10p1 - 10	1	<u>Irisdeckscheibe</u> diaphragm covering disc	an Stelle von I - 10 - 10 inst. of I - 10 - 10	
50	I - 10p - U 8	1	<u>Irisscheibe</u> diaphragm disc	an Stelle von I - 10 - U 8 inst. of I - 10 - U 8	
50a	7 002 953	1	<u>Fixierschraube</u> locating screw		
57	I - 10p - U 2	1	<u>Boden</u> ohne Bild bottom without illustration	wird nicht abgegeben cannot be supplied	an Stelle von I - 10 - U2 inst. of I - 10 - U2
58	I - 10p1 - 7	1	<u>Iriszeigerring</u> diaphragm pointer ring	an Stelle von I - 10 - 7 inst. of I - 10 - 7	
59	IJRX5p - 164	1	<u>Anschraubring</u> flange		
			Die übrigen Teile nach Grundmodell I - 10 The remaining parts as per basic model I - 10		
ALFRED GAUTHIER G.m.b.H. Calmbach / Enz					

Ersatzteilliste

PRONTOR-PRESS 1-10p2

Fa. Polaroid USA

Kamera :

Optik/Lens: Ysarex 1:4,7 / 127

Liste best.aus Blatt 1 - 4


Anz.der Änd.Bl.






Gefertigt 9. 3. 65 *fe.*

Blatt Nr.

Geprüft



1







➡ 50a



Ersatzteilliste			Gefertigt 9.3.65 <i>fe.</i>
PRONTOR - PRESS I-10 p2			Geprüft
			Blatt Nr. 4
Pos.	Teil - Nr.	Stück	Benennung
2	I - 10p - 143	1	<u>Frontplatte</u> front plate an Stelle von I - 10 - 143 inst. of I - 10 - 143
3	I - 10p - 137	1	<u>Einstellring</u> speed setting ring an Stelle von I - 10 - 137 inst. of I - 10 - 137
5	I - 10p - U 1	1	<u>Kapsel</u> ohne Bild wird nicht abgegeben an Stelle von I - 10 - U 1 housing without illustration cannot be supplied inst. of I - 10 - U 1
12	7 002 445	1	<u>Sektorenringschraube</u> shutter blade ring screw an Stelle von 7 002 139 inst. of 7 002 139
16	I - 12p - 123	1	<u>Auslösröhr "A"</u> cable release socket "A" an Stelle von I - 12 - 123,1 inst. of I - 12 - 123,1
26	IJR5p - 72a	1	<u>Auslösröhr "B"</u> cable release socket "B" an Stelle von IJR5q - 72a inst. of IJR5q - 72a
43	I - 10p2 - 134	1	<u>Einstellbogen</u> scale band an Stelle von I - 10 - 134 inst. of I - 10 - 134
44	I - 10p - U 80	1	<u>Antriebring</u> drive ring an Stelle von I - 10 - U 80 inst. of I - 10 - U 80
46	IJR5p - 61	5	<u>Sektor</u> shutter blade an Stelle von IJR5 - 61 inst. of IJR5 - 61
48	I - 10p2 - 10	1	<u>Irisdeckscheibe</u> diaphragm covering disc an Stelle von I - 10 - 10 inst. of I - 10 - 10
50	I - 10p - U 8	1	<u>Irisscheibe</u> diaphragm disc an Stelle von I - 10 - U 8 inst. of I - 10 - U 8
50a	7 002 953	1	<u>Fixierschraube</u> locating screw
57	I - 10p - U 2	1	<u>Boden</u> ohne Bild wird nicht abgegeben an Stelle von I - 10 - U2 bottom without illustration cannot be supplied inst. of I - 10 - U2
58	I - 10p2 - 7	1	<u>Iriszeigerring</u> diaphragm pointer ring an Stelle von I - 10 - 7 inst. of I - 10 - 7
59	IJR5p - 164	1	<u>Anschraubring</u> flange
			Die übrigen Teile nach Grundmodell I - 10 The remaining parts as per basic model I - 10
ALFRED GAUTHIER G.m.b.H. Calmbach / Enz			



INSTRUCTIONS FOR REPAIR SHOPS

PHOTOGRAPHIC SHUTTERS

Service Instructions for PRONTOR Shutters

Models PRONTOR-PRESS I-12p and I-12p1
-----1. General Introductory Remarks

The purpose of these service instructions is to assist repairmen in handling repairs rapidly, efficiently, reliably and without any appreciable difficulties. The instructions start with a description of the operation of the shutter and it is advisable to read this paragraph carefully, for the knowledge of the functions of the individual components is the basis for understanding the co-ordinated operation of all components in the PRONTOR-PRESS shutter.

Notes

- a) The PRONTOR-PRESS shutter can only be dismantled after it has previously been removed from the camera.
- b) The numbers used in the text are the line item numbers in the spare parts list.
- c) A reference to right or left in the service instructions refers to the position shown in the illustrations in the spare parts list.

All parts shown in the spare parts list are shown in the position as assembled in the shutter, so that in case of doubt they can be used as reference.

a) Tools for the Repair

Apart from the front plate wrench MV 100 and the lever bending tool A2 there are no other special tools required for dismantling and repairing a shutter.

In selecting the screwdrivers it is important, however, to select the right size for the various screws. Wherever screwdrivers of improper size are used, chances are that the slots in the screws will be damaged.



INSTRUCTIONS FOR REPAIR SHOPS

PHOTOGRAPHIC SHUTTERS

b) Lubricants

The manufacturer lubricates the shutter by means of special pastes at all positions requiring lubrication and this lubrication can be regarded as life-time lubrication. In doing repair work lubrication is only necessary where parts have been washed or been replaced by new ones.

From the attached lubrication diagram it can be seen at what points the shutter components have to be lubricated and what lubricant is to be used.

Note

In lubricating the shutter, lubricants other than those indicated in the lubrication diagram must not be used. Oil or grease must not be used in the shutter. The repairman must see that there will be no accumulation of lubricants on edges, in openings and holes. If necessary the excessive lubricant must be wiped off.

c) Spare Parts

If in repairing a shutter it is necessary to replace parts, only

factory-made spare parts

should be used. These parts can be ordered by using the attached spare parts list as reference. In this respect it is necessary to indicate the exact designation and the part number given in the spare parts list, for this is the only way to insure that the correct replacement parts will be supplied.

2. Mode of Operation

By actuating the tripping lever 21 (or the cable release) the PRONTOR-PRESS single-action shutter is cocked and tripped. When the cocking lever is actuated, the cocking latch 102

INSTRUCTIONS FOR REPAIR SHOPS



PHOTOGRAPHIC SHUTTERS

- pivotally riveted to the tripping lever 21, strikes the stop lug of the drive lever 31 and displaces the latter radially toward the rim of the shutter. An integral raised lug of the drive lever 31 strikes a star-shaped locking lever 108 riveted to the shutter blade ring 41, which locks the drive ring 40, and displaces this ring toward the rim of the shutter. At the same time the brake latch 104 pivotally riveted to the driving lever 31, slides along the abutment of the brake lever 36 toward the nozzle. Just before the end of the cocking travel the driving latch 104 riveted to the driving lever, engages the ring lever; and the cocking latch 102 displaces the lever 27, preventing the tripping of the shutter, toward the rim of the shutter, then the driving lever 31 becomes disengaged and the shutter completes its cycle.

The shutter cycle involves the following operations:

During the return travel of the drive lever 31 the driving latch 103 displaces the ring lever 24 and the drive ring 40 connected to it, the shutter blades 43 open and depending upon the previously set shutter speed, the cycle is delayed by the action of the slow speed assembly 8 and of the brake lever 36 (see speed setting system).

The brake lever 36 returning to its original position while the shutter completes its cycle, disengages the braking latch 104, while simultaneously the ring lever 24 driven by the driving latch 103, returns the driving ring 40 to its starting position - the shutter blades close and the star-shaped locking lever 108 engages the drive ring lug and thus prevents bouncing of the shutter blades 43.

When the tripping lever 21 becomes disengaged, the ring lever 24 becomes again engaged by the tripping prevention lever 27.



INSTRUCTIONS FOR REPAIR SHOPS

PHOTOGRAPHIC SHUTTERS

b) Time Exposures "B" or "T"

When set for instantaneous speeds the locking lever 11 and the B lever 10 resting against the locking lever are displaced toward the rim of the shutter by the integral control slot of the setting ring 3 to such an extent that the driving lever 31 slips past.

Setting "B"

When the setting ring 2 is rotated to the position "B", the locking lever becomes disengaged to such an extent that the B lever 10 rests only against the raised lug of the tripping lever 21.

When the shutter completes its cycle, the B lever 10 travels in the direction of the nozzle, so that the drive lever 31 is stopped in operation and kept in position when the shutter blades are completely opened. During the return travel the raised lug of the tripping lever 21 is displaced toward the rim of the shutter and the driving lever 31 becomes disengaged permitting the shutter to complete its cycle and the shutter blades to close.

Setting "T"

When the shutter is set for "T" the locking lever 11 is completely disengaged from the setting ring and rests against the driving lever 31. Similar to setting "B", when the shutter completes its cycle, the B lever 10 stops the driving lever 31 when the shutter blades are open, while the locking lever 11, still resting against the raised lug of the tripping lever 21, has not returned to its original position.

INSTRUCTIONS FOR REPAIR SHOPS



PHOTOGRAPHIC SHUTTERS

Permitting the tripping lever 21 to return to its original position entails the following operations:

The locking lever 11 and the B lever 10 are simultaneously moved by the raised lug of the tripping lever 21. While the locking lever, which is a little shorter than the B lever 10, moves right in front of the abutment of the driving lever 31, the B lever is displaced toward the rim of the shutter, so that the driving lever 31 rests only against the locking lever 11.

The tripping lever 21 is caught by the integral locking abutment of the locking lever 11, so that the cycle of the shutter is interrupted and the shutter blades stay open. A repeated actuation of the tripping lever 21 in the cocking direction causes the locking lever 11 to be likewise displaced toward the rim of the shutter, the driving lever 31 becomes disengaged, the shutter completes its cycle and the shutter blades 43 close.

3. Dismantling and Re-assembling the Shutter

a) Dismantling the Shutter

After removing the four bottom screws 49, the bottom 50 together with the diaphragm system can be lifted off (for details please see diaphragm system - sheet 11).

The shutter blades 43 can be lifted off immediately. The star-shaped locking lever 106 has to be seized by use of a pair of pincers and moved a little bit toward the rim of the shutter thus making the shutter blade ring 41 accessible and it can then be lifted off. The drive ring 40 must first be lifted slightly at the slow speed assembly 8 and then pulled out from underneath the ring lever 24.

The removal of the other parts is relatively easy and only in such cases where it is deemed necessary are details given in the descriptions of the individual systems.



INSTRUCTIONS FOR REPAIR SHOPS

PHOTOGRAPHIC SHUTTERS

Note

Should it be necessary to remove the front plate 2, the setting ring 3, or the detent notch spring 4, the front plate ring 1 must first be removed by means of the front plate ring wrench MV 100.

b) Re-assembling the Shutter

In general, attention must be given that in re-assembling the shutter no levers will be bent and no springs stretched, as otherwise there will be no assurance of a proper shutter function.

Further details will be given in the descriptions of the individual systems.

4. Cocking and Tripping System

The mode of operation of the cocking and tripping system has already been described in section 2. The following paragraph contains instructions on how to replace parts, on the assembly and on the correction of defects.

a) Replacing Tripping Lever and Driving Latch

The B and locking lever spring 20 is unhooked from the B lever by use of a pair of pincers. Similarly the driving spring is unhooked from the driving lever 31. Then after loosening the locking lever screw 9, the locking lever 11 and the B lever 10 and after removing the driving lever screw 29, the driving lever 31 is removed from the shutter. When removing the bearing bridge screw 17, the driving latch spring 22 must be held in position by use of a pair of pincers to avoid flipping off of the spring. After removing the bearing bridge 18, the tripping lever 21 and the driving latch 102 become accessible and can be removed from the shutter after the tripping spring has previously been unhooked.



INSTRUCTIONS FOR REPAIR SHOPS

PHOTOGRAPHIC SHUTTERS

- b) In assembling the shutter the repairman must first see to it that the cable release socket pin 15 is in the cable release socket 14. Then the tripping lever 21 together with the hooked-up tripping spring 21a is fitted into the shutter. The spacing bushing 19 and then the bearing bridge 18 are placed in position and screwed on by means of the bearing bridge screw 16.

The cocking latch spring 22 has to be placed over the spacing bushing 19 and to be held by use of a pair of pincers in such a manner that both arms of the spring are held in position. Slide the spacing bushing 19 and the driving latch spring 22 under the bearing bridge 18 and fit in and tighten the bearing bridge screw 17. The long arm of the spring must be placed against the rivet underneath the driving latch spring 102. To fit in the driving lever 31, the ring lever 24 and the tripping prevention lever 27 have to be turned toward the right (clockwise) and placed against the wall of the housing.

Tighten the B and locking levers 10 and 11. Remove the B and locking lever spring 20 from the bearing bridge, place one spring arm into the hole drilled for the spring in the locking lever 11, push it back onto the bearing rivet and place the other spring arm against the lug of the B lever 10.

Note

During the initial period of the manufacture the shutters were only fitted with the driving latch spring 22 (part no. IJRX5-93). When the driving latch spring 22 was modified and fitted into the shutter by means of a spacing bushing 19, the shutter was also fitted with the tripping spring 21a. The cycle of operations of the shutters that are only fitted with the driving latch spring 22, is the same as previously described in section b and only the assembly is slightly different.



INSTRUCTIONS FOR REPAIR SHOPS

PHOTOGRAPHIC SHUTTERS

<u>Defect</u>	<u>Cause of the Defect</u>	<u>Correction</u>
1. Shutter does not cock.	1. Driving latch spring 22 does not rest against the spring rivet.	1. Seize the cocking latch spring 22 and place it against the spring rivet of the driving latch 102.
1b Shutter does not cock.	1b Tripping prevention lever 27 does not rest against the ring lever 24, so that the cocking latch 102 is blocked.	1b Rotate the tripping prevention lever 27 clockwise to such an extent that during the return travel it is stopped by the ring lever 24.
2. Tripping lever 21 does not or only very reluctantly return to its starting position.	2. Tripping lever spring 21a is not hooked up or may be stretched.	2. Hook up or replace tripping lever spring 21a.
3. Shutter cocks but does not trip.	3a Driving latch spring is not placed in position.	3a Insert the driving latch spring 28 into the drilled hole of the driving latch and place the other spring arm against the rivet for the driving spring 32.
	3b The ring lever 24 is not in the recessed portion of the drive ring 40.	3b Properly fit in the drive ring 40 (see shutter blade system).



INSTRUCTIONS FOR REPAIR SHOPS

PHOTOGRAPHIC SHUTTERS

<u>Defect</u>	<u>Cause of the Defect</u>	<u>Correction</u>
4. When set for slower instantaneous speeds the shutter completes its cycle, i. e. although the shutter has been set for a speed of 1 sec. the shutter blades close immediately.	4. The driving spring 32 is not properly hooked up.	4. Hook up the driving spring 32.

5. Slow Speed Assembly and Speed Setting System

By rotating the setting ring 3 both the engagement of the brake lever 36 and the engagement and disengagement of the escapement are controlled. Whereas the shutter speeds from 1/60 to 1/15 sec. are attained exclusively by action of the gear train, for the speeds from 1/8 to 1 full second the escapement is brought into engagement.

The top speed of 1/125 sec. is attained without engagement of either the escapement or the gear train.

The integral speed control cam of the speed setting ring 3 governs the starting position of the brake lever 36 controlling the exposure time. Before the slow speed assembly 8 can be removed from the shutter, the brake lever 36 must be removed from the shutter, so that after the two fixing screws of the slow speed assembly 6 and 7 have been unscrewed, the slow speed assembly can be lifted off.

For fitting the slow speed assembly 8 into the shutter, the setting ring has to be rotated to the 1 sec. position. Then the slow speed assembly 8 can be fitted and screwed on.



INSTRUCTIONS FOR REPAIR SHOPS

PHOTOGRAPHIC SHUTTERS

The brake lever 36 must be placed on the bearing pin of the gear segment. The washer must be placed on the threaded hole and the brake lever 36 goes on top of it and is screwed into position. Place the brake lever spring 101 into the groove of the brake lever screw 35 and against the rivet of the gear segment.

<u>Defect</u>	<u>Cause of the Defect</u>	<u>Correction</u>
1. When set for slower instantaneous speeds the shutter completes its cycle instantly. Please also see defect 4 in the cocking and tripping system.	1. Brake lever spring 101 does not rest in position, so that the brake lever 36 cannot stop the braking latch 104.	1. Place brake lever spring 101 against the gear segment and against the brake lever screw as described in paragraph 5.
2. Shutter speeds are slower than provided for by the program.	2. Brake lever 36 does not move easily; washer 37 has been omitted.	2. Remove the brake lever 36 and re-install it together with washer 37.

Hint for Making Adjustments

The shutter speeds can be adjusted by filing or swaging the integral speed control cam of the setting ring. The shutter speeds can only be accurately tested by use of a shutter speed tester.



INSTRUCTIONS FOR REPAIR SHOPS

PHOTOGRAPHIC SHUTTERS

6. Shutter Blade SystemAssembly

Place the driving ring 40 with the recessed portion under the ring lever 24 in such a manner that the rivet will fit into the recess. It must be noted that the contact lug 107 is located before the contact spring 100 and that the pin of the escapement lever comes to rest against the abutment 106. Seize the star-shaped locking lever 106 by use of a pair of pincers as described in section 3a, move it toward the rim of the shutter and fit in the shutter blade ring 41 in such a manner that the locking lever screw 9 will be accepted by the small rectangular hole.

For assembling the shutter blades 43, rotate the setting ring to "T" and trip the shutter once. Starting from the cable release socket 14, the shutter blades must be assembled clockwise, with the last shutter blade coming to rest on top of the first one. Then the bottom with the diaphragm system must be placed on and screwed in position.

Note

Shutter blades and diaphragm blades must be handled with particular care and protected against fingerprints. As a rule diaphragm blades and shutter blades that are not in perfect condition should be replaced. Diaphragm blades and shutter blades should never be oiled or greased.

7. Diaphragm System

After removing the diaphragm covering disc 45 mounted to the bottom 40 of the shutter by means of three screws, the diaphragm blades become accessible.



INSTRUCTIONS FOR REPAIR SHOPS

PHOTOGRAPHIC SHUTTERS

Assembly

Place the diaphragm covering disc 45 in front of you as illustrated in the spare parts list and assemble the diaphragm blades clockwise so that the rivets project into the drilled holes. Open or close the diaphragm blades in such a manner that they form a circle of the same diameter as the opening. Fit the diaphragm pointer disc 48 into the bottom 50 of the shutter and rotate it so that the pointer as seen from the nozzle will come to a stop in a clockwise direction. Adjust the diaphragm covering disc 47 and the bottom 50 according to the threaded holes and place the bottom together with the diaphragm pointer disc on top of the diaphragm covering disc with the diaphragm blades.

A slight rotation of the diaphragm covering disc 48 causes the rivets to project into the slots of the diaphragm pointer disc and that the diaphragm covering disc can be screwed to the bottom.

<u>Defect</u>	<u>Cause of the Defect</u>	<u>Correction</u>
1. Diaphragm pointer disc 48 does not move easily.	1a. The diaphragm pointer disc or the diaphragm covering disc is bent out of position.	1a. Fit in new discs.
	1b. Diaphragm blades are damaged.	1b. Replace diaphragm blades.

8. Flash Contact System

When the shutter completes its cycle, the contact 107 of the drive ring 40 presses the flash contact spring 100 against the strobe connector riveted into the wall of the shutter housing and thus forms a live connection.



INSTRUCTIONS FOR REPAIR SHOPS

PHOTOGRAPHIC SHUTTERS

<u>Defect</u>	<u>Cause of the Defect</u>	<u>Correction</u>
1. With the flash equipment in proper working condition, it does not fire.	1a. The contact is not closed, because the contact lug 102 of the driving ring is bent out of position.	1a. Adjust the contact lug 107 or replace the drive ring 40.
	1b. Drive ring 40 is not properly installed; contact lug 107 is located between flash contact spring 100 and contact pin.	1b. Fit in the driving ring 40 in such a manner that when the driving ring is rotated the contact lug 107 presses the flash contact spring 100 against the strobe connector.
	1c. Flash contact spring 100 is bent out of position.	1c. Adjust the flash contact spring 100.
2. Contact does take place at the moment when the shutter blades reach the proper position.	2. Contact lug 107 is bent out of position.	2. see 1a.



INSTRUCTIONS FOR REPAIR SHOPS

PHOTOGRAPHIC SHUTTERS

PRONTOR-PRESS I-12
LUBRICATION DIAGRAM

Item No.	Designation	Lubricant	Lubrication Aids	Remarks - Lubrication Points
3	Setting ring	Losoid 70		Inside diameter, control slots and bearing surfaces on both sides
5	Housing	BR 2	MV 160/2	Tripping lever 21, bearing bushing
		Molykote paste G rapid		Drive ring seat
10	B lever	BR 2	Brush	Bearing hole, supporting surface and stop abutment for the drive lever 31
11	Locking lever	BR 2	Brush	
14	Cable release socket	Losoid 70	MV 161/3	Drilled hole
15	Cable release socket pin	G rapid		Drive surface
24	Ring lever	G rapid		Bearing hole
26	Spring of the tripping prevention lever	Losoid 70	Grease pad	
28	Driving latch spring	Losoid 70	Grease pad	
31	Driving lever	BR 2	Brush	Bearing hole and driving edge
36	Brake lever	BR 2	MV 161/4 Brush	Drilled hole Stopping abutment
40	Drive ring	G rapid		Recess for ring lever rivet
		BR 2	Brush	Disconnecting lug 106
102	Cocking latch	Alpha		Point of impact of the tripping pin
		BR 2	Brush	Driving edge
103	Driving latch	G rapid	Brush	Recess accepting the rivet of the ring lever



INSTRUCTIONS FOR REPAIR SHOPS

PHOTOGRAPHIC SHUTTERS

BR 2 and G rapid are Molykote pastes.

Grease pad - a piece of felt impregnated with a lubricant.

To introduce the lubricants into the drilled holes please use either the lubricating awls (MV 161/...) referred to or metal sticks of the respective diameter.

Please note the instructions under 1b.

Ersatzteilliste
PRONTOR - PRESS I - 12

Liste best. aus Blatt 1-7

Anz. der Änd. Bl. 8 -

Gefertigt 26. 2. 65 *fe*


Blatt Nr.





Geprüft


1







Kamera :

Optik / Lens :










49



49

I - 12 / 4

Ersatzteilliste			Gefertigt 26. 2.65 <i>fe.</i>
PRONTOR - PRESS I - 12			Geprüft
			Blatt Nr. 5
Pos.	Teil - Nr.	Stück	Benennung
1	IJR5p - 239.1	1	<u>Frontplattenring</u> front plate ring
2	I - 12 - 143	1	<u>Frontplatte</u> front plate
3	I - 12 - 137	1	<u>Einstellring</u> speed setting ring
4	0376y - 362	1	<u>Rastenfeder</u> notch spring
5	I - 12 - U 1	1	<u>Kapsel</u> <u>wird nicht abgegeben</u> housing cannot be supplied
6	7 000 884	1	<u>Hemmwerkschraube</u> screw for slow speed assembly
7	7 002 002	1	<u>Hemmwerkschraube</u> screw for slow speed assembly
8	I - 12 - G 20	1	<u>Hemmwerk</u> <u>wird nur als Ganzes abgegeben</u> slow speed assembly only complete unit can be supplied
9	7 000 616	1	<u>Sperrhebelschraube</u> locking lever screw
10	I - 12 - 119	1	<u>Zeithebel</u> B - lever
11	I - 12 - U122	1	<u>Sperrhebel</u> locking lever
12	IJR5p - 73	1	<u>Gewindestift</u> threaded pin
13	7 002 026	1	<u>Auslösrohrschraube</u> cable release socket screw
14	I - 12 - 123.1	1	<u>Auslösrohr</u> cable release socket
15	I - 12 - U124	1	<u>Auslösstift</u> cable release socket pin
16	7 002 992	1	<u>Lagerbrückenschraube</u> bearing bridge screw
17	7 001 445	1	<u>Lagerbrückenschraube</u> bearing bridge screw
18	I - 12 - U361	1	<u>Lagerbrücke</u> bearing bridge
19	I - 13 - 464	2	<u>Distanzbüchse</u> distance bushing
ALFRED GAUTHIER G.m.b.H. Calmbach / Enz			

Pos.	Teil - Nr.	Stück	Benennung
20	I - 12 - 121,1	1	<u>Teil und Sperrhebelfeder</u> U end locking lever spring
21	I - 12 - U 85	1	<u>Auslöser</u> release
22	I - 12 - 682	1	<u>Spannklintenfeder</u> cocking latch spring
23	7 002 294	1	<u>Ringhebelschraube</u> ring lever screw
24	I - 12 - U 67	1	<u>Ringhebel</u> ring lever
25	7 000 604	1	<u>Auslösesperrhebelschraube</u> release stop lever screw
26	I - 12 - 159	1	<u>Auslösesperrhebelfeder</u> release stop lever screw
27	I - 12 - 156	1	<u>Auslösesperrhebel</u> release stop lever
28	IJRX5 - 70	1	<u>Treibklintenfeder</u> driving latch spring
29	QJRX10 - 102,1	1	<u>Treibhebelschraube</u> drive lever screw
30	JRI - 64	1	<u>Bremsklintenfeder</u> brake latch spring
31	I - 12 - U 96	1	<u>Treibhebel</u> drive lever
32	I - 12 - 132	1	<u>Treibfeder</u> drive spring
33	7 001 415	1	<u>Regulierhebelschraube</u> adjusting lever spring
34	IJRX5 - U 45	1	<u>Regulierhebel</u> adjusting lever
35	3114 - 25 - 3220	1	<u>Bremshebelschraube</u> brake lever screw
36	IJRX5 - U 34,1	1	<u>Bremshebel</u> brake lever
37	QJRX5 - 78	1	<u>Unterlegscheibe für Bremshebel</u> washer for brake lever
38	7 000 073	2	<u>Einstellbogenschraube</u> scale band screw

Ersatzteilliste				Gefertigt	26. 2. 65	fe
PRONTOR - PRESS				I - 12	Geprüft	Blatt Nr. 7
Pos.	Teil - Nr.	Stück	Benennung			
39	I - 12 - 134	1	<u>Einstellbogen</u> scale band			
40	I - 12 - U 80	1	<u>Antriebring</u> drive ring			
41	I - 12 - U685,1	1	<u>Sektorenring</u> shutter blade ring			
42	I - 12 - 971	1	<u>Sternsperrhebelfeder</u> drive ring lock spring			
43	IJR5 - 61	6	<u>Sektor</u> shutter blade			
44	7 002 002	3	<u>Irisdeckscheibenschraube</u> diaphragm covering disc screw			
45	IJR5 - 8,2	1	<u>Irisdeckscheibe</u> diaphragm covering disc			
46	IJR5p - 591	1	<u>Federring</u> spring ring			
47	I - 12 - U 5	10	<u>Irislamelle</u> diaphragm blade			
48	I - 12 - 7	1	<u>Iriszeigerscheibe</u> diaphragm pointer disc			
49	7 001 443	4	<u>Bodenschraube</u> bottom screw			
50	I - 12 - 2	1	<u>Boden</u> bottom	<u>wird nicht abgegeben</u> cannot be supplied		
51	JRI - 71	1	<u>Anschraubring</u> flange			
			<u>Die Positionszahlen über 100 beziehen sich auf den Text der Reparatur - Hinweise</u> The index numbers above 100 refer to the text of the "Instructions for Repair Shops"			
ALFRED GAUTHIER G.m.b.H. Calmbach / Enz						

PRONTOR - PRESS I - 12

Geprüft

Blatt Nr.
8

21a




22

Geprüft


Blatt Nr.
9

ALFRED GAUTHIER G.m.b.H Calmbach/Enz






2




3



14



40




39

44a






43

44



45

44



Ersatzteilliste				Gefertigt 26. 2. 65 <i>fk</i>	
PRONTOR - PRESS I - 12 p				Geprüft	Blatt Nr. 4
Pos.	Teil - Nr.	Stück	Benennung		
2	I - 12p - 143	1	<u>Frontplatte</u> front plate	an Stelle von I - 12 - 143 inst. of I - 12 - 143	
3	I - 12p - 137	1	<u>Einstellring</u> speed setting ring	an Stelle von I - 12 - 137 inst. of I - 12 - 137	
5	I - 12p - U 1	1	<u>Kapsel</u> ohne Bild housing without illustration	<u>wird nicht abgegeben</u> cannot be supplied	an Stelle von I - 12 - U1 inst. of I - 12 - U1
14	I - 12p - 123	1	<u>Auslöserohr</u> cable release socket	an Stelle von I - 12- 123.1 inst. of I - 12 - 123.1	
39	I - 12p - 134	1	<u>Einstellbogen</u> scale band	an Stelle von I - 12 - 134 inst. of I - 12 - 134	
40	I - 12p - U 80	1	<u>Antriebring</u> drive ring	an Stelle von I - 12 - U 80 inst. of I - 12 - U 80	
43	IJR5p - 61	6	<u>Sektor</u> shutter blade	an Stelle von IJR5 - 61 inst. of IJR5 - 61	
44	7 002 002	2	<u>Irisdeckscheibenschraube</u> diaphragm covering disc screw	an Stelle von 7 002 002 3 Stück inst. of 7 002 002 3 pcs.	
44a	7 002 561	1	<u>Irisdeckscheibenschraube</u> diaphragm covering disc screw		
45	I - 12p - 10	1	<u>Irisdeckscheibe</u> diaphragm covering disc	an Stelle von IJR5 - 8.2 inst. of IJR5 - 8.2	
47	476 - U 5	5	<u>Irislamelle</u> diaphragm blade	an Stelle von I - 12 - U 5 10 Stück inst. of I - 12 - U 5 10 pcs.	
48	I - 12p - U 7	1	<u>Iriszeigerscheibe</u> diaphragm pointer disc	an Stelle von I - 12 - 7 inst. of I - 12 - 7	
49a	7 002 953	1	<u>Fixierschraube</u> locating screw		
50	I - 12p - 2	1	<u>Boden</u> ohne Bild bottom without illustration	<u>wird nicht abgegeben</u> cannot be supplied	an Stelle von I - 12 - 2 inst. of I - 12 - 2
50a	I - 12p - 7a	1	<u>Blendenring</u> diaphragm ring		
51	I - 12p - 141	1	<u>Anschraubring</u> flange	an Stelle von JRI - 71 inst. of JRI - 71	
			Die übrigen Teile nach Grundmodell I - 12 The remaining parts as per basic model I - 12		
ALFRED GAUTHIER G.m.b.H. Calmbach / Enz					

Ersatzteilliste
PRONTOR-PRESS I-12p1 Fa. Polaroid, USA
Kamera : Optik/Lens: Ysarex 1:4,7 / 127

Liste best. aus Blatt 1 - 4


Anz. der Änd. Bl.



Gefertigt 26. 2. 65

Geprüft


Blatt Nr.

1





14



40




39

44a




43

44





45

44



49 a



Ersatzteilliste				Gefertigt	26. 2.65		
PRONTOR - PRESS I-12 p1				Geprüft	Blatt Nr. 4		
Pos.	Teil - Nr.	Stück	Benennung				
2	I - 12p - 143	1	<u>Frontplatte</u> front plate		an Stelle von I - 12 - 143 inst. of I - 12 - 143		
3	I - 12p - 137	1	<u>Einstellring</u> speed setting ring		an Stelle von I - 12 - 137 inst. of I - 12 - 137		
5	I - 12p - U 1	1	<u>Kapsel</u> housing	<u>ohne Bild</u> without illustration	<u>wird nicht abgegeben</u> cannot be supplied	an Stelle von I - 12 - U1 inst. of I - 12 - U1	
14	I - 12p - 123	1	<u>Auslösröhr</u> cable release socket		an Stelle von I - 12 - 123.1 inst. of I - 12 - 123.1		
39	I - 12p1 - 134	1	<u>Einstellbogen</u> scale band		an Stelle von I - 12 - 134 inst. of I - 12 - 134		
40	I - 12p - U 80	1	<u>Antriebring</u> drive ring		an Stelle von I - 12 - U 80 inst. of I - 12 - U 80		
43	I - 12p - 116	6	<u>Sektor</u> shutter blade		an Stelle von IJRX5 - 61 inst. of IJRX5 - 61		
44	7 002 002	2	<u>Irisdeckscheibenschraube</u> diaphragm covering disc screw		an Stelle von 7 002 002 3 Stück inst. of 7 002 002 3 pcs.		
44a	7 002 561	1	<u>Irisdeckscheibenschraube</u> diaphragm covering disc screw				
45	IJRX5p2 - 8	1	<u>Irisdeckscheibe</u> diaphragm covering disc		an Stelle von IJRX5 - 8.2 inst. of IJRX5 - 8.2		
46	I - 12p1 - U 7	1	<u>Iriszeigerscheibe</u> diaphragm pointer disc		an Stelle von I - 12 - 7 inst. of I - 12 - 7		
49a	7 002 953	1	<u>Fixierschraube</u> locating screw				
50	I - 12p1 - 2	1	<u>Boden</u> bottom	<u>ohne Bild</u> without illustration	<u>wird nicht abgegeben</u> cannot be supplied	an Stelle von I - 12 - 2 inst. of I - 12 - 2	
50a	I - 12p1 - 7a	1	<u>Blendenring</u> diaphragm ring				
51	I - 12p - 141	1	<u>Anschraubring</u> flange		an Stelle von JRI - 71 inst. of JRI - 71		
			<u>Die übrigen Teile nach Grundmodell I - 12</u> The remaining parts as per basic model I - 12				
ALFRED GAUTHIER G.m.b.H. Calmbach / Enz							

Instructions for the Repair of
the PRONTOR IJRX5p Shutter

- - - - -

<u>Table of Contents</u>	Sheet
1. <u>Introductory Remarks</u>	1
2. <u>Mode of Operation</u>	3
a) when set for instantaneous speeds from $\frac{1}{125}$ sec to 1 sec	
b) when set for "B" (time exposures)	
3. <u>Dismantling and Reassembling the Shutter</u>	4
4. <u>Cocking and Tripping System</u>	5
5. <u>Slow Speed Assembly and Speed Setting System</u>	8
6. <u>Shutter Blade System</u>	10
7. <u>Diaphragm System</u>	13
8. <u>Flash Contact System</u>	14
9. <u>Illustrations</u>	15
10. <u>Lubricating Diagram</u>	16

Appendix:

Spare Parts List

Repair Instructions for GAUTHIER Shutters
Model PRONTOR IJRX5p

1. General Introductory Remarks

These repair instructions have been written in order to enable repairmen to furnish a quick, efficient and reliable repair service without any major difficulties.

They start with a description of the mode of operation of the shutter, and it is recommended to read this paragraph very carefully, for the knowledge of the functions of the individual components is the basis for understanding the concerted operation of all components in the Gauthier P R O N T O R precision shutter.

a) Tools for Repair Work

Apart from the front plate wrench MV 100, and the lever bending tool A2 there are no other special tools required for dismantling and repairing the shutter.

However, in selecting the screwdrivers it is very important to use a screwdriver of the proper size for the various screws. If screwdrivers of a non-fitting size are used, the repairman will run the risk of damaging the screw slots. As a result it will be impossible to loosen the screws.

b) Lubricants

The manufacturer lubricates the shutter at all points requiring lubrication by means of lubricating pastes

that can be regarded as life-time lubricants. In repair work additional lubrication is required only in such cases where parts are washed or replaced by new ones. The attached lubricating diagram indicates the points of the shutter parts that require lubrication, and the type of lubricant to be used.

Note

Only those lubricants indicated in the lubricating diagram should be used for lubricating the shutter. By using a different type of lubricant the repairman will run the risk that the viscosity will not meet the specific requirements, which means that the shutter blades might be glued together by the lubricant, or the gears may become gluey resulting in each case in incorrect shutter speeds. Attention must also be given that there will not be an excessive amount of lubricant at the edges, recesses and drilled holes. If necessary the lubricant must be wiped off carefully.

c) Spare Parts

If in repairing a shutter it is necessary to replace individual components, only

FACTORY-MADE SPARE PARTS

should be used. The parts can be ordered by use of the attached spare parts list. However, it is necessary to state the exact designation and the part number shown in the list. This is the only possible way for us to supply the correct spare parts.

2. Mode of Operation

a) Instantaneous Speeds

Shutter speed and aperture are set to the desired values. A pressure on the cable release plunger advances the cable release socket pin 6, the cocking lever 7, and the cocking latch 9 which is connected with the latter. An integral cam 9a of the cocking latch 9 comes to rest against the angular stop plate 35, and when actuated moves the driving lever 13 radially towards the outside. In doing so the cam strikes the stop lug of the driving lever 13. The driving latch 14 riveted to the driving lever 13 is pressed by the closing spring 17 against the ring lever 16, and a recessed portion engages the driving lug; at the same time the brake latch 24, also riveted to the driving lever, slips past the driving lug of the brake lever 25. At the end of the cocking travel the cocking latch 9 disengages the driving lever 13, and pulled by the driving spring 21 the driving lever returns to its original position.

In returning, the brake latch 24 strikes the lug of the brake lever 25, and depending upon the setting has to overcome the braking action of the slow-speed gear train (see Speed Setting System page 7).

During the return travel of the driving lever 13, the driving latch 14 displaces the ring lever 16 and the driving ring 36 in positive engagement with the latter. The shutter blades open.

Just prior to reaching the resting position the brake lever 25 becomes disengaged, both brake latch 24 and driving lever 13 flip back, and the driving latch 14 returns the ring lever 16 and the driving ring 36 positively connected with the latter to their original positions.

b) Time Exposures

Independent of the selected shutter speed the shutter blades can be opened for any period of time, if the cable release is screwed into the cable release socket 1a.

A pressure on the cable release plunger causes the cable release socket pin 6a to strike the driving lug 37a of the shutter blade ring 37 and to displace the latter. The shutter blades open. If the cable release socket pin is allowed to return, the shutter blade ring 37 actuated by the shutter blade ring spring will follow immediately, and the shutter blades will close.

3. Dismantling and Reassembling

A. Dismantling the Shutter

After removing the four mounting screws of the shutter base the latter can be lifted off together with the diaphragm system. (For further details on the diaphragm system please see sheet 11).

The shutter mechanism is now accessible. The shutter blades can be lifted off directly, the shutter blade ring spring 10 can be unhooked, and the shutter blade ring 37 and the drive ring 36 can be removed. The remaining shutter dismantling operations are relatively easy, and will be described in some cases in the descriptions of the individual systems.

Note:

Should it become necessary to replace the front plate, the setting ring or the notched speed lever, the front plate ring must be removed. The stock number of the front plate ring wrench is MV 100.

B. Reassembling the Shutter

Important Note

As a general rule attention must be given to the fact that in reassembling the shutter no lever will be bent and no spring stretched, as otherwise the shutter will not function properly. Special attention must be given to the position of the cable release socket pin 6a, as this part will become loose when the shutter blade ring 37 is removed, and may slip out of the drilled hole of the cable release socket 10. Moreover, the driving spring 21 should not be hooked up on the second rivet of the adjusting lever 23 as shown in the illustration, but rather on the first rivet as viewed from the adjusting lever screw 22. Additional detailed assembly instructions will be given in the descriptions of the individual systems.

4. Cocking and Tripping System

The mode of operation of the cocking and tripping system has already been described in paragraph 2a. The following paragraphs contain instructions on the replacement of parts, on the assembly, and on the correction of defects.

a) Replacing

the cocking lever 7, the cocking latch 9, the angular stop plate 35, and the cocking lever spring 3.

By removing the two bearing bridge screws 5 and 11, the cocking lever 7 and the cocking latch 9, and after removing the screw 34, the angular stop plate 35 will become loose.

- b) In assembling the shutter the angular stop plate 35 is first secured by means of the screw 34, then the cocking lever 7 and the cocking latch 9 are fitted with the cocking lever spring hooked up on the cocking lever 7. Place the two spacing bushings over the

threaded holes, pretension the cocking latch spring 12, and stick it over the spacing bushing. Hold down the cocking latch spring 12 and the spacing bushing by means of one finger, fit the bearing bridge 8, and secure it in position by means of the two screws 5 + 11. Then the cocking latch spring 12 is placed underneath the cocking latch 9 where it must rest against the spring rivet.

<u>Defect</u>	<u>Cause</u>	<u>Correction</u>
1. Shutter does not cock, release has no resistance at all, or very little.	a) Cocking lever spring 3 is unhooked. b) Cocking lever spring 3 is extended. c) Cocking-latch spring 12 does not rest against the spring rivet of the cocking latch 9, but against the nozzle of the housing.	a) Hook up the cocking lever spring 3. b) Install new cocking lever spring (for this purpose the cocking lever 7 must be removed). c) Pull the cocking latch spring 12 along the base of the housing and hold it by means of a pair of tweezers (at the ring lever 16). Make the cocking latch 9 rest against the nozzle, but make sure that the spring rivet will slip over the spring 12. Lift the spring lightly and let it strike against the rivet.

<u>Defect</u>	<u>Cause</u>	<u>Correction</u>
2.		
Shutter cocks but does not trip.	a) Closing spring 17 is unhooked from the driving latch 14.	a) Hook the closing spring 17 on the spring rivet of the driving latch 14.
	b) Ring lever 16 is not located in the recessed portion of the driving ring 36.	b) Install the driving ring 36 properly (see shutter blade system).
	c) The slide cam 9a is too steep, so that the driving latch cannot get caught in position.	c) Bend slide cam slightly by means of a pair of tongs.
3.		
The shutter set for slower instantaneous speeds produces faster speeds, i.e. (although set for 1 sec) the shutter blades close instantly after opening.	The driving latch spring 20 does not rest against the spring rivet.	Make driving latch spring 20 rest against the spring rivet.

5. Slow-Speed Assembly and Speed Setting System

Rotating the setting ring controls both the engagement of the brake lever 25, and the engagement and disengagement of the escapement. The escapement is engaged when the shutter is set for any of the following speeds: 1, $\frac{1}{2}$, $\frac{1}{4}$ and $\frac{1}{8}$ sec; it is disengaged when the shutter is set for any of the following speeds: $\frac{1}{15}$, $\frac{1}{30}$, $\frac{1}{60}$ and $\frac{1}{125}$ sec.

The control cam of the setting ring serves to set the angular position of the brake lever 25 that governs the shutter speeds.

Time Exposures "B" - See Shutter Blade System.

The two fixing screws 30 + 33 in the lower bearing plate secure the slow speed assembly 31 in the shutter. The slow-speed assembly can only be removed from the shutter after the brake lever 25 has previously been removed.

For assembling the slow-speed assembly the setting ring has to be rotated all the way to the right to the 1 sec position, then the slow-speed assembly can be installed and secured by screws. Press the tie lever 29 on the post of the gear segment, place the washer on the threaded hole, slide the brake lever over it, and secure it by means of the retaining screw 26. After the brake lever spring 27 is hooked up, the slow-speed assembly is ready to operate.

Note:

In fitting the setting ring give special attention that the escapement rocker arm and the control rivet of the gear segment that project through the base of the housing will come to rest in the recessed portions of the setting ring.

<u>Defect</u>	<u>Cause</u>	<u>Correction</u>
1. Shutter produces faster speeds than the slower speeds set. Please also see defect 3 and Cocking and Tripping System.	Brake lever 25 is not engaged; brake lever spring is unhooked.	Hook up brake lever spring 27.
2. Shutter speeds are slower than indicated in the program.	a) Brake lever 25 does not move easily, no washer has been fitted. b) Dirt inside the slow-speed assembly.	a) Remove the brake lever 25, and re-install it together with a washer. b) Replace the slow-speed assembly by a new one.

Note:

The shutter speeds can be adjusted in relation to each other by swadging or filing the control cam of the setting ring. The shutter speeds can only be accurately examined by means of a shutter speed measuring instrument.

6. Shutter Blade System

When the shutter completes its cycle the rivet 96 locks the shutter blade ring 37 against shifting, whereas the drive ring 36 is briefly advanced and returned by the ring lever 16. The rotation is limited by the recesses in the drive ring 36, and in the shutter blade ring 37, and by the stop screw 32.

a) Time Exposures "B"

When the shutter is tripped by use of the cable release socket 1a, the cable release socket pin 6a strikes the drive lug 37a of the shutter blade ring and displaces the latter. In doing so the shutter blades are opened, and when the pressure of the cable release crown is eased, the shutter blade ring spring 10 returns the shutter blade ring 37 to its starting position, - the shutter blades close. As the locking abutment 37b of the shutter blade ring is rotated in front of the rivet 9b, the shutter is prevented from giving an instantaneous speed at the same time. On the other hand when the shutter is used for instantaneous speeds, the rivet 9b prevents simultaneous time exposures, because when the shutter completes its cycle this rivet slides in front of the locking abutment 37b.

- b) In fitting the drive ring 36 attention must be given to the fact that the ring lever 16 will slip into the recess provided for it, and that the contact arm 36a will not be pushed in between the flash contact spring 28 and the flash contact nipple (please also see flash contact system). After that, by use of a pair of tweezers the closing spring 17 is slipped through underneath the spring rivet of the drive ring 36 and is placed in position.

The shutter blade ring 37 must first be slipped under the head of the shutter blade ring screw 2, and can then be pushed on the nozzle of the housing. Use a pair of tweezers to hook the shutter blade ring spring 10 on the drive lug 37a. Then the shutter blades are fitted in such a way that the rivets of the driving ring 36, and of the shutter blade ring 37 will slip into the drilled holes of the shutter blades. Mount the shutter base with the diaphragm system in such a way that the shutter blade ring screw 2 will fit into the recesses in the base, and secure it by means of 4 screws.

<u>Defect</u>	<u>Cause</u>	<u>Correction</u>
1.		
Shutter blades do not form a light-tight closure of the shutter opening.	a) In assembling a new drive ring 36, or a shutter blade ring 37 it is noted that the recesses for the stop screw 32 are too large.	a) Reduce the recesses 36c and 37c by swadging.
	b) Shutter blades are bent.	b) Replace shutter blades.
2.		
Shutter blades rusty.		Replace shutter blades.

Note:

The shutter blades and diaphragm blades must be handled with particular care. Bent parts must be replaced by new ones. The shutter blades and diaphragm blades must be protected against fingerprints which are apt to lead to the formation of rust. As a general rule parts that are not in perfect condition must be replaced, and only in cases where no replacements are available the fingerprints should be removed with a clean cloth. Make sure to place the shutter blades and diaphragm blades on a flat surface for cleaning.

Diaphragm blades and shutter blades should never be lubricated.

7. Diaphragm System

After lifting off the diaphragm covering disc secured by means of three screws, the diaphragm blades are freely accessible.

Assembly

Insert the pointer arm of the diaphragm pointer disc into the slot of the base, place it into the annular recess, and rotate it counter-clockwise right to the stop. Fit the diaphragm blades in such a way that the rivets will come to rest in the drilled holes provided in the diaphragm pointer disc. Fit the spring ring centrically, and place on the diaphragm covering disc, but make sure that the diaphragm blade rivets come to rest in the drilled holes; this can easily be attained by a very slight forward and backward rotation of the diaphragm pointer disc. The three mounting screws secure the diaphragm system in the shutter base.

<u>Defect</u>	<u>Cause</u>	<u>Correction</u>
The diaphragm pointer disc does not move easily.	a) The diaphragm pointer disc or the diaphragm covering disc are bent.	a) Install new flat discs.
	b) The diaphragm blades are damaged.	b) Replace the diaphragm blades.




8. Flash Contact System

The shutter has X synchronization, which means that the contact is made when during the opening cycle of the shutter the shutter blades still project into the shutter opening for about 1.5 to 2 mm.








When the shutter completes its cycle, the contact arm 36a of the drive ring presses the flash contact spring 28 against the flash contact nipple and thus creates a conducting connection.

<u>Defect</u>	<u>Cause</u>	<u>Correction</u>
1.		
The flashgun does not fire despite the fact that it is in good working order.	a) There is no contact made due to the fact that the contact arm 36a is bent. b) The drive ring is not mounted properly; the contact arm 36a is located between the flash contact spring 28 and the contact pin. c) Flash contact spring 28 is bent.	a) Adjust the contact arm 36a, or replace the drive ring 36. b) Install the drive ring in such a way that the contact arm 36a when displaced pushes the flash contact spring 28 against the flash contact nipple. c) Adjust the flash contact spring 28.
2.		
The contact is not made at the correct position of the shutter blades.	Contact arm 36a is bent.	See 1a.

1JRX5p



Lubricating Diagram
for the
PRONTOR IJRX5p Shutter



A = Molykote paste micro fine
C = Molykote paste BR 2
F = Losoid 1164




The points to be lubricated are marked in red. The letters designate the type of lubricant to be used.

[illegible]

Anz. der Änd.-Bl.

[illegible]


Teil:



IJRX5-61

























0JRX5-78








IJRX5p-G10

wird nur als Ganzes abgegeben
only complete assembly can be supplied







Teil Nr.:	Teilbenennung:	Teil:
IJR5p - 136	Anschlagwinkelschr. angular stop plate screw	 <u>IJR5p-136</u>
IJR5p-72	Auslösrohr A cable release socket A	 <u>IJR5p-72</u>
IJR5p-72a	Auslösrohr B cable release socket B	 <u>IJR5p-72a</u>
JR0 - 73	Auslösrohrschr. cable release socket screw	 <u>JR0 - 73</u>
IJR5p-73a	Auslösrohrschr. cable release socket screw	 <u>IJR5p-73a</u>
IJR5p-74	Auslösstift A cable release socket pin	 <u>IJR5p-74</u>
IJR5p-74a	Auslösstift B cable release socket pin	 <u>IJR5p-74a</u>
IJR5p-94	Antriebring-Anschlagschr. drive ring stop screw	 <u>IJR5p-94</u>
3114-20-3220	Bremshebelschr. brake lever screw	 <u>3114-20-3220</u>
1217-32-2110	Bodenschr. 2 Stück bottom screw 2 pcs.	 <u>1217-32-2110</u>
OJR5-136	Distanzbüchse 2 Stück distance bushing 2 pcs.	 <u>OJR5-136</u>
1217-16-1433	Deckscheibenschr. 3 Stck cover disc screw 3 pcs.	 <u>1217-16-1433</u>
1217-12-1433	Einstellbogenschr. 2 Stck. scale band screw 2 pcs.	 <u>1217-12-1433</u>
1614-12-7110	Fixierschraube locating screw	 <u>1614-12-7110</u>
1014-20-2110 1517-20-1110	Herrnwerkschr. slow speed assembly scr.	 <u>1517-20-1110</u>
0304u-223	Lagerbrückenschr. lang bearing bridge scr. long	 <u>0304u-223</u>
1517-32-2116	Lagerbrückenschr. kurz bearing bridge scr. short	 <u>1517-32-2116</u>
IJR5-88	Ringhebelschr. ring lever screw	 <u>IJR5-88</u>
1217-22-2130	Regulierhebelschr. adjusting lever screw	 <u>1217-22-2130</u>
IJR5p-130	Sektorenringschr. shutter blade ring scr.	 <u>IJR5p-130</u>
OJR10-102	Treibhebelschr. drive lever screw	 <u>OJR10-102</u>
JR0-108	Zuziehfederschr. closing spring screw	 <u>JR0-108</u>

[illegible]

Lfd.Nr.	Teil Nr.:	Teilbenennung:	Teil:
1		<u>Änderung Nr. 2525</u> <u>Change Nr. 2525</u>	
2	IJR5p - 94.1	<u>Antriebring-Anschlagschr.</u> <u>an Stelle v. IJR5p-94</u> drive ring stop screw inst. of IJR5p - 94	 <u>IJR5p-94.1</u>
3		<u>Änderung Nr. 2566, 3301, 3410</u> <u>Change Nr. 2566, 3301, 3410</u>	
4	IJR5p - 73	<u>Gewindestift</u> 3 Stück <u>an Stelle v. IJR5p-73a</u> threaded pin 3 pcs. inst. of IJR5p - 73a	 <u>IJR5p-73</u>
5	1517-20-1110	<u>Bodenschr.</u> 2 Stück bottom screw 2 pcs.	 <u>1517-20-1110</u>
6		<u>Änderung Nr. 2860</u> <u>Change Nr. 2860</u>	
7	OJR10 - 102.1	<u>Treibhebelschr.</u> <u>an Stelle v. OJR10-102</u> drive lever screw inst. of OJR10-102	 <u>OJR10 - 102.1</u>
8		<u>Änderung Nr. 2929</u> <u>Change Nr. 2929</u>	
9	IJR5p-169	<u>Lichtdämpfring</u> <u>auf besondere Bestellung</u> light baffle ring upon special request	 <u>IJR5p-169</u>
10			




Änderungszustand dieses Blattes

Änd. Nr.	Lfd. Nr.	Tag u. Name	Änd. Nr.	Lfd. Nr.	Tag u. Name	Änd. Nr.	Lfd. Nr.	Tag u. Name
2525	2	20.3.62						
2566	4, 5	" " "						
2860	7	26.8.63						
2929	9	" " "						

Lfd.Nr.	Teil Nr.:	Teilbenennung:	Teil:
1		<u>Änderung Nr. 2950</u> <u>Change Nr. 2950</u>	
2	IJR5p-U31	<u>Antriebring</u> an Stelle v. IJR5-U31.1 drive ring inst. of IJR5-U31.1	
3	IJR5p-U128.1	<u>Sektorenring</u> an Stelle v. IJR5p-U128 shutter blade ring inst. of IJR5p-U128	
4	IJR5p-61	<u>Sektor</u> an Stelle v. IJR5-61 shutter blade inst. of IJR5-61	
5		<u>Änderung Nr. 3171</u> <u>Change Nr. 3171</u>	
6	IJR5p-94.2	<u>Antriebring-Anschlagschr.</u> wahlweise zu IJR5p-94.1 drive ring stop screw optionally to IJR5p-94.1	
7		<u>Änderung Nr. 3233</u> <u>Change Nr. 3233</u>	
8	1517-20-1110	<u>Deckscheibensch. 3 Stck.</u> an Stelle v. 1217-16-1433 cover disc screw 3 pcs inst. of 1217-16-1433	
9		<u>Änderung Nr. 3409a</u> <u>Change Nr. 3409a</u>	
10	JRI - 107.1	<u>Zuziehfeder</u> an Stelle v. JRI-107 closing spring inst. of JRI-107	







Änderungszustand dieses Blattes

Änd. Nr.	Lfd. Nr.	Tag u. Name	Änd. Nr.	Lfd. Nr.	Tag u. Name	Änd. Nr.	Lfd. Nr.	Tag u. Name
2950	2, 3, 4	27.8.63						
3171	6	" " "						
3233	8	" " "						
3409a	10	" " "						

Lfd.Nr.	Teil Nr.:	Teilbenennung:	Teil:
1		<u>Änderung Nr. 3463</u> Change Nr. 3463	
2	IJR5p - 3.1	<u>Boden</u> an Stelle v. IJR5p-3 bottom inst. of IJR5p-3	
3		<u>Änderung Nr. 3464</u> Change Nr. 3464	
4	IJR5p - 5.1	<u>Zeigerscheibe</u> an Stelle v. IJR5p-5 diaphragm pointer disc inst. of IJR5p-5	
5		<u>Änderung Nr. 3557</u> Change Nr. 3557	
6	IJR5p- 159.1	<u>Einstellring</u> an Stelle v. IJR5p-159 speed setting ring inst. of IJR5p-159	
7		<u>Änderung Nr. 3558</u> Change Nr. 3558	
8	IJR5p-U1.1	<u>Kapsel</u> ohne Skizze wird nicht abgegeben an Stelle v. IJR5p-U1 housing without sketch cannot be supplied inst. of IJR5p-U1	
9			
10			

Änderungszustand dieses Blattes

Änd. Nr.	Lfd. Nr.	Tag u. Name	Änd. Nr.	Lfd. Nr.	Tag u. Name	Änd. Nr.	Lfd. Nr.	Tag u. Name
3463	2	27.8.63						
3464	4	" " "						
3557	6	" " "						
3558	8	" " "						

Lfd.Nr.	Teil Nr.:	Teilbenennung:	Teil:
1		<u>Anderung Nr. 3625</u> <u>Change Nr. 3625</u>	
2	IJR5 - 70	<u>Treibklinkenfeder</u> an Stelle v. JRI-107.1 driving latch spring inst. of JRI-107.1	 <u>IJR5 - 70</u>
3	IJR5 - 107	<u>Antriebringfeder</u> an Stelle v. JRI-107.1 drive ring spring inst. of JRI-107.1	 <u>IJR5 - 107</u>
4		<u>Anderung Nr. 3635</u> <u>Change Nr. 3635</u>	
5	1-12p-123	<u>Auslösrohr „A“</u> an Stelle v. IJR5p-72 cable release socket „A“ inst. of IJR5p-72	 <u>1-12p-123</u>
6		<u>Anderung Nr. 3696</u> <u>Change Nr. 3696</u>	
7	122 02	<u>Antriebring-Anschlagschr.</u> an Stelle v. IJR5p-94.1 drive ring stop screw inst. of IJR5p-94.1	 <u>122 02</u>
8	122 03	<u>Antriebring-Anschlagschr.</u> an Stelle v. IJR5p-94.2 drive ring stop screw inst. of IJR5p-94.2	 <u>122 03</u> wahlweise optionally
9		<u>Anderung Nr. 3714</u> <u>Change Nr. 3714</u>	
10	0376y - 362	<u>Zeit - Rastenfeder</u> click stop spring	 <u>0376y-362</u>

Änderungszustand dieses Blattes

Änd. Nr.	Lfd. Nr.	Tag u. Name	Änd. Nr.	Lfd. Nr.	Tag u. Name	Änd. Nr.	Lfd. Nr.	Tag u. Name
3625	2,3	27.8.63						
3635	5	" " "						
3696	7,8	" " "						
3714	10	" " "						

Alfred Gauthier G. m. b. H.
Calmbach a. d. Enz

PRONTOR-PRESS IJRX5p

Geänderte
Teile
Changed parts







Liste besteht aus Blatt

Blatt Nr. 5

Gepr.







Gefertigt:

27. 8. 63

Lfd.Nr.	Teil Nr.:	Teilbenennung:	Teil:
1		<u>Änderung Nr. 3988</u> <u>Change Nr. 3988</u>	
2	I - 13 - 464	<u>Distanzbüchse 2 Stck.</u> <u>an Stelle v. IJRX5-136</u> distance bushing 2 pcs. inst. of IJRX5-136	 <u>I-13-464</u>
3	IJRX5 - U135.2	<u>Lagerbrücke</u> <u>an Stelle v. IJRX5-U135.1</u> bearing bridge inst. of IJRX5-U135.1	 <u>IJRX5-U135.2</u>
4	109 05	<u>Lagerbrückenschr. lang</u> <u>an Stelle v. 0304u-223</u> bearing bridge scr. long inst. of 0304u-223	
5	103 07	<u>Lagerbrückenschr. kurz</u> <u>an Stelle v. 1517-32-2116</u> bearing bridge scr. short inst. of 1517-32-2116	 <u>109 05</u>  <u>103 07</u>
6		<u>Änderung Nr. 3073</u> <u>Change Nr. 3073</u>	
7	IJRX5p - 8	<u>Jrisdeckscheibe</u> <u>an St. v. IJRX5p-8 auf Bl. Nr. 3</u> diaphragm covering disc inst. of IJRX5p-8 on sheet No. 3	 <u>IJRX5 - 8</u>
8		<u>Änderung Nr. 3559</u> <u>Change Nr. 3559</u>	
9	I-12 - U124	<u>Auslösstift</u> <u>an Stelle v. IJRX5p-74</u> cable release socket pin inst. of IJRX5p-74	 <u>I-12 - U124</u>
10			

Änderungszustand dieses Blattes

Änd. Nr.	Lfd. Nr.	Tag u. Name	Änd. Nr.	Lfd. Nr.	Tag u. Name	Änd. Nr.	Lfd. Nr.	Tag u. Name
3988	2, 3, 4, 5	27. 8. 63						
3073	7	" " "						
3559	9	16. 3. 65						

Lfd.Nr.	Teil Nr.:	Teilbenennung:	Teil:
1		<u>Änderung Nr. 4650</u> <u>Change Nr. 4650</u>	
2	IJRX5p-U128.3	<u>Sektorenring</u> <u>an Stelle v. IJRX5p-U128.1</u> shutter blade ring inst. of IJRX5p-U128.1	
3		<u>Änderung Nr. 4667</u> <u>Change Nr. 4667</u>	
4	7 002 026	<u>Auslösrohrschr.</u> <u>an Stelle v. JR0-73</u> cable release socket screw inst. of JR0-73	 <u>7 002 026</u>
5		<u>Änderung Nr. 4695</u> <u>Change Nr. 4695</u>	
6	I-10p-U80	<u>Antriebring</u> <u>an Stelle v. IJRX5p-U31</u> drive ring inst. of IJRX5p-U31	
7	IJRX5p-U1.2	<u>Kapsel ohne Skizze</u> <u>wird nicht abgegeben</u> <u>an Stelle v. IJRX5p-U1.1</u> housing without sketch cannot be supplied inst. of IJRX5p-U1.1	
8	I-10-U361	<u>Lagerbrücke</u> <u>an Stelle v. IJRX5-U135.2</u> bearing bridge inst. of IJRX5-U135.2	
9	I-10-U85	<u>Auslöser</u> <u>an Stelle v. IJRX5p-U47</u> release inst. of IJRX5p-U47	 <u>I-10-U361</u> <u>I-10-U85</u>
10	7 002 228	<u>Lagerbrückenschr.</u> <u>an Stelle v. 109 05</u> bearing bridge screw inst. of 109 05	 <u>7 002 228</u>

Fortsetzung zu Änd. Nr. 4695 auf Blatt Nr. 7
continuation of change No. 4695 on sheet No. 7

Änderungszustand dieses Blattes

Änd. Nr.	Lfd. Nr.	Tag u. Name	Änd. Nr.	Lfd. Nr.	Tag u. Name	Änd. Nr.	Lfd. Nr.	Tag u. Name
4650	2	18.3.65						
4667	4	" " "						
4695	6-10	" " "						

Alfred Gauthier G. m. b. H.
Calmbach a. d. Enz

PRONTOR-PRESS IJR5p

Geänderte
Teile
Changed parts






Liste besteht aus Blatt

Blatt Nr. 7

Gepr.

Gefertigt:





18. 3. 65

Lfd.Nr.	Teil Nr.:	Teilbenennung:	Teil:
1	I - 10 - 130	<u>Auslöserfeder</u> an Stelle v. IJR5 - 52 release spring inst. of IJR5 - 52	 <u>I-10-130</u>
2		<u>Änderung Nr. 4919</u> Change Nr. 4919	
3	IJR5p - 239.1	<u>Frontplattenring</u> an Stelle v. IJR5p-239 front plate ring inst. of IJR5p-239	 <u>IJR5p - 239.1</u>
4		<u>Änderung Nr. 4982</u> Change Nr. 4982	
5	IJR5 - U34.1	<u>Bremshebel</u> an Stelle v. IJR5-U34 brake lever inst. of IJR5-U34	 <u>IJR5-U34.1</u>
6		<u>Änderung Nr. 5080, 5198</u> Change Nr. 5080, 5198	
7	I - 12 - G20	<u>Hemmwerk</u> an Stelle v. IJR5p-G10 slow speed assembly inst. of IJR5p-G10	 <u>I-12 - G20</u>
8	7 000 884	<u>Hemmwerkschr.</u> an Stelle v. 1014-20-2110 slow speed assembly scr. inst. of 1014-20-2110	<u>wird nur als Ganzes abgegeben</u> only complete assembly can be supplied
9		<u>Änderung Nr. 5244</u> Change Nr. 5244	
10	I - 12 - U5	<u>Jrislamelle</u> an Stelle v. IJR5-U2 diaphragm blade inst. of IJR5-U2	 <u>I-12 - U5</u>

Änderungszustand dieses Blattes


Änd. Nr.	Lfd. Nr.	Tag u. Name	Änd. Nr.	Lfd. Nr.	Tag u. Name	Änd. Nr.	Lfd. Nr.	Tag u. Name
4695	1	18. 3. 65	5244	10	18. 3. 65			
4919	3	" " "						
4982	5	" " "						
5080	7, 8	" " "						

IJR X5p3 - 134



Alfred Gauthier G.m.b.H. Calmbach a. d. Enz		PRONTOR-PRESS IJRX5 p3		Geänderte Teile Changed parts		Liste besteht aus Blatt 1,2 Blatt Nr. 1 Gepr. Gefertigt: 2.9.63		
zu Modell IJRX5p		to model IJRX5p						
Lfd.Nr.	Teil Nr.:	Teilbenennung:		Teil:				
1		Änderung Nr. 2950 Change Nr. 2950						
2	IJRX5 - U31.1 siehe Mod. IJRX5p Bl.1 see model IJRX5p on sheet 1	Antriebring an Stelle v. IJRX5p-U31 drive ring inst. of IJRX5p-U31						
3	IJRX5 - 61 siehe Mod. IJRX5p Bl.3 see model IJRX5p on sheet 3	Sektor an Stelle v. IJRX5p-61 shutter blade inst. of IJRX5p-61						
4		Änderung Nr. 2963 Change Nr. 2963						
5	IJRX5p3-127	Anschlagplatte stop plate						
6	1817-30-6400	Sektorenringschr. an Stelle v. IJRX5p-130 shutter blade ring screw inst. of IJRX5p-130						
7		Änderung Nr. 3074 Change Nr. 3074						
8	IJRX5p3-8	Irisdeckscheibe an Stelle v. IJRX5p-8 diaphragm covering disc inst. of IJRX5p-8						
9		Änderung Nr. 3340 Change Nr. 3340						
10	IJRX5p2-8	Irisdeckscheibe an Stelle v. IJRX5p3-8 diaphragm covering disc inst. of IJRX5p3-8						
<div><div> IJRX5p3-127</div><div> 1817-30-6400</div></div> <div><p>IJRX5p3-8</p><p>IJRX5p2-8</p></div>								
Änderungszustand dieses Blattes								
Änd. Nr.	Lfd. Nr.	Tag u. Name	Änd. Nr.	Lfd. Nr.	Tag u. Name	Änd. Nr.	Lfd. Nr.	Tag u. Name
2950	2,3	2.9.63						
2963	5,6	" " "						
3074	8	" " "						
3340	10	" " "						



IJR5p3-127



1817-30-6400



Alfred Gauthier G. m. b. H.
Calmbach a. d. Enz

PRONTOR - PRESS
IJRX5 p3

Geänderte
Teile


zu Modell IJRX5p to model IJRX5p Changed parts

Liste besteht aus Blatt

Blatt Nr. 2 Gepr.

Gefertigt: 2.9.63 /e

Lfd.Nr.	Teil Nr.:	Teilbenennung:	Teil:
1		<u>Änderung Nr. 3341</u> <u>Change Nr. 3341</u>	
2	IJRX5p - U31 siehe Mod.IJRX5p Änd.-Bl.2 see model IJRX5p change sheet 2	<u>Antriebring</u> an Stelle v. IJRX5 - U31.1 drive ring inst of IJRX5 - U31.1	
3	IJRX5p - 61 siehe Mod.IJRX5p Änd.-Bl.2 see model IJRX5p change sheet 2	<u>Sektor</u> an Stelle v. IJRX5 - 61 shutter blade inst. of IJRX5 - 61	
4	IJRX5p - 130 siehe Mod.IJRX5p Bl. 4 see model IJRX5p Bl. 4	<u>Sektorenringschr.</u> an Stelle v. 1817-30-6400 shutter blade ring screw inst. of 1817-30-6400	
5		<u>Änderung Nr. 3463</u> <u>Change Nr. 3463</u>	
6	IJRX5p3 - 3.1	<u>Boden</u> an Stelle v. IJRX5p3 - 3 bottom inst. of IJRX5p3 - 3	
7			
8			
9			
10			



Änderungszustand dieses Blattes

Änd. Nr.	Lfd. Nr.	Tag u. Name	Änd. Nr.	Lfd. Nr.	Tag u. Name	Änd. Nr.	Lfd. Nr.	Tag u. Name
3341	2, 3, 4	2.9.63						
3463	6	" " "						