


REPAIR MANUAL

MODEL	HOUSE CODE	FIG. 1/8
OLYMPUS OM-2	MDE	

OLYMPUS OPTICAL CO., LTD. TOKYO, JAPAN


NOTE: WHEN ORDERING FOR SPARE PARTS, PLEASE CLARIFY A MODEL, PARTS NUMBER AND QUANTITY.



REPAIR MANUAL

MODEL	HOUSE CODE	FIG. 2/8
OLYMPUS OM-2	MDE	
OLYMPUS OPTICAL CO. LTD. TOKYO, JAPAN		


NOTE: WHEN ORDERING FOR SPARE PARTS, PLEASE CLARIFY A MODEL, PARTS NUMBER AND QUANTITY.



REPAIR MANUAL

MODEL	HOUSE CODE	
OLYMPUS OM-2	MDE	FIG. 3/8
OLYMPUS OPTICAL CO., LTD. TOKYO, JAPAN		


NOTE: WHEN ORDERING FOR SPARE PARTS, PLEASE CLARIFY A MODEL, PARTS NUMBER AND QUANTITY.



REPAIR MANUAL

MODEL	HOUSE CODE	FIG. 4/8
OLYMPUS OM-2	MDE	
OLYMPUS OPTICAL CO., LTD. TOKYO, JAPAN		


NOTE: WHEN ORDERING FOR SPARE PARTS, PLEASE CLARIFY A MODEL, PARTS NUMBER AND QUANTITY.




REPAIR MANUAL

MODEL	HOUSE CODE	FIG. 5/8
OLYMPUS OM-2	MDE	
OLYMPUS OPTICAL CO., LTD. TOKYO, JAPAN		

NOTE: WHEN ORDERING FOR SPARE PARTS, PLEASE CLARIFY A MODEL, PARTS NUMBER AND QUANTITY.



Shutter Circuit Diagram



REPAIR MANUAL

MODEL	HOUSE CODE	FIG. 8/8
OLYMPUS OM-2	MDE	
OLYMPUS OPTICAL CO. LTD. TOKYO, JAPAN		

NOTE: WHEN ORDERING FOR SPARE PARTS, PLEASE CLARIFY A MODEL, PARTS NUMBER AND QUANTITY