

# **Mamiya**

## **REPAIR MANUAL**

### **645 PRO CAMERA BODY**



**MAMIYA AMERICA CORPORATION**

8 Westchester Plaza, Elmsford, NY 10523 • 914-347-3300

Catalog No. **20091140**

# 1. CMERA BODY

---

## 1-1 GENERAL SPECIFICATIONS

|                                  |   |
|----------------------------------|---|
| 1. APPERANCE AND DIMENSION ..... | 1 |
| 2. SPECIFICATION .....           | 2 |

## 1-2 DISASSEMBLY AND REASSEMBLY


|                                       |   |
|---------------------------------------|---|
| 1. LEFT, RIGHT AND BOTTOM COVER ..... | 4 |
| 2. WIND-UP SUBSTRATE UNIT .....       | 6 |
| 3. SHUTTER CURTAIN UNIT 1 .....       | 7 |
| 4. MAIN F.P.C. BOARD .....            | 8 |
| 5. WIND-UP SUBSTRATE UNIT 2 .....     | 9 |



645 PRO

|   |                        |
|---|------------------------|
| 1 | CAMERA BODY            |
| 1 | GENERAL SPECIFICATIONS |

|   |                         |     |   |  |
|---|-------------------------|-----|---|--|
| 1 | APPERANCE AND DIMENSION | 1/1 | 1 |  |
|---|-------------------------|-----|---|--|



|         |    |      |
|---------|----|------|
| Remarks | 92 | AUG. |
|---------|----|------|

|   |                |     |   |  |
|---|----------------|-----|---|--|
| 2 | SPECIFICATIONS | 1/2 | 2 |  |
|---|----------------|-----|---|--|

## MAMIYA-645 PRO SPECIFICATIONS

|                     |  |
|---------------------|--|
| Type                | 6 × 4.5 cm sized single-lens reflex camera with an electronically controlled focal-plane shutter   |
| Size of image plane | Semi-brownie size : Actual image plane size 56 mm × 41.5 mm  |
| Film for use        | 120 film (120 roll film holder)<br>15 exposures<br>220 film (220 roll film holder)<br>30 exposures<br>Instant film (Polaroid Land pack film holder) Polaroid 100, 600 series, Fuji FP series<br>135 film (135 film holder)<br>35 mm film, Panoramic film |
| Film loading        | Middle frame type (120 and 220 roll film holder)<br>(135 film holder)<br>Pack type (Polaroid Land pack film holder)<br><br>All these films are supplied together with ISO sensitivity dial, and sliding cover type safety device.                        |
| Standard lens       | Mamiya-Sekor C80mm f/2.8N  |
| Lens mount          | Mamiya M645 Bayonet Mount<br>(All M645 lens can be mounted.)   |
| Shutter             | Electronically controlled focal-plane shutter<br>(The second curtain is controlled by moving coil.)  |
| Shutter speed       | Manual : 4 sec. to 1/1000 sec., B.T.<br>Auto : 8 sec. to 1/1000 sec. (When the AE prism finder is used.)   |
| Shutter button      | Electro-magnetic release<br>Changeable to lock and self-timer modes by pressing the selector switch.   |
| Mirror              | Instant return reflective mirror with mirror lock-up device  |
| Finder              | Changeable (Waist level finder, prism finder, AE prism finder)<br>(Finder for M645 Super can be used.)   |
| Finder screen       | With standard micro/split (horizontal) fresnel lens, periphery of which is mat screen.   |
| Visual field factor | Real image plane ratio      Approx. 94%  |


Remarks

92 AUG.

|  |   |
|--|---|
| Film advancing                                   | One revolution advancing by a handle with crank<br>Crank starting position can be set at 6 places.<br>Interchangeable with winder grip  |
| Film counter                                     | Automatic restoration, sequential counting<br>Films 120, and 220 are automatically changed by the middle frame.   |
| Multiple exposure                                | Practicable with multiple exposure selector lever   |
| Depth of field                                   | Lens with graduations for the depth of field, practicable to check with A-M selector lever  |
| Self-timer                                       | Electronic self-timer, working time : 10 seconds, suspension on the halfway is feasible, Working is indicated by the LED  |
| Auxiliary release contact point                  | Releasing is feasible by inserting electro-magnetic cable release into the contact point of the body.<br>The cable release can also be used by inserting the cable release adapter or the terminal adapter into the said contact point. |
| Battery checker                                  | The LED displays the remaining amount of electricity in 3 steps when the battery check button is pressed.   |
| Synchronized flashing                            | X contact (Hot shoe and terminal)   |
| Back lid   | With housing pocket for sliding lid<br>With memo-pocket (excluding Polaroid Land Pack Film Holder)  |
| Operating temperature                            | -10 to +40° C (relative humidity; 85%)  |
| Feasible number of photographings (Battery life) | 10,400 times (4LR44) <ul style="list-style-type: none"> <li>— With AE prism finder</li> <li>— Shutter speed: 1/60 sec.</li> <li>— Continuous photographing at normal temperature</li> </ul>   |
| Power source                                     | One 6V electric cell (4SR44 Mercury cell, 4LR44 Alkali-manganese cell and Lithium cell) Interchangeable (common with the screen of M645 Super)  |
| Others   | With a neck strap   |
| Dimensions                                       | (W) × (H) × (D)<br>92 × 102.5 × 69  |
| Weight   | 550g (excluding battery)  |

Remarks

92 AUG.



As for the disassembly and reassembly not described herein, please refer to the exploded views in the Parts Catalogue. Here, we mention only key points of disassembly, reassembly and adjustment.

#### [A. DISASSEMBLY]

1. Disassemble in the order of numerical figures shown in small circles. (See Fig. 1.)
2. Set the release selector at the release position (set the index mark (A) to the □ mark (B).), and remove the left cover. (See Fig. 2.)
3. For removing the hooks (C) and (D) of left and right covers, insert a thin plate (No.2 (-) screw driver) and push up them. They may easily be taken out. Meantime, when inserting a screw driver, exercise good care not to mar the cover. (See Fig. 3, Fig. 4)

Remarks

92 AUG.




Fig. 5

**[B. REASSEMBLY]**

Reassemble in the reverse order of disassembly.

1. Before reassembling right cover, insert the RC cover **F** to the RC pin base **E** from the direction RC and then assemble right cover. (See Fig. 5.)





Fig. 6

2. Set the release selector to the release position **G** and then install. (See Fig. 6.)

Remarks

92 AUG.





#### [A. DISASSEMBLY]

1. Disassemble in the order of numerical figures shown in small circles. (See Fig. 1.)
2. Unsolder orange C and black D lead wires from the switch S4. (See Fig. 2.)
3. Unsolder pink E and black F lead wires from the MR unit B (magnet). (See Fig. 3.)

**Note:** Let the F3 gear substrate A escape in the arrow direction, and remove the wind-up substrate unit C. (See Fig. 1.)

Remarks






Fig.4

**[B. REASSEMBLY]**

1. Reassemble in the reverse order of disassembly.
2. Set the mirror release lever ④ on the right side of the release lever ①, and right the S2 gear ⑨ engage wit the S3 gear ⑩.




Fig. 4




Fig. 2 BOTTOM VIEW




Fig. 3




Fig. 1

**[A. DISASSEMBLY]**

1. Remove the wind-up substrate. (Refer to on page 6.)
2. Disassemble in the order of numerical figures shown in small circles. (See Fig. 1.)
3. Remove the synchro-cords (A) and (B) from the relay substrate. (See Fig. 2.)
4. Unsolder four connected points of the main flexible substrate (C), using the desoldering wire (solder-wick).
5. Peel off the main flexible substrate in the arrow direction. (As this is adhered with pressure sensitive double coated tape, be careful not to break the flexible substrate. (See Fig. 3.)


**Note:** When removing the shutter substrate, remove the tip of the release lever (E) through the groove (F) of the body. (See Fig. 4.)

**[B. REASSEMBLY]**

1. Reassemble in the reverse order of disassembly.

Remarks

92 AUG.




#### [A. DISASSEMBLY]

1. Disassemble in the order of numerical figures shown in small circles. (See Fig. 1.)
2. With desoldering wire (solder wick) remove the lead wires (A), (B), (E) (each 2 wires), (F) (2 places), and connected parts of flexible substrate (C), (D), (G). (See Figs. 2 and 3.)  
Part (C) : 26 places    Part (D) : 2 places    Part (G) : 4 places  
**Note : As the flexible substrate is adhered with pressure sensitive double coated tape, be careful not to break it when peeling off the tape.**
3. Remove two places of contact (H) from the battery case. (See Fig. 1.)

#### [B. REASSEMBLY]

1. Reassemble in the reverse order of disassembly.


Remarks



#### [A. DISASSEMBLY]

1. Disassemble in the order of numerical figures shown in the small circles.

**Note:** When disassembly with wind-up substrate from its front face, be sure not to disassemble other parts than the parts numbered ① to ⑩ in Fig. 1. (When disassembling the clutch substrate ⑤, pay attention to the position for reassembling.)




#### [B. REASSEMBLY]

1. Reassemble in the reverse order of disassembly.
2. Assemble the F. idle gear ① so that its convex face will be on the side of wind-up substrate ⑤. (See Fig. 2.)
3. The F1 gear ② shall be installed to the position on a straight line connecting the centers of the positioning holes both ③ and ④. (See Fig. 3.)
4. Put the plate ⑥ in the notch of claw ⑦ of the wind-up substrate ⑤. (See Fig. 4.)
5. Insert the coupler plate ⑧ so that its positioning hole ⑨ will fit to the hole ⑩ in the F1 gear. (See Fig. 3.)

Remarks

92 AUG.



#### [A. DISASSEMBLY]

1. Disassemble in the order of numerical figures shown in small circles.

**Note :** First remove the springs ⑤ and ⑦, then remove three screws ⑧. (See Fig. 1.)

#### [B. REASSEMBLY]

1. Reassemble in the reverse order of disassembly.  
2. Positional relationship of each gear, viz. ①, ② and ③ is shown in Fig. 2. (Gear ② is in the shape of a cam (reverse side), and its starting position is fitted.)

Remarks






Fig.3

3. Subassemble the S. lever ass'y ③ by hitching the hooks ④ and ⑤ of the spring as shown in Fig. 3, and then install to the substrate M.

4. Take off once the spring of reversal lever claw ⑥, and move the reversal lever claw to make a gap, in which insert the S. lever ass'y ③ as shown in Fig. 4. (See Fig. 4.)

Next, place the substrate F ⑤, when pay attention to the fitting position of the lever ③. (See Fig. 5.)

Hook the spring of reversal lever claw ⑥.




Fig.4 Back side view





Fig.5




Fig.6

5. After hooking the spring ⑦, hook the spring ⑧ while pushing it down from above. (See Fig. 6.)

Remarks

92 AUG.




Fig. 8




Fig. 7




Fig. 9

**[C. CHECK]**

1. Install the crank knob, and check wind-up operation. (See Fig. 7)
2. Push the wind-up stopper lever ① to release the stopper, and wind the crank knob up. (See Fig. 8.)

Check that the stopper lever ① is at the position in the middle of wind up motion, i.e. down position at this time, and when wind-up operation is completed and set, this lever returns simultaneously to its original position.

3. Push the lever ②, and release wind-up. (See Fig. 9.)
4. Next, push the lever ③ in the arrow direction to release the mirror up lever and the friction gear. (See Fig. 10.)

Check that the wind-up stopper lever ① goes down when the lever ③ is pushed in the arrow direction all the way, and when the lever ③ is brought back, the wind-up stopper lever ① returns to its original position.

5. Repeat the above mentioned steps 1 to 4 for several times, and check to see if all the mechanisms function smoothly.

Remarks

92 AUG.



# 2. ROLL FILM HOLDER

---


## 2-2 DISASSEMBLY AND REASSEMBLY

- 1. LEFT AND RIGHT AND REASSEMBLY ..... 14
- 2. WIND-UP SUBSTRATE UNIT ..... 15

## 2-3 ADJUSTMENT

- 1. FILM STARTING POSITION ADJUSTMENT ..... 16



**[A. DISASSEMBLY]**

1. Disassemble in the order of numerical figures shown in small circles.
2. Remove the right cover **C** after removing the upper cover **A** and the knob **B**.

**Note :** If you try to remove the right cover **C** before removing the knob **B**, there is a fear of bending the lever **D**.

**[B. REASSEMBLY]**

1. Reassemble in the reverse order of disassembly.

Remarks

92 AUG.




Fig.1

**[A. DISASSEMBLY]**

1. Remove four screws ①. (See Fig. 1.)





Fig.2

**[B. REASSEMBLY]**


1. Reassemble in the reverse order of disassembly.
2. Insert the lever A of the winding substrate ass'y into the groove B of transmission lever of the upper substrate ass'y. (See Fig. 2.)

Remarks

92 AUG.



(A) • (B) : A standard as to the space between picture planes is added. (This is applicable to M645 SUPER.)  
 As for the Film Starting Position Adjustment Procedure, refer to Repair Manual of the M645 SUPER.  
 Refer to page 86.



Remarks

92 AUG.

## 1-3 ADJUSTMENT

|   |    |
|---|----|
| 1. S4 SWITCH AND WIND-UP STOPPER LEVER .....  | 17 |
| 2. ADJUSTMENT OF WIND-UP OVER SET .....   | 18 |
| 3. POSITIONING ADJUSTMENT OF THE FIRST AND SECOND SHUTTER CURTAIN<br>AND SHUTTER CURTAIN SPEED ADJUSTMENT ..... | 20 |
| 4. SHUTTER SPEED ADJUSTMENT .....   | 21 |
| 5. FLANGE-BACK DIMENSION ADJUSTMENT .....   | 22 |

## 1-4 ELECTRIC CIRCUIT

|   |    |
|---|----|
| 1. REFERENCE VOLTAGE • INFORMATION SIGNAL TRANSFER TERMINAL PIN ..... | 23 |
| 2. BASIC CHECK ITEMS .....  | 28 |
| 3. LEAK CIRRENT CHECK AND RELEASE BUTTON HALF PRESSING CHECK .....    | 29 |
| 4. SHUTTER RELEASE CHECK .....  | 30 |
| 5. SHUTTER SPEED STANDARDS .....                                      | 31 |




Fig.1 Back side view





Fig.2

**[A. ADJUSTMENT]**

1. Adjust so that the clearance between the contact of the S4 switch and the upper tip of the switch will be 0.1 to 0.4 mm when the wind-up stopper lever ① is pressed fully. (See Fig. 1.)
2. Adjust by turning an eccentric screw ②. (See Fig. 2.)

**Note :** After adjustment, apply "Lock Tight" to the eccentric screw ②.




Fig.3

3. Connect the tester to the switch cord.  
(See Fig. 3.)
4. Push the lever ③ fully in the arrow direction and keep it as it is, and press down slowly the wind-up stopper lever ① with a finger. (See Figs. 2 and 3.)
5. When the switch turns "ON", put the finger off. Then, the wind-up stopper lever ① returns surely to its original position and the switch must turn "OFF".  
(When checking, do not press the wind-up stopper lever ① beyond the position where the switch turns "ON".)




Fig.4

6. If the wind-up stopper lever ① does not return, bend the contact of the S4 switch to strengthen its bounce ability.  
(See Fig. 4.)

**Note :** Do not over bend the contact of the switch more than necessity.

Remarks




Fig. 1

In the process of winding up the wind-up crank, the shutter charge gear (first and second curtains) will be set, and next, the clutch for wind-up crank will get out of gear, which means completion of wind-up motion. In this process, the over set of shutter charge and the timing of clutch getting out are the important problems.

Adjustment is made fundamentally in the state that the mirror box is removed. However, we also mention a simple method of adjustment.




Fig. 2

#### [A-1. ADJUSTMENT]

1. Wind up the wind-up crank until the space between the second curtain charge gear (A) and the hook (B) of the second curtain becomes 0.3 to 0.6 mm, at this time, the clutch (C) of the wind-up substrate must get out of the gear.  
Loosen the screw (D) and adjust the position of the stopper (E) so that the clutch works at the timing as described above. (See Fig. 1.)

#### [B. CHECK]

1. If the clutch (C) gets out of the gear before the second curtain charge gear (A) hitches the second curtain hook (B), the first curtain would run as soon as the wind-up crank is wound.
    - ① The MC works but the shutter cannot released.
    - ② The shutter can be released but the curtain does open.
  2. If the over set is too large, wind-up and setting cannot be made.  
Even if wind-up and setting could be made, release of crank becomes heavy.
  3. Repeat shutter releasing for several times for checking smooth operation.
- Note :** After adjustment, be sure to apply screw lock tight to the screw (D).






Fig. 3




Fig. 4




Fig. 5




Fig. 6




Fig. 7

**[A-2. ADJUSTMENT]**

1. Loosen the screw ① and push the stopper ② in the arrow direction until it comes to the end. Then, tighten the screw temporarily. (See Fig. 3.)

2. Wind the wind-up crank and press the release button.

At this time, if you cannot release (the shutter does not run), release it forcibly, and make it possible to wind up.

- ① Push the lever ③ in the arrow direction to let the first curtain run. (See Fig. 4.)

- ② Push the second curtain ④ (white) and let it run. (See Fig. 5.)

(Through the hole in the lower substrate insert No.2 (-) screw driver and release the shutter. (See Fig. 5.)

3. Next, loosen the screw ① and move the stopper ② a little in the arrow direction. Then, tighten the screw ① temporarily and repeat the step 2 again.

4. While repeating the steps 2 and 3, find out the position where you can release the shutter, and put the mark ⑤. (See Fig. 6.)

5. In the arrow direction move the stopper ② further from the position marked ⑤ to the position ⑥, which distance is equal to the thickness of the stopper ②.

At this position, tighten the screw ① finally and firmly. (See Fig. 7.)

(This position corresponds with the position of overcharge 0.3mm)




Fig. 1

For the assembly and adjustment procedures of the shutter curtain start positioning, refer to repair manual of the M645 SUPER.

(See Fig. 1)

**Note:** Refer to pages 31 to 33.

We show assembly tolerance of the M645 SUPER. (See Fig. 2)

**Note:** Refer to pages 31 to 34.




Fig. 2





Fig. 3

We show adjustable range of the M645 PRO shutter curtain speed as follows (See Fig. 3)

**Note:** Refer to pages 34.

|                  |        |         |          |
|------------------|--------|---------|----------|
| ① First curtain  | 1/1000 | 13.3 mS | ± 0.2 mS |
| ② Second curtain |        | 13.3 mS |          |

Remarks

92 AUG.




Fig. 4 Bottom view




Fig. 5

1. Shutter speed adjustment is made only for 1/1000 mS.

(As for 1/500 mS to 4S, correct value for each speed can be obtained necessarily but be sure to check each shutter speed.)

## 2. ADJUSTMENT


Turn an eccentric pin (B), and adjust the clearance between the trigger switch contact (C) and working pin (D). (See Fig. 4.)

### Notes:

- ① If the eccentric pin (B) is drawn too much in the direction (E), it will touch the working pin (D), resulting in malfunction. So, be careful. (See Fig. 5.)
- ② Check the source voltage is 6V.



Remarks

92 AUG.




**Note :** From 3 kinds of jigs and tools for checking and adjusting dimensions of the flange-back and flatness of the bayonet face, remove the guide plate (A) of SLS-3 (645 PRO / M645 SUPE / M645) as shown in the drawing and use.

(This is because the guide plate (A) touches the aperture lever of the camera body and it interferes accurate measurement.)



Remarks

92 AUG.



| Symbol | Connection of DCV tester           |                            |       | Switch S         |         |
|--------|------------------------------------|----------------------------|-------|------------------|---------|
|        | Description                        | Red terminal (+)           | ( - ) |                  | Out put |
| G3     | Shutter speed code                 |                            | GND   | 1.3V<br>or<br>0V | ON      |
| G2     | Shutter speed code                 |                            |       |                  |         |
| G1     | Shutter speed code                 |                            |       |                  |         |
| G0     | Shutter speed code                 |                            |       |                  |         |
| GND    | Ground ( - Power source)           | Refer to page 24<br>Fig. A |       |                  |         |
| TG     | Trigger signal output              |                            |       |                  |         |
| VCC    | + Power source output              |                            |       |                  |         |
| AMG2   | AE control signal input            |                            |       |                  |         |
| ASL    | Release signal output              |                            |       |                  |         |
| ASI    | Power ON signal output             |                            |       |                  |         |
| SV     | ISO signal output                  |                            |       |                  |         |
| VK     | Reference voltage (Hi) input       |                            |       |                  |         |
| CHK    | Magnet check input                 |                            |       |                  |         |
| VK     | Reference voltage (Hi) input       |                            |       |                  |         |
| VR     | Reference voltage (Lo) input       |                            |       |                  |         |
| AVR    | Aperture information signal output |                            |       |                  |         |

| Symbol<br>Shutter speed | G0 | G1 | G2 | G3 |
|-------------------------|----|----|----|----|
| 1/1,000                 | 1  | 0  | 0  | 0  |
| 1/500                   | 1  | 1  | 0  | 0  |
| 1/250                   | 0  | 1  | 0  | 0  |
| 1/125                   | 0  | 1  | 1  | 0  |
| 1/60                    | 1  | 1  | 1  | 0  |
| 1/30                    | 1  | 0  | 1  | 0  |
| 1/15                    | 0  | 0  | 1  | 0  |
| 1/8                     | 0  | 0  | 1  | 1  |
| 1/4                     | 1  | 0  | 1  | 1  |
| 1/2                     | 1  | 1  | 1  | 1  |
| 1                       | 0  | 1  | 1  | 1  |
| 2                       | 0  | 1  | 0  | 1  |
| 4                       | 1  | 1  | 0  | 1  |
| B                       | 1  | 0  | 0  | 1  |
| AEL                     | 0  | 0  | 0  | 1  |
| A                       | 0  | 0  | 0  | 0  |

Finder contact pin signal  
0=0V, 1=3V  
Output resistor 1k  $\Omega$

|   |   |     |    |
|---|---|-----|----|
| 1 | REFERENCE VOLTAGE • INFORMATION SIGNAL<br>TRANSMITTING TERMINAL PIN | 2/5 | 24 |
|---|---|-----|----|


Fig. A

| Symbol      |      | Connection of the DCV tester  |  |  |           |
|-------------|------|-------------------------------|--|--|-----------|
| Description |      | Red terminal (+)              | Black terminal ( - )   | Output                                     | S1 switch |
| 1           | GND  | Earthing<br>( - power source) | (1) Space between ( - ) contact points in the battery chamber (no battery)   | 2 $\Omega$ or lower                        | OFF       |
|             |      |                               | (2) Pin B3 (GND)   |  | OFF       |
| 2           | TG   | Trigger signal output         | When the resistor of 10k $\Omega$ is connected between TG and Vcc under the condition that power source voltage is 6V, the voltage between the TG and the GND shall be about at the time immediately after completion of wind-up motion, while it shall be 6V when the first curtain of the shutter is about to start (The needle of the swings momentarily) |  |           |
| 3           | VCC  | +power source output          | (1) GND  | About 6V                                   | OFF       |
|             |      |                               | (2) Between (+) contact points in the battery chamber  | About 10 $\Omega$                          | OFF       |
| 4           | AMG2 | AE control signal input       | In case of the A - AEL mode, signal the AE finder is input.  |  |           |
| 5           | ASL  | Release signal output         | (1) GND  | About 6V                                   |           |
|             |      |                               | (2) When releasing the shutter, the negative pulse of about 7.8ms width and 6V amplitude is output (But in case of the modes A and AEL, the pulse extended to about 1 sec maximum until the AMG2 becomes H.)   |  |           |
| 6           | AS1  | Power ON signal output        | (1) GND  | About 3V                                   | ON        |
|             |      |                               | (2) Shutter speed for manual operation   | Voltage (3V) is hold for about 10 $\Omega$ | ON        |
|             |      |                               | (3) When the shutter is released,  | About 0V (about 1K $\Omega$ )              | ON        |
| 7           | SV   | ISO signal output             | When the reference voltage (VK) is input, the ISO sensitivity (SV) from the film holder is output.   |  |           |
| 8           | VK   | Reference voltage (Hi) input  | Reference voltage from finder is input.  |  |           |
| 9           | CHK  | magnet detection input        | (1) Set the shutter speed dial at the position A, and turn the to S1 to ON. when the S1 is shorted with the GND, the magnet for releasing the first curtain shall function.  |  |           |
|             |      |                               | (2) Set the shutter speed dial at the AEL, and turns the and turns the S1 to ON when the S1 is shorted with the GND the moving coil for  |  |           |

Remarks

92 AUG.





Remarks



## WINDER GRIP CONTACT




Fig.1

| Symbol | Description  |
|--------|--|
| GND    | Ground (- Power source)  |
| S1     | Half pressing signal input   |
| S2     | Release signal input   |
| BW     | Winder starting signal output  |
| WD     | Winder stopping signal output  |
| LS4    | Lens shutter mode signal input   |
| LS3    | Lens shutter prelumious signal input<br>(When the shutter button is half pressed, it is about 3V between pin LS3 and GND.) |

(See Fig. 1.)

## BACK CONTACT




Fig.2

| Symbol | Description                   |
|--------|-------------------------------|
| VK     | Reference voltage (Hi) output |
| SV     | ISO signal input              |
| GND    | Ground (- Power source)       |
| DS     | Dark Slide signal input       |

(See Fig. 2.)

## AUXILIARY RELEASE CONTACT




Fig.3

| Symbol | Description                |
|--------|----------------------------|
| S2     | Release signal input       |
| S1     | Half pressing signal input |
| GND    | Ground (- Power source)    |
| NC     | Auxiliary pin              |

(See Fig. 3.)

## SYNCHRO TERMINAL

## ACCESSORY SHOE




Fig. 4





Fig. 5

| Symbol | Description                                      |
|--------|--|
| X      | X contract                                       |
| NC     | Auxiliary pin                                    |
| SON    | Strobe recognition signal input<br>(See Fig. 4.) |
| GND    | Ground (– Power source)                          |
| X      | X contract                                       |
| GND    | Ground (– Power source)                          |

(See Fig. 5)



| No. | Symbol | Description                  |
|-----|--------|------------------------------|
| 1   | VK     | Reference voltage (Hi) input |
| 2   | SV     | ISO signal output            |
| 3   | GND    | Ground                       |
| 4   | DS     | Dark Slide signal output     |

Remarks

92 AUG.

Check shall basically be made for body as a single substance.

(This check is to offer a hint to find out the cause of trouble that the shutter does not function well.)

#### FOUR BASIC CHECK ITEMS

##### 1. Battery

- (1) Press the battery check button and check to see if the battery check LED lights.

No

- ① Is the battery polarity correct?
- ② Is the battery voltage 6V?
- ③ Check soldering of orange cord for battery check button. (See Fig. 1.)
- ④ Does the moving coil short? (See Fig. 2.)  
(For check method, refer to page 52 of Repair Manual for the M645 SUPER.)
- ⑤ Check to see if the C6 (1000  $\mu$  F) condenser is properly soldered or if this part is faulty.

YES




Fig. 1




Fig. 2

- ⑥ Check to see if battery check LED is properly soldered or if this part is faulty.

S1 = "ON" (Release button is half pressed.)

On the above condition, let the part (A) of the LED short to the GND, and check the LED lights or not.




Fig. 3

(The battery check circuit is made up with the relay IC, and when the battery checker does not light, it is judged that the IC is faulty. However, for the sake of confirmation, be sure to execute 4 basic item check.)

IC is faulty: Replace the main P.C.B. with new one.

(1) When body circuit is normal, leak current is  $1 \mu A$  or less.




Fig.4

**Notes:** 1) As it is impossible to measure with an analog tester, be sure to use a digital multi-meter.

2) Be careful of the polarities of the dummy battery.

A current of about 7mA will flow if connections to the battery terminals are wrong. (See Fig. 7.)

3) As the leak current is as low as  $1 \mu A$  or less, it is rather difficult to check. Therefore, let the S1 turn ON and on this condition measure the current. After confirming that the connections are correct, measure the leak current. (When S1 is ON, it is about 2mA.)

| Current<br>MODEL | Leak current       | Consumed current<br>(S1=ON) |
|------------------|--------------------|-----------------------------|
| M645 SUPER       | $10 \mu A$ or less | About 1.7mA to 3mA          |
| 645 PRO          | $1 \mu A$ or less  | About 2mA                   |

(2) Be sure to mount new type of the reference AE Prism Finder (for M645 PRO), and if leak current is  $2 \mu A$  or more, it is necessary to change the main P.C. Board.

**Note :** Shutter speed dial position: A

### 3. RELEASE BUTTON HALF PRESSING (S1 = ON) CHECK

(1) Body is in the state that the wind-up is completed

S1 = ON → LED display in the AE finder : Lights.

S1 = OFF → LED display in the AE finder : Confirm that the LED goes out.

① S1 switch is faulty. (S1 = ON Power is supplied to the circuit.)

② Power source (Battery is faulty.)

**Notes :** 1) With the AE prism finder

2) Shutter speed dial position: A

(1) Can the shutter be released at the shutter speed  $1/1000\text{ms} \cdot 1\text{S} \cdot 4\text{S} \cdot \text{B}$ ?

No

Mount the new type AE prism finder on the camera body and check to see if the LED display inside the finder flashes at 1Hz

a) If it flashes at 1Hz:

- ① Dark Slide switch
- ② LS3 signal
- ③ S4 switch

There are possibilities of these switches short to the GND. (See Fig. 5.)





Fig. 5



b) If it does not flash,

Check whether or not the sound click to tap the moving coil is heard when releasing the shutter.

- ① Turn shutter speed dial to 4S, and release.

If it sounds immediately after releasing, it is probable that the trigger switch is at OFF position. (See Fig. 6.)

- ② If it sounds 4 seconds after releasing, the release magnet does not function. Accordingly, check function of the release magnet mechanism. (See Fig. 7.)




Fig. 6




Fig. 7

Remarks



## FOCAL-PLANE SHUTTER EXPOSURE TIME TOLERANCE

(Unit: ms)

| Speed graduation | Allowance<br>(step) | Reference value |           |       |
|------------------|---------------------|-----------------|-----------|-------|
|                  |                     | +               | Tolerance | -     |
| 1                | ± 0.5 EV            | 1014            | 1000      | 707   |
| 2                |                     | 707             | 500       | 354   |
| 4                |                     | 354             | 250       | 177   |
| 8                |                     | 177             | 125       | 88.4  |
| 15               |                     | 88.4            | 62.5      | 44.2  |
| 30               |                     | 44.2            | 31.2      | 22.1  |
| 60               |                     | *22.1           | *20.0     | *18.0 |
| 125              | ± 0.43 EV           | 13.1            | 7.81      | 4.65  |
| 250              |                     | 6.57            | 3.91      | 2.32  |
| 500              |                     | 3.28            | 1.95      | 1.16  |
| 1000             |                     | 1.64            | 0.976     | 0.58  |

- \* Special standards (Countermeasure against large size strobe)
  - Measured source voltage 5.8V
  - Allowance Normal temperature (22° ± 5°C)

(1) X contact timing Shutter speed: 1/60 A chenal : 0.5mS~1.0mSec  
B chenal : 2.5 mS or more




Remarks

92 AUG.

|         |                         |     |                  |
|---------|-------------------------|-----|------------------|
| 645 PRO |                         | 1   | CAMERA BODY      |
|         |                         | 4   | ELECTRIC CIRCUIT |
| 5       | SHUTTER SPEED STANDARDS | 2/2 | 32               |

(2) Contact efficiency      Synchro-terminal

Shutter speed 1/15      70% or more  
Contact time ② (INTERVAL ms) 2.5 mS



Contact efficiency meter

Remarks

92    AUG.



# 3. AE PRISM FINDER

---

## 3-1 OUTLINE

|                        |    |
|------------------------|----|
| 1. SPECIFICATION ..... | 33 |
|------------------------|----|

## 3-2 DISASSEMBLY AND REASSEMBLY

|   |    |
|---|----|
| 1. TOP COVER DISASSEMBLY AND REASSEMBLY ..... | 34 |
|---|----|

## 3-3 ELECTRIC CIRCUIT

|   |    |
|---|----|
| 1. INFORMATION SIGNAL TRANSFER TERMINAL PIN ..... | 35 |
| 2. DISPLAY INSIDE THE FINDER .....                | 36 |
| 3. REFERENCE VOLTAGE .....                        | 38 |
| 4. AE ADJUSTMENT (AV/SP) .....                    | 42 |
| 5. BATTERY CHECK AND ADJUSTMENT .....             | 43 |

|                        |   |
|------------------------|---|
| Model                  | TL exposure measurement at open aperture<br>Aperture-priority automatic exposure 6 × 4.5 cm Prism finder  |
| Prism optical system   | Composed of 4 prisms including roof (Dach) prism and eye piece  |
| Diopter                | - 0.8 dptr. (Standard)<br>Diopter correcting lens exchangeable  |
| Metering system        | Composed of 3 changeover light measuring systems, viz.:<br>Average light measuring (Av), Partial light measuring (Sp),<br>A-S automatic changeover light measuring  |
| Photometry range       | 80/2.8N lens, by ISO 100<br>Ev1 (F2.8, 4 seconds) to Ev19 (F22, 1/1000 Second)  |
| Control system         | Electronic shutter control  |
| Shutter speed          | (1) AUTO : 1/1000 to 8 sec. (step interval 1/6 Ev)<br>(2) MANUAL : 1/1000 to 4 sec. (step interval 1 Ev)  |
| Aperture range         | All 7 steps (Step interval 1/5 Ev. Coupled with all aperture values of all  |
| Film sensitivity range | ISO 25-6400 (Step interval 1/3Ev, coupled with film holder)   |
| Display                | Character display by LED back light<br>(1) Shutter speed: 1/1000 to 1 sec. (step interval 1Ev), LT (long time exceeding 1 sec.)<br>B. Intermediate shutter speed is displayed by 2 shutter speed displaying lights neighboring each other.<br>(2) Outside the limit of correct exposure: "Over" flashes, for under "LT" flashes<br>(3) Displaying metering system: Av, Sp |
| Exposure correction    | By means of exposure correction dial $\pm 3\text{Ev}$ (step interval 1/3 Ev)  |
| AE lock                | At the AEL position of shutter speed dial on the side of body. Shutter release button is half pressed. Measured light value is stored in memory.  |
| Eye-piece shutter      | Built-in, opened and closed by sliding knob locating on the upper part of eye-piece.  |
| Power source           | Common use of body power source. Nominally 6V.  |




Fig. 1




Fig. 3





Fig. 2

**[A. DISASSEMBLY]**

1. Move the eye-piece shutter knob in the arrow direction. (See Fig. 1.)
2. Set the metering system change-over dial at AUTO A-S, and set the exposure correction dial at "0". Then remove four screws ① and take out the top cover. (See Fig. 1.)


**[B. REASSEMBLY]**

1. Reassemble in the reverse order of disassembly.
2. The click position of the exposure correction dial is the 10th valley from left (right), which is the position "0". (See Fig. 2.)

**Note :** The screw ④ which fasten the dial substrate sometimes pierces the prism and can break it. So, be careful for the length of the screw. (See Fig. 3.)

Remarks

92 AUG.



| Symbol | Description                       |
|--------|-----------------------------------|
| G3     | Shutter speed code                |
| G2     | Shutter speed code                |
| G1     | Shutter speed code                |
| G0     | Shutter speed code                |
| GND    | Ground (- Power source)           |
| TG     | Trigger signal input              |
| VCC    | + Power source input              |
| AMG2   | AE control signal output          |
| ASL    | Release signal input              |
| ASI    | Power ON signal input             |
| SV     | ISO signal input                  |
| VK     | Reference voltage (Hi) output     |
| VR     | Reference voltage (Lo) output     |
| AVR    | Aperture information signal input |

Remarks

92 AUG.

# 645 PRO

3 AE FINDER

3 ELECTRIC CIRCUIT

2 DISPLAY INSIDE THE FINDER

1/2

36

## AE Display

When the shutter dial on the body side is at A or AEL,

- (1) When exposure is correct, one of the shutter speed graduations 1000 to 1, and Lt (in case the shutter speed is at one graduation) or two neighboring graduations (in case the shutter speed is at intermediate position of two graduations) shall light.
- (2) When exposure is over, over graduation shall flash at 8 Hz.
- (3) When exposure is under, graduation LT shall flash at 8 Hz.
- (4) When battery capacity goes down, lighting measured exposure graduation shall start flashing at 2 Hz.


| Correct exposure            |          |   |          | Over   |                             | under   |                 | Battery capacity   |                 |
|-----------------------------|----------|---|----------|--|-----------------------------|---|-----------------|--|-----------------|
| AV<br>SP<br>OVER            | Lighting | AV<br>SP<br>OVER                                | Lighting | AV<br>SP<br>OVER   | Lighting<br>8Hz<br>Flashing | AV<br>SP<br>OVER                                      | Lighting        | AV<br>SP<br>OVER   | Lighting        |
| 1000                        |          | 1000  |          | 1000   |                             | 1000  |                 | 1000   |                 |
| 500                         |          | 500   |          | 500  |                             | 500   |                 | 500  |                 |
| 250                         |          | 250   |          | 250  |                             | 250   |                 | 250  |                 |
| 125                         |          | 125   | Lighting | 125  |                             | 125   |                 | 125  | 2Hz<br>Flashing |
| 60                          | Lighting | 60  | Lighting | 60   |                             | 60  |                 | 60   |                 |
| 30                          |          | 30  |          | 30   |                             | 30  |                 | 30   |                 |
| 15                          |          | 15  |          | 15   |                             | 15  |                 | 15   |                 |
| 8                           |          | 8   |          | 8  |                             | 8   |                 | 8  |                 |
| 4                           |          | 4   |          | 4  |                             | 4   |                 | 4  |                 |
| 2                           |          | 2   |          | 2  |                             | 2   |                 | 2  |                 |
| 1                           |          | 1   |          | 1  |                             | 1   |                 | 1  |                 |
| LT                          |          | LT  |          | LT   |                             | LT  | 8Hz<br>Flashing | LT   |                 |
| B                           |          | B   |          | B  |                             | B   |                 | B  |                 |
| Photometry AV<br>Correct 60 |          | Photometry SP<br>Correct 125<br>Intermediate 60 |          | Photometry AV-SP<br>Lighting<br>Over OVER LT<br>8hz Flashing |                             | Photometry AV<br>Lighting<br>Under LT 8Hz<br>Flashing |                 | Photometry SP<br>Lighting<br>Correct 125<br>2Hz Flashing |                 |

Remarks

92 AUG.








S1 : ON

|   |                                       | DCV Meter Connection |           | Output        | Adjustment |
|---|---------------------------------------|----------------------|-----------|---------------|------------|
|   |                                       | (+) Red              | (-) Black |               |            |
| ① | VR : Operating reference voltage      | VR                   | GND       | 1.0~1.2V      | VR 5       |
| ② | VK : Inputing reference voltage       | VR                   | VK        | 153mV $\pm$ 5 | VR 7       |
| ③ | VAD : AD Converting reference voltage | VR                   | VAD       | 285mV $\pm$ 5 | VR 4       |

Remarks

92 AUG.



S1 : ON

|   |                              | DCV Meter Connection |           | Adjustment |
|---|------------------------------|----------------------|-----------|------------|
|   |                              | (+) Red              | (-) Black |            |
| ④ | VAV : Luminance step voltage | VAV                  | VR        | VR 2       |
| ⑤ | VSP : Luminance step voltage | VSP                  | VR        | VR 1       |


**Note :** When let the luminance change by  $n$  step, output voltage of VAV / VSP shall change by  $n \times 18 \text{ mV}$ .

$$\left( \begin{array}{l} n = 1\text{EV} \\ 1\text{EV} = 18 \text{ mV} \end{array} \right)$$

Remarks

92

AUG.



S1 : ON


|   |                        | DCV Meter Connection |           | ISO | SV : Output |
|---|------------------------|----------------------|-----------|-----|-------------|
|   |                        | (+) Red              | (-) Black |     |             |
| ⑥ | SV : ISO input voltage | SV                   | VR        |     | 153mV ± 10% |
|   |                        |                      |           | 25  | 144mV ± 10% |
|   |                        |                      |           | 50  | 126mV ± 10% |
|   |                        |                      |           | 100 | 108mV ± 10% |
|   |                        |                      |           | 200 | 90mV ± 10%  |
|   |                        |                      |           | 400 | 72mV ± 10%  |
|   |                        |                      |           | 800 | 54mV ± 10%  |
|   |                        |                      |           | 160 | 36mV ± 10%  |

|   |   | DCV Meter Connection |           | CV  | CV : Output   |
|---|---|----------------------|-----------|-----|---------------|
|   |   | (+) Red              | (-) Black |     |               |
| ⑦ | CV : Exposure correction output voltage | CV                   | VR        |     | 153mV ± 10%   |
|   |   |                      |           | - 2 | 112.5mV ± 10% |
|   |   |                      |           | - 1 | 94.5mV ± 10%  |
|   |   |                      |           | 0   | 76.5mV ± 10%  |
|   |   |                      |           | +1  | 58.5mV ± 10%  |
|   |   |                      |           | +2  | 40.2mV ± 10%  |

Note : Whenever ISO dial and exposure correction dial is changed over 1 step each, output voltage shall change about 18 mV.

Remarks

92 AUG.



S1 : ON

|   |                             | DCV Meter Connection |           | FV  | FV : Output   |
|---|-----------------------------|----------------------|-----------|-----|---------------|
|   |                             | [+] Red              | [-] Black |     |               |
| ⑧ | VF : Aperture input voltage | VF                   | GND       |     | 1.253mV ± 10% |
|   |                             |                      |           | F32 | 1.238mV ± 10% |
|   |                             |                      |           | 22  | 1.220mV ± 10% |
|   |                             |                      |           | 16  | 1.202mV ± 10% |
|   |                             |                      |           | 11  | 1.184mV ± 10% |
|   |                             |                      |           | 8   | 1.166mV ± 10% |
|   |                             |                      |           | 5.6 | 1.148mV ± 10% |
|   |                             |                      |           | 4   | 1.130mV ± 10% |
|   |                             |                      |           | 2.8 | 1.112mV ± 10% |

**Note :** Whenever the aperture ring is changed over one step each, input voltage shall change 18mV.

# 645 PRO


3 AE FINDER

3 ELECTRIC CIRCUIT

4 AE ADJUSTMENT (AV/SP)

1/1

42



## 1. AE Shutter speed adjustment

S1 : ON



| TV Dial | Brightness | ISO | Aperture | CV | V/F LED    | Adjuster |      | Reference value          |
|---------|------------|-----|----------|----|------------|----------|------|--------------------------|
|         |            |     |          |    |            | Average  | Spot |                          |
| A       | LV15       |     |          |    | 500        | VR3      | VR6  | * - 0.3EV<br><br>± 0.75E |
|         | LV12       | 100 | 8        | 0  | 125 and 60 |          |      |                          |
|         | LV9        |     |          |    | 8          |          |      |                          |
|         | LV6        |     |          |    | 1          |          |      |                          |

Reference lens : F2.8/80 mm is used.

\* : Reference lens shall be in common with both M645 SUPER and M645 PRO.  
Adjustment shall be made on the basis that the value - 0.3EV is value "0".

Remarks

92 AUG.



1. POWER Supply  
Set the digital tester as shown in the above illustration.
2. Press the B.C. button, turn the VR8 and so adjust that the LED (AE Finder) will flash when the voltage is within the range of 4.5 to 4.7V (indicated by the digital tester).

4.5V to 4.7V Flashing VR8

Remarks

92 AUG.



# 4. WINDER GRIP

---

## 4-1 OUTLINE

|                        |    |
|------------------------|----|
| 1. SPECIFICATION ..... | 44 |
|------------------------|----|

## 4-2 ADJUSTMENT

|                          |    |
|--------------------------|----|
| 1. B.C. ADJUSTMENT ..... | 45 |
|--------------------------|----|

## 4-3 ELECTRIC CIRCUIT

|   |    |
|---|----|
| 1. PREFERENCE VOLTAGE, INFORMATION SIGNAL TRANSFER TERMINAL PIN ..... | 46 |
| 2. OPERATION SEQUENCE .....   | 48 |

## 4-4 TROUBLESHOOTING

|                           |    |
|---------------------------|----|
| 1. MAINTENANCE FLOW ..... | 51 |
|---------------------------|----|

|  |   |
|--|---|
| Battery  | 6 pieces of Dry battery, Size AA<br>(Alkaline or Ni-cad)  |
| The number of<br>photographing frames                | 1 frame photographing and continuous photographing is possible by<br>depressing the shutter button continuously.  |
| Wind-up time   | About 0.5 sec. for 1 frame (Forcal-plane mode)<br>About 1.1 sec. (Lens shutter mode)  |
| The number of films<br>possible for<br>photographing | [Under normal temperature, and under the test conditions of our company]<br>About 80 pcs. of AA size Alkaline battery<br>About 70 pcs. of AA size Ni-cad battery  |
| Operation system                                     | Starts up by half pressing the shutter button or pressing the start button.<br>All are ready for photographing.<br>After completion of photographing, the film is automatically rewound and<br>then it stops. (About 4 seconds.)<br>[In case of M645 SUPER being used, it starts and at the starting position.]<br>After completion of photographing, the film is rewound automatically and<br>then it stops. (About 4 seconds) |
| Battery checker                                      | Checking function with the LED display is attached.   |
| Inputting outside<br>commercial power                | Use 9V an exclusive adaptor for MAMIYA.   |
| When lens shutter lens is<br>used                    | With an exclusive connection cord, automatic set photographing is possible.   |
| Dimensions   | (W) 77.3 × (H) 88 × (D) 72.5 mm   |
| Weight   | 290mg (excluding batteries)   |




Fig. 2





Fig. 3




Fig. 1

1. Remove the mechanism ass'y from the main body, and attach the power supply and digital tester as illustrated. (See Fig. 1.)

**Note:** If the DC jack is unavailable, fit the cords A + and B - to the power supply and connect to the A and B of main P.C. board. (See Fig. 3.)


2. Turn the mode selector ① to the B.C. Turn the VR2 and so adjust that the B.C. LED ② will start to light or flash between 7.34V and 7.06V (displayed on digital tester). (See Figs. 2 and 3.)

3. Turn VR1 and so adjust that the B.C. LED ② will flash or goes out between 7.04V and 6.76V.


Between 7.04V and 6.76V : Flashes or goes out VR1

Between 7.34V and 7.06V : Flashes or goes out VR2

**Note:** If the B.C. LED is lighted for a long time, the R18;27  $\Omega$  runs hot.  
Inspection and adjustment shall be carried out quickly.



| Symbol | Description                             |
|--------|---|
| GND    | Ground (-signal)                        |
| S1W    | Half-press signal output                |
| S2W    | Release signal output                   |
| BW     | Winder starting signal input            |
| WD     | Winder stopping signal output           |
| LS4    | Lens shutter mode signal output         |
| LS3    | Lens shutter pre-emitting signal output |




| Symbol | Description   |
|--------|---|
| LM1    | Lens shutter charge motor power source output<br>(3V outputs between Pin LM1 and GND)         |
| LS1    | Lens shutter charge control signal input  |
| LS2    | Lens shutter charge control signal input  |
| GND    | Ground (- signal)   |
| LS3    | Lens shutter pre-emitting signal input  |
| LS4    | Lens shutter mode signal input  |
| LM2    | Lens shutter charge motor power source output<br>(About 2.6V outputs between Pin LM2 and GND) |

1

REFERENCE VOLTAGE, INFORMATION SIGNAL TRANSFER  
TERMINAL PIN

2/2


47



| Symbol | Description   |
|--------|---|
| LM1    | Lens shutter drive motor (+)  |
| LM2    | Lens shutter drive motor (-)  |
| LS1    | Lens shutter motor control  |
| LS2    | Lens shutter motor control  |
| WD     | Wind up completion signal Turns to H level when wind up is completed. |
| BW     | Wind-up signal  |
| LED    | LED for encoder   |
| PI     | Control signal for encoder  |
| COM    | Ground  |
| WM+    | Motor for wind up   |
| WM-    | Motor for wind up   |
| PVcc   | Motor drive power source (9V)   |
| Vcc    | Power source for control (9V)   |
| RL     | Release lock signal After grounding it becomes enable.                |
| BC     | Power source for battery check control                                |
| START  | Forcible wind-up signal under uncharged condition                     |
| SW1    | Shutter first stroke switch   |
| SW2    | Shutter second stroke switch  |

Remarks

92 AUG.





\*1. Power turns ON by start switch: On or stand up of BW (Wake-up), and operation starts.



\*2. In case that the lens shutter lens is not connected, it turns to the operation of the completion of charge, and only body wind-up is conducted.




- (1) Connect the lens shutter lens to the grip (A), and release the shutter (B).  
(Shutter position: Set at the AUTO.)



- (2) Set the winder select mode to "ON". At this time, the RL terminal becomes L (0V) level. (Action: Enable)





- (3) When the winder select mode is turned to START, the lens shutter is charged.




**Note:** After starting normal or reverse rotation of LM motor, if the position of LS1 or LS2 does not change within 2 seconds, stop the wind-up motion.


- (1) Turn the select mode switch of the winder grip (in the state of single substance) ON. (At this time the RL terminal becomes L (0V) level.)  
↓
- (2) Ground the WD terminal to GND, and turn the select mode switch to START for revolving the motor. (Or impress 3V or more pulse voltage to the BW terminal.)



#### Wind-up by the BW signal



- Notes :**
- 1) After starting the motor, if no change in pulse is recognized in the PI terminal within 200mS, stop the motor.
  - 2) After starting the motor, if 256 pulse comes (3 to 4 seconds), stop the motor automatically. (Wind-up after 15th/30th frame)



\*1 : When START switch is turned ON, the needle oscillates instantaneously.

\*2 : Power time voltage is automatically cut off after 10 seconds.

(When the select mode switch is turned to START, about 2.8V is output.)