

PARTS LISTS & REPAIR MANUALS

ZENZA BRONICA IND., INC.

- CONTENTS -

0	ETR-C CAMERA
	Parts List & Repair Manual 1
0	ETR/ZENZANON 250mm Lens
	Parts List & Repair Manual 16
0	AUTO BELLOW-E
	Parts List & Repair Manual 22

ETR-C CAMERA

Parts List & Repair Manual

1. Composition

- 1. It consists of 9 pages.
- 2. Pages 1 $^{\circ}$ 4 consist of parts lists.
- 3. Pages 5 ∿ 9 consist of exploded views.

2. On Parts Lists

Only ETR-C specialty-parts are described. For common Parts with ETR, refer to ETR-Parts Lists.

3. On Exploded Views

- 1. Based on ETR-C Parts Lists, only those related parts are described. Therefore, just like Parts Lists, for the common parts with those of ETR, refer to the exploded views of ETR.
- 2. In exploded views, the part encircled with ____ means the specialty-part for ETR-C.

z	ENZA BRONICA	ETR-C	!		
Parts No. 部品番号	Name 名 称	Shape 形 状	Posper Unit 個数 頁	Price 単 価	Remarks 備 考
1-290 020	Connecting plate 結合板		1		
062	Bottom cover 下カバー	0	1		
070	Back douser 有面态光板		1		
082	F-releasing pin sleeve F解除ピンスリーフ		1		
091	F-releasing pin F角引介たシ		1		

____ 2 ____

	ZENZA BRONICA LIRICI						
Parts No. 部品番号	Name 名 称	Shape 形 状	Pcs.per Unit 個数	rage	Ass'y No. 組立番号	Price 単 価	Remarks 備 考
1-290120			2	ζ	100 H. 101 7		ина - 5
131	ETR-C name plate ETR-C 含結核	[ETR-C]	1	,			
151	Right cover leatherette (front) 右が一章前		1				
161	Right cover leatherette (back) 石か八-革後	Ö	1				
171	Left cover leatherette 石カハー草		i				
181	S-dial leatherette cover Sタイヤル 蓋草		1				
200	S-dial ring Sダイヤンリック		1				
210	Back bottom cover liner バックトカバーウィナー	0	1				
220	Liner for right cover bottom 石カバー革下用ライナー		1				

ZENZA BRONICA


ZENZA BRONICA						<u> </u>
Parts No.	Name	Shape	Posper Unit Pag		1 1	Remarks
部品番号	名 称 ERT-C top frame ETR-C 上存(彫刻図)	形状	個数頁	組立番号	単価	備考
250	551 QI label					
	551 61751V	521				
270	Connection plate telemp 結合板テレンプ		2			


ZENZA BRONICA


ZENZA BRONICA ETR-C


Parts No.	Name	Shape	Posper	Page	Ass'y No.	Price	Remarks
部品番号	名	形状	Unit 個数		組立番号	単価	備考
1-792010	Winding base plate unit 捲上地板ユニット		1				
1-796010	Top frame set 上梓セルト	The state of the s	1				
1-797000	Connecting plate set 結合板セット		1				
1-797210	Back top cover- caulking set バッフ上かバーカンノセット		1				
I-798020	551 left cover set 551 左カバーセット	6.0	1	:			
1-798040	551 right cover set 551 右カバーセット		1				
			:				

---- 5 ----









Q,

1. Composition

- 1) Contents
- 2) Manual
- 3) Tools for repair

2. Contents

- The contents are mostly the same as those of ETR, and only items are described. As the page-numbers of ETR Repair Manual are described, please refer to them.
- Repairing methods on the Item 1.3.22 are the same as those of ETR, however, some parts are different. To help you check them, the pagenumbers of ETR-C Parts Lists are described for your reference.
- 3) The Item 14.30 is greatly different from that of ETR, thus it is not described in ETR Repair Manual, and page-numbers of ETR-C Repair Manual and those of ETR-C Parts Lists are described for your reference.
- 4) Item 20 does not correspond to ETR-C, also, the connecting plate 2 is described only in exploded view of ETR-C Parts Lists.

Manual

Refer to 2-3).

4. Tools for repair

Description is made for the tools used specifically for ETR-C, and also, positions and methods for their use are listed.

Refer to ETR Repair Manual for other tools.

ETR-C REPAIR MANUAL

CONTENTS


	Item	ETR Repair Manual	ETR-C Repair Manual	ETR-C Parts Lists
1	Right external cover	1	Same as in ETR	8
2	Crank shaft is liable to come off. Does not come off.	2	0	
3	No crank-winding - Poor movement of winding auxiliary plate -	3	17	7
4	No stoppage of crank-winding - Winding-stoppage lever spring came off -	4	"	
5	Much "play" of crank - Main axis stopper-screw is loose -	5	11	
6	No winding - Crack of winding inter- mediate gear -	6	tt .	
7	No depressing of S-button - Wrong position of reverse- checking pawl -	6	gt .	
8	Stiff winding - Loose connecting gear- stopper -	7	"	
9	F-releasing plate and winding plate	8	. 11	:
10	No mirror charge - Wrong bending of M-set lever and S-latch -	9	11	
11	No opening of shutter-blades - Weak power of Mr-operat- ing plate -	10)	
12	Adjustment of eccentric collar	10	91	
13	No opening of S-blades - Stiff rotation of operat- ing ring -	10	11	
14	Mounting of left outside- cover - Rise of S-dial ring -	- <u>-</u>	4	8
15	S-speed becomes 1/500 sec.	13	Same as in ETR	
16	Position of shutter-scale ring and S-dial click	13	11	
17	How to dismount the lens	14	11	ļ
18	No dismounting of lens - No depressing of setscrew with on and off-operating plate -	15	11	
	· · · · · · · · · · · · · · · · · · ·			

	Item	ETR	ETR-C	ETR-C
	TEEM	Repair Manual	Repair Manual	Parts Lists
19	No winding - No return of bottom- releasing bar in hitting the bottom-cover -	16	Same as in ETR	
20	No connection of back - Connecting pawl is loose -	17	_	
21	No operation of AE - Wrong M switch set -	18	Same as in ETR	
22	No mounting of finder-hood - Connecting spring is bent -	19	II	6
23	Adjustment of finder screw- focus	20	11	
24	Mirror douser	21	11	
25	Replacement of mirror	22	. "	
26	Mirror-frame and 45° adjustment	23	**	
27	Finder hood	24	11	
28	Wiring diagram I (ETR-C has no old S-circuit)		"	
29	Wiring diagram II	26	Same as in ETR	
30	Adjustment of F-releasing stroke	_	5	5 & 9
1	Film holder	31 ∿ 37	Same as in ETR	
2	Connecting plate	38 ∿ 40		9
3	75mm F2.8	41 ∿ 43	Same as in ETR	
4	Tools for repair		6	

14. Mounting of left outside cover — Rise of S-dial ring, wrong stopper of S-dial ring —

- 1) Never forget the cable release pin (10755540).
- 2) Among 3 setscrews on lens-side, 2 setscrews on top and bottom are in the earth-circuit, thus use electroplated screws.
- For the rise of S-dial, set #2 and S-dial scale-ring (#1) concentrically.
- 4) Wrong stopper of S-dial

 Set the washer (5-52-311) to 1-256800, and if it still does not stop, replace 1-290201.



30. Adjustment, confirmation on F-release stroke


1) How to dismount the back connecting plate

Dismount the small screws (5-823557 \times 2, 5-823457 \times 3) clamping the connecting plate, in this state, do not take up the connecting plate immediately. Turn the lens-mount side of the body upward, and separate it from the connecting plate by holding the body-side upward. If the connecting plate is dismounted while the lens-mount side is kept downward, the F-releasing pin (1-290091) may fall down and enter into the body-side.

Similarly, to connect, put the body after putting F-releasing pin into F-releasing sleeve on the side of connecting plate. Otherwise, F-releasing pin may fall into the body and the camera would not work.

Be sure the above is observed. Next, dismount the back douser (1-290070).


- 2) By the use of CT-341A F-releasing stroke check gauge (special use for ETR-C), check F-releasing stroke check. Refer to page 6.
 - a) In case of abnormal.....refer to page 8 of ETR Repair Manual
 - b) In case of normal
 Check the Film Holder... refer to page 35 of ETR Repair Manual



Jig No.	Rough sketch	How to use
CT-341A F-releasing stroke check- gauge	16.8 16.0.40.62	Dismount the back connecting plate, and put the body from the upside so that both pins A and B of the jig enter into the holes of the body in which F-releasing sleeve of the connecting plate is to be inserted. In this case, set the multi-lever vertically. Refer to P.2. 1. Check with A (longer one) Shutter should be released with incomplete winding. 2. Check with B (shorter one) Shutter should not be released without complete winding.
CT-302 303 317 Jigs for mechanical measurement		1-252227 Lens Mount For measuring the mechanism of the body itself. Use the set board and dial guage. Put CT-317, CT-303 and CT-302 together. And set the dial gauge indicator to "0". Take out CT-303, put on the camera-body, and put CT-302, on the mount-part for measurement. And adjust the camera-body. o Rated play of connection shall be within 0.06 on the periphery of CT-302. o Mechanical dimension shall be within 0.03 at the central part of CT-302. CT-302 and CT-303 are the same jigs as those for ETR.
CT-371 372 373 Jigs for mechanical measurement	98 98	It is used for mechanical measurement with lens-bayonet and back-connecting plate mounted. Use the set board and dial gauge. Put CT-372, CT-371 and CT-373 together, and set the dial gauge indicator to "0". Take out CT-371, put on CT-373 by putting the mount-side of camera body downward. Next, open the rear cover, and measure it by putting CT-372 on the gate-face to check the mechanism of the camera body. o Mechanical dimensions shall be checked by measuring a total of 5 points, namely, 1 point at the center and 4 points at corners of the jig of CT-372.

ETR/ZENZANON 250 mm Lens

Parts Lists & Repair Manual



1148 (F5.6/250mm)

Index	Parts No.	Parts Name	Q' ty
1	1148-14	Name ring	1
2	1148- 2	Front lens holder	1
3	1148-G1	Lens	1
4	1148- 3	Front lens space ring	1
5	1148-G1	Lens	1
6	1148- 3	Front lens space ring	1
7	1148-G1	Lens	1
8	1148- 1	Front lens frame	1
9	1148-G2	Lens	1
10	1148- 4	Middle lens holder	1
11	1148- 5	Middle frame	1
12	819	Shutter	1
13	1144-39	Limit plate	1
14	1PM1.7 x 4	Pan-head small screw	4
15	1148-12	Filter ring	1
16	3PM1.7 x 3	Pan-head small screw	4
17	1144-38	Diaphragm fork	2
18	1148-13	Aperture ring	1
19	1144-34	T lever axis	2
20	1144-32	T change-over fork	1
21	1144-16	Relay ring	1
22	1144-31	Manual lever axis	1
23	1144-30	Manual lever	1
24	1144-26	Opening spring	1
25	1144-24	Spring axis	1
26	1144-24	Spring axis	1
27	1144-17	Lever	1
28	1144-20	C lever	1
29	1144-23	Lever axis	1
30	1144-27	Auxiliary spring	1
31	1148-28	Lever base plate	1
32	1144-29	Lever holding plate	1
33	3PM1.7 x 4	Pan-head small screw	2
34	1PM1.7 x 4	Pan-head small screw	4

36 1148 37 1147 38 1144 39 1PM1 40 1147 41 1148 42 1144 43 1PM1 44 1148 45 1148 46 1147 48 1147 49 1147 50 1PM1 51 1PM1 52 1148 53 1PM1 54 1148 55 1144 56 1144 57 1144 58 1144 59 1144 60 1144	- 7 -15 .7 x 3.5 - 8 - 9 -11 .7 x 3.5 -12 -22 -10 - 9 -10	Pan-head small screw Depth of field scale ring Shutter printed circuit board Shutter clamp ring Pan-head small screw Helicoid male Distance ring Washer Pan-head small screw Cover plate Tape Rubber knurling ring Helicoid female Master screw	3 1 1 1 6 1 3 3 1 1 1
37	- 7 -15 .7 x 3.5 - 8 - 9 -11 .7 x 3.5 -12 -22 -10 - 9 -10	Shutter printed circuit board Shutter clamp ring Pan-head small screw Helicoid male Distance ring Washer Pan-head small screw Cover plate Tape Rubber knurling ring Helicoid female Master screw	1 1 6 1 1 3 3 1 1 1
38	-15 .7 x 3.5 - 8 - 9 -11 .7 x 3.5 -12 -22 -10 - 9	Shutter clamp ring Pan-head small screw Helicoid male Distance ring Washer Pan-head small screw Cover plate Tape Rubber knurling ring Helicoid female Master screw	1 6 1 1 3 3 1 1 1
39	.7 x 3.5 - 8 - 9 -11 .7 x 3.5 -12 -22 -10 - 9 -10	Pan-head small screw Helicoid male Distance ring Washer Pan-head small screw Cover plate Tape Rubber knurling ring Helicoid female Master screw	6 1 1 3 3 1 1 1
40 1147 41 1148 42 1144 43 1PM1 44 1144 45 1148 46 1148 47 1147 49 1147 50 1PM1 51 1PM1 52 1148 53 1PM1 54 1148 55 1144 56 1144 57 1144 58 1144 59 1144 60 1144	- 8 - 9 -11 .7 x 3.5 -12 -22 -10 - 9 -10	Helicoid male Distance ring Washer Pan-head small screw Cover plate Tape Rubber knurling ring Helicoid female Master screw	1 1 3 3 1 1 1
41 1148 42 1144 43 1PM1 44 1144 45 1148 46 1148 47 1147 48 1147 49 1147 50 1PM1 51 1PM1 52 1148 53 1PM1 54 1148 55 1144 56 1144 57 1144 58 1144 59 1144 60 1144	- 9 -11 .7 x 3.5 -12 -22 -10 - 9 -10	Distance ring Washer Pan-head small screw Cover plate Tape Rubber knurling ring Helicoid female Master screw	1 3 3 1 1 1
42 1144- 43 1PM1 44 1144- 45 1148- 46 1148- 47 1147- 48 1147- 49 1147- 50 1PM1 51 1PM1 52 1148- 53 1PM1 54 1148- 55 1144- 56 1144- 57 1144- 58 1144- 59 1144- 60 1144-	-11 .7 x 3.5 -12 -22 -10 - 9	Washer Pan-head small screw Cover plate Tape Rubber knurling ring Helicoid female Master screw	3 3 1 1 1
43 1PM1 44 1144- 45 1148- 46 1148- 47 1147- 48 1147- 49 1147- 50 1PM1 51 1PM1 52 1148- 53 1PM1 54 1148- 55 1144- 56 1144- 57 1144- 58 1144- 59 1144- 60 1144-	.7 x 3.5 -12 -22 -10 - 9	Pan-head small screw Cover plate Tape Rubber knurling ring Helicoid female Master screw	3 1 1 1
44 1144- 45 1148- 46 1148- 47 1147- 48 1147- 50 1PM1- 51 1PM1- 52 1148- 53 1PM1- 54 1144- 56 1144- 57 1144- 58 1144- 59 1144- 60 1144-	-12 -22 -10 - 9 -10	Cover plate Tape Rubber knurling ring Helicoid female Master screw	1 1 1
45 1148- 46 1148- 47 1147- 48 1147- 49 1147- 50 1PM1. 51 1PM1. 52 1148- 53 1PM1. 54 1148- 55 1144- 56 1144- 57 1144- 58 1144- 59 1144- 60 1144-	-22 -10 - 9 -10	Tape Rubber knurling ring Helicoid female Master screw	1 1 1
46 1148- 47 1147- 48 1147- 49 1147- 50 1PM1. 51 1PM1. 52 1148- 53 1PM1. 54 1148- 55 1144- 56 1144- 57 1144- 58 1144- 59 1144- 60 1144-	-10 - 9 -10	Rubber knurling ring Helicoid female Master screw	1
47 1147- 48 1147- 49 1147- 50 1PM1. 51 1PM1. 52 1148- 53 1PM1. 54 1148- 55 1144- 56 1144- 57 1144- 58 1144- 59 1144- 60 1144-	- 9 -10	Helicoid female Master screw	1
48	-10	Master screw	
49 1147- 50 1PM1. 51 1PM1. 52 1148- 53 1PM1. 54 1148- 55 1144- 56 1144- 57 1144- 58 1144- 59 1144- 60 1144-			
50 1PM1. 51 1PM1. 52 1148- 53 1PM1. 54 1148- 55 1144- 56 1144- 57 1144- 58 1144- 59 1144- 60 1144-	-11		1
51 1PM1. 52 1148- 53 1PM1. 54 1148- 55 1144- 56 1144- 57 1144- 58 1144- 59 1144- 60 1144-		Key	1
52 1148- 53 1PM1. 54 1148- 55 1144- 56 1144- 57 1144- 58 1144- 59 1144- 60 1144-	.7 x 3.5	Pan-head small screw	6
53 1PM1. 54 1148- 55 1144- 56 1144- 57 1144- 58 1144- 59 1144- 60 1144-	.7 x 5	Pan-head small screw	4
54 1148- 55 1144- 56 1144- 57 1144- 58 1144- 59 1144- 60 1144-	-15	Connecting ring	1
55 1144- 56 1144- 57 1144- 58 1144- 59 1144- 60 1144-	.4 x 3	Pan-head small screw	4
56 1144- 57 1144- 58 1144- 59 1144- 60 1144-	-20	Bayonet ring	1
57 1144- 58 1144- 59 1144- 60 1144-	-43	Bayonet ring index	1
58 1144- 59 1144- 60 1144-	-41	Bayonet	1
59 1144- 60 1144-	-48	Set ring lock plate	1
60 1144-	-49	Lock palte axis	1
	·51	Lock leaf spring	1
61 1PM1.	·50	Spring holding screw	1
	7 x 3.5	Pan-head small screw	4
62 1144-	·52	Flexible printed circuit board	2
63 1147-	-23	Ball holder	1
64 1FMl.	7 x 3.5	Pan-head small screw	4
65 1101-	49	Steel ball	83
66 1148-		Set ring plate	1
67 1FM1.	19	Pan-head small screw	4
68 1148-	19 7 x 3.5	Set ring	1
	7 x 3.5		

1148 (F5.6/250mm)

Index	Parts No.	Parts Name	Q¹ty
69	1101-49	Steel ball	91
70	1148-17	Set ring holder	1
71	1147-24	Set ring knock plate	1
72	1FM1.7 x 3	Pan-head small screw	4
73	1148-21	Lead wire	1
74	1144-54	Contact piece insulating plate	1
75	3PM1.4 x 2	Pan-head small screw	4
76	1147-31	Light-tight plate	2
77	1148-16	Set ring base plate	1
78	1PM1.7 x 3	Pan-head small screw	6
79	1RM1.7 x 4	Pan-head small screw	4
80	B.T1M1.7 x 3	Countersunk small screw	4
81	1148- 7	Rear-middle lens holder	1
82	1148-G3	Lens	1
83	1148- 6	Rear lens frame	1
84	1148-G4	Lens	1
85	1148- 8	Rear lens holder	1

Zenzanon 250mm f5.6 lens shutter unit replacing procedure

[Step 1]

Remove the name ring 2 with a name ring mounting jig 1.


[Step 2]

Remove the front lens 3 with a flexible pin-face wrench.

[Step 3]

Remove 3 screws (5) and remove the front frame unit (4).

Note: At this time, be sure to put a rear cap 6 over the unit to protect the shutter contact and contact piece insulating plate from damage.



	1-242602	Rear Cap
5	$1FM1.7 \times 3.5$	Countersunk small screw
4		Front frame unit
3		Front lens
	1148-14	Name ring
$\begin{bmatrix} 1 \end{bmatrix}$	1-210482 - AJ	Name ring mounting jig

[Step 4]

After removing 6 screws (1), remove the set ring unit (2).

[Step 5]

Remove 4 screws (4), and remove (5).

[Step 6]

Remove the rear lens (6).

[Step 7]

Remove solder connecting the shutter cord and flexible printed circuit board 3.

[Step 8]

Loosen the shutter clamp ring (7) and take the shutter out and replace it.

[Step 9]

After replacing a shutter, check the unit if it properly assembled. If it is deviated partly, remove the rubber knurling ring 11, tape 10 and cover plate 9.

After that, loosen screws 8 and perform mechanical focus adjustment of the unit.


Upon completion of adjustment, tighten those screws securely.

Note:

Assembly of shutter unit can be accomposshed by performing the above steps in reverse


order.


1148-10	Rubber knurl ring
1148-22	Tape
1144-12	Cover plate
	Screw
1144-15	Shutter clamp ring
	Rear lens
	- ''
1PM1.7x5	Screw
1-710490	Flexible printed
	circuit board
	Set ring unit
BT1M1.7x3	Screw
	1148-22 1144-12 1PM1.7x3.5 1144-15




Auto Bellow-E

Parts List & Repair Manual







ZENZA BRONICA		AUTO BELLOW E					
Parts No	. Name	Shape	Posper Unit	Page	Ass'y No.	Price	Remarks
部品番号	名 称	形 状	個数	Ą	組立書号	単価	備考
1-217032	Tripod plate (socket) 三种疗台						
217044	Limit plate (front) 知) 飛れる(あ)	G BROWN O					
217059	Limit plate (rear) 争,程表练为						
517060	Bellows 空之 月复						
517074	Rack axis (top) ラック連由(上)	(Martin Martin Martin 1. 1)					
511085	Rack axis (bottom) ろっり動む(下)	(American and a second					
217093	Guide axis (top) 案内軸(上)	a		•			
51,5101	Guide axis (bottom) 菜内酏(下)	6					
217113	Clamp knob フランマ) つ"		3				-
217160	Adjusting collar (right) 言句学から(右)		3				
217170	Operating axis 行動動						

ZENZA BRONICA ETR			AUTO BELLOW.E				
Parts No.	Name	Shape	Posper Unit	Page	Ass'y No.	Price	Remarks
部品番号	名 称	形状	個数	頁	組立番号	単価	備 考
ו 1 פורון 2-ו	Charge gear B イマージ転車B	40000					
217213	Charge gear D - シ島車D	00000					
217230	Charge gear B bearing 善車B軸受	800					
217240	Charge gear D bearing 占重D動質	600					
217391	Release button axis 着用之ボのと動血						
217400	Release button 着 脱ボタン	6					i
217410	Release button spring 看 胶ボタンスプッシン		:				;
217420	コードカパー Cord cover						3
217460	Synchrosocket nut B シンクロンゲルトポット B	0					
217470	Friction spring B フリクションドネB	(M))))	2				
217480	Connection base plate 塔統基核	C lies	2				

ZENZA BRONICA ETR			AL	OT (BELL	ow.	
Parts No.	Name	Shape	Posper Unit	Page	Ass'y No.	Price	Remarks
部品番号	名 称	形状	個数		組立番号	単価	億 考
1-217490	Cord-fixing plate コード 固定 木反		2				
511210	Gear B collar 歯 動 B カラー	© Z=45	5				Adj. 1-218030
217520	Gear-retaining collar 歯事押シカラー		5				
217530	Gear D cover 苗重 D 烹						
217540	Release button cover 着脱ホツン基						
217580	Rear plate 後 板						
217590	Gear A holder 萬草A夏						
217600	Gear A guide ring 勘車Aが不穏						
217610	Gear A ring 歯車A押ご環						
217631	Operating axis collar 作動が動から		5				
217640	Gear B cover 酱豆B薹	1.0.					

z	ZENZA BRONICA ETR					ω· E	
Parts No.	Name	Shape	Posper Unit	Page	Ass'y No.	Price	Remarks
部品番号	名 称	形 状	個数	頁	組立番号	単 価	備考
1-517661	Cord housing cover コード格納蓋						
217680	Tripod socket 三 科タネジ						
217630	Tripod rubber 三月むアンベム						
517710	Rack axis sleeve A ちぃり春由スツーフ゛A						
217721	Rack axis sleeve B ラック事由スッープ B	6)	3				
217731	Rack axis sleeve C ラック重由スリーブC						
217741	Guide axis sleeve A 案内軸かいる						
217751	Guide axis sleeve B 実内車ない。プ B	6	3				
217762	Guide axis sleeve C 果内軸スリープC					_	
217770	M 1.7 (small screw) M Nワピス		10				
21 77% 0	M 2 (small screw) H2ピス		පෙ				

ZENZA BRONICA ETR AUTO BELLOW E							
Parts No.	Name	Shape	Posper		Ass'y No.	Price	Remarks
部品番号	名 称	形状	個数		組立番号	単価	備考
1-217980	Connecting cord 持続用ユード						
217990	Cord tube コード チューフ"	0	2	:			
518000	Lens mount レンズマウント						
218030	Gear B collar (for adjustment) 画車Bカラー(調整用)	() +=1.0	(5)			ļ	
							·

ZENZA BRONICA ETR			υΑ	το	BELLO	, ω . <u>e</u>	
Parts No.	Name	Shape	Posper Unit	Page	Ass'y No.	Price	Remarks
部品番号	名 称	形 状	個数	頁	組立番号	単 価	備考
1-717030	Movable knob set 可動か)つ"セート		3				
717040	Charging gear A チャージ 歯車 A						
717050	Synchrosocket シェクロソケット	S.C.					
060 חוח	Housing box 特約箱						
ካነ ጎ 8 ጎ o	Release lever 春 成 レバー						
717080	Charging gear B axis チャージ 茜重 B車由						
ነ ግነግ ማዕ	Charging gear C set 4ァ-ジ茜南Cセル						
							•

Forward and backward movements are stiff (I)

Stiff rotation of rack axis (1-217082) and pinion


Loosen the set screw (1-217770) fixing the adjusting collar (#1) assembled to the movable knob (1-717030) and also loosen #1, then, if smooth movement is possible, adjust it in the following methods.

- i. The adjusting collar (#1) has its eccentric radius 0.2mm between the internal and external diameter, thus rotate #1 to the smoothly rotating position of the rack axis and pinion in arrow-mark direction, and fix with the set screw.
- ii. In order to give some proper friction to the movable knob, adjust and control the screwing degree of the screw (1-241720).

Stiff movement of guide axis (1-217101) or rack axis

Fix the rack axis sleeve B (10217721) with the set screw (1-217780). There is a slit in the guide axis sleeve B (1-217751), and put this part upside, then fix it to a position of smooth movement by adjusting the clamping degree of the set screw.

Make the similar adjustment for the main bodh of lens-side and that of the body-side.




2. Forward and backward movements are stiff (II)

When the movement is especially stiff in a state of camera-setting and winding-up position, there may be friction between the operating axis (1-217170) and charge gear B axis (1-717080) and the charge gear D (1-217213).

 Apply a high performance-lubricant on the surface of the operating axis.

Lubricant designated by Bronica: Biral VG Spray


Biral Lubricants Norway A/S



3. Control of winding range

Engagement between the charge gear C(1-717090) and charge gear D(1-217213) is done by matching each mark on threading top and bottom. Also, for mounting the gear D bearing (1-217240), fix it with the screw $(5-825507)\times 3$ to leave a little backlash between the gear C and D. The same manner is applied for the gear B bearing (1-217230).

Mount the testing instrument of winding range (CT-321) on the lens-mount, and fix it with the screw $(5-825357)\times 2$ by rotating A pin of the charge gear B axis (1-717080) and the gear B (1-217191) in order to obtain the stipulated range in winding. For the test-instument (T-321), refer to the tool-list ETR Repair Manual.





PARTS LISTS & REPAIR MANUALS

ZENZA BRONICA IND., INC.



ETR Acc'y Parts Lists


1.	AE finder (Revised)	1.
2.	Prism view finder	8.
3.	Sports finder	11.
4.	Rotary view finder	15.
5.	Lens hood	20.
6.	Professional lens hood	21.
7.	Extension tube E-14	26.
8.	Extension tube E-28	31.
9.	Extension tube E-42	36.

Note: Please place AE finder spare parts order by this revised

parts list.

AE finder parts list, and discard old version of AE finder

Printed in Japan




Z	ENZA BRONICA	etr	AE Finder						
Parts No. 部品番号	Name 名· 称	Shape 形 状	Posper Unit 個数	Page	Ass'y No. 組立書号	Price (年) 単 任	Remarks 借 考		
A220133	Eye piece frame					17			
A22015 4	Attacning metal 接統心	6600	2			18			
A220164	Eye cup A					30			
A220191	Eye piece unit attaching screw	6			·	12			
A210240	Selector dial mark	Ø,				5			
A242702	Buttom cover でルデー底のバー	213				15			
A222211	AE finder base plate AE マインダーベース					85			
A222300	AE selector dial					240			
A222311	AE selector lock button AE tp 換 D…つ ポッシ	0		:		55			
A222372	AE button cover AEバース喜ね					62			
A22235.0	AE ontact piece AEフグ 本友	•				2			

Z	ENZA BRONICA	ETR	AE	Finde	r		
Parts No. 部品書号	Name 名 称	Shape 形 状	Posper Unit	Page	Ass'y No. 組立番号	Price (羊)	Remarks 備 考
A222412	AE contact pin AE 培育ヒ°ン		9			54	
A222490	Display button out frame 表示ボタンタト杆	er				20	
A222540	Lock button spring AEtr共立へポタンオテンド	1 2				5	
Δ222641	Prism holder フペス"ムギャシギ及				·	24	
A222650	Insulating sheet AE回路絶縁レール					8	
A222660	Main circuit pillar AE 座を入へ・サー	9	4			3	
A222710	Leatherette (Front) AE hir-首小部 革					15	
Δ222720	Leatherette (Upper) AEナベー 上空P草					17	
A222730	Leatherette (Rear) AEカヅー後春					14	
Δ222740	Leatherette (Selector lock but AEtn換ボタュ草	ton)				3	
A222811	ASA dial unit attaching screw ASA ダイアルオン	©				56	

	ENZA BRONICA	ETR	AE I	Finde:	r		
Parts No. 部品番号	Name 名 称	Shape 形 状	Posper Unit 個数	Page	Ass'y No. 組立書号	Price (羊) 単 緬	Remarks 備 考
A223040	Leatherette (ASA dial unit attaching scre ASA ボウン草	.)				3	
A252004	Contact pin spring コネクターパオ	9	9			3	
A722710	SPC set (w/wire センボービット (新)					920	
A7 <i>22070</i>	Cover 語來nw~	12				45	
A722050	ASA dial unit ASA ダイアルユール					500	
A72215 0	Display button 表示ポターユニット	unit (1)				180	
A722210	ASA lock button unit ASA ローフポタンコ=					110	
A222201	AE top cover					1,200	
A7 <i>2230</i> 0	Display circuit 表不基板也小					4,640	
A722360	Display prism wr	it S.F.				1,100	
Д722250	ASA base plate u ASA ベース本をユニッ	(e 0 e)				770	

ZI	ENZA BRONICA	MR	AE	Finde	r		
Parts No. 部品番号	Name 名 称	Shape 影 状	Posper Unit 個数	Page	Ass'y No. 組立書号	(¥)	Remarks
A722460			- AX			490	備考
	AE 57ポント						
A722530	AE prism holder unit A モフロスツキギネコート					110	
A722560	AE prism set(old)					8,450	(*w/ recepter lens)
	A E フロリズムセット ()B)				·		
A722640	AE contact pin base plate AE 特集色	E SECONDARIO				50	
A722200	Main circuit					9800	
	AE回問生物も、人	***************************************			i	3000	
A722561	AE prism set (new) AEプリスン ピット(新)	***				8,200	(.w/o rr epter lena)
A722700	Main circuit (w/display circuit) AE回路曼板1-> (新))			14,500	
A222421	AE display print AE表示フ°リント	ands				75	
A223221	Prism hold spacer プリズム4甲エスペーサー		2			5	
A223270 A223280	AEP spacer I,II (adjustment) AEP Z ~ T-I,I					3	
A222760	ASA display plate	653				25	
<u> </u>	ASA 文字 板	() y					


21	ENZA BR	ONICA	ETR	1	AE	Finde	er		
Parts No. 部品番号	名	Name 称	S 形	hape 状	Pospe Unit 個 數	Lage	Ass'y No. 超立番号	Price (¥) 単 価	Remarks
A223240	ASA loc plate	k button 駅バエント			188 30		献立 書方	10	備考
:							·		
	·-· - · · ·								



Z (ENZA BRONICA	etr	Prism view finder					
Parts No. 部品番号	Name 名 称	Shape 形 状	Posper Unit 個数	Mage	Ass'y No. 組立番号	Price (¥) 単 価	Remarks 備 考	
1220012	Pinder cover							
0025	Finder base plate							
0132	Eve-piece mask 共長日民マスク		:					
0153	Attaching metal	0 0 0	2					
0164	Eye cup A							
0172	Bottom cover バース度 板							
0192	Eye-piece unit attaching screw 若眼神止*>	©		İ				
0212	2 mark 2マーファロート	D						
0230	Leatherette ファインダー 革	1						
	·							
0180	Prism cushion							

Z	ENZA BRONICA	ETR	Prism Vie	# finder		
Parts No.	Name	Shape	Posper Unit Page	Ass'y No.	Price	Remarks
部品番号	名 称	形状	個数 頁	組立番号	単 価	備考
1-720010	Prism set					,,
	プリスムセット					
	· · · · · · · · · · · · · · · · · · ·					
					i	
			,			
			 			
				_		
•						

SPORTS FINDER E





Z	ENZA BRONICA	ETR	Spor	ts fi	nder E		
Parts No. 部品番号	Name 名 称	Shape 形 状	Posper Unit 個數	Page	Ass'y No. 組立書号	Price (字) 学 価	Remarks 備 考
1-224011	harge frame フレー44(大)				"		`
4021	Middle frame						
4031	Small frame	F					
404'	Frame spring フレーム 用 バネ				,		
4051	Frame shaft cover	(
4061	Frame shaft	1					
4071	Frame shaft bearing	6000					
4081	Frame washer フレーム 育 ワッシャー	©	2				
4101	Leatherette 上种用草	The same of the sa					
4112	Finder lower plate スペンツー下ネ及		·			•	

z	ENZA BRONICA	TR	Snor	ta fi	nder E		
Parts No. 部品番号		Shape 形 状	Posper Unit 個数	Page	Ass'y No. 組立番号	Price 単 価	Remarks
1-224122	Finder upper rlate		100 100		W.T. B. A.	# 10	偏 考
	ファルダー上板						
4131	Eye-piece mount A						
	TYPマAA						
4141	Eye-piece mount B	200					
	アイピース台目	•					
4151	Eye-piece snaft				-		
	アイヒース事由		ļ				
1-724 162	Eye-piece stand	()					
 	でくピース			į			
1-224171	l f				·	,,	
	アイヒニスタバネ		-				_
	,						
4191	Eve-piece frame						
	培账 枠						
4 201	Leatherette						
	接風枯草	© 					
4 211	Lock releasing button	©					
	一年除ボタン						
1 221	Lock releasing shaft	<i>3</i>					
	口。今時所動						

Z	ENZA BRONICA	ETR	Sports fir	nder E		
Parts No. 部品書号	Name 名 称	Shape 形 状	Posper Unit 個数 頁	Ass'y No. 組立番号	Price (革) 価	Remarks 備 考
1-224231	Lock releasing shaft sleeve	6 00				
4241	Lock pin	I				
4 251	Inck plate ロック本反	600				
4261	Lock releasing plate	(b)		,		
		·				
1-220133	We-piece mask 搭配でなっ					
-251991	Spring バネ	@				

ROTARY FINDER E







Z	ENZA BRONICA	<u>TR</u>	Rotary view finder E						
Parts No.	Name	Shape	Posper Unit	Page	Ass'y No.	Price	Remarks		
部品番号	名 称	形 扶	個數	Ţ	組立書号	単価	備考		
1-221010	P-1 Priem P1フoリズム	1				ı			
1040	C-1 Eye-piece lens								
1060	Base cover								
1070	Rotary prism cover								
1080	Base frame								
1090	P-1 Prism retainer 固定プリス公特え								
1120	Waved washer ウェーブ、ワッシャー	0							
1130	Rotary plate retainer 写章对表 中入	0							
1170	Prism rotary ring タハプリズム回転台								
1180	Prism bottom holder るリズム保持下板								
1191	Prism top holder プロンズム(保持下板								

Z	ENZA BRONICA	TR	Rotar	ry vi	ew finder	E	
Parts No.	Name	Shape	Posper Unit	Page	·	Price	Remarks
部品番号	名	形 状	個 数	M	組立書号	単価	備考
1-221201	Prism retainer	8		!			
	ダハフ。リズム保持板						
1211	Eve-piece base plate						
	培眼 图 定板						<u> </u>
1221	G-2 fixing ring						
	G21F91:0.						
1240	Eye-piece ring			ı			
	接眼科B			ļ		1	
1251	Click spring						
	QU.,QZ70U±Q"	()					:
1260	Prism retainer soring	\$ m.	2				·
	タンスツズム国定スプッケ						
1270	Leatherette	(B)		!			
	ベースカバー革						
140	Prism cushion						
	のバフのスムギシ						
1410	Prism cushion						
7410	つりない打な						
1420	Rubber eye cup						
T#4.0	アイカックの多						
1430	Screw	(B)	8				
, 42 0	カバーエネン	U					

ZI	ENZA BRONICA	ETR	Rotar	y vie	w finder	E	
Parts No.	Name	Shape	Posper Unit		Ass'y No.	Price (¥)	Remarks
部品書号	名 称	形状	備数		組立書号	単価	備考
1701021	Rotary prism set						
1-721021	ロータリータンハフゃリズムた。ト			:			:
1030	Rotary base ring	((Sie)					
	国 定台						
1041	Rotary ring						
7041	回事台						
-			_				
							;
				j			

ZE	ENZA BRO	NICA	STR			Lei	е Но	bc			
Parts No.	Na			Shape		Posper Unit	Page		Price (¥)	Rema	arks
部品番号	名		形		状	個数	頁	組立番号	単価	備	考
	Lock Leve	_									
1021	POCK TieAe	r				2	İ				
	ロッフレベ										
		.									
1052	Lock leve	r Spring				2					
	ロックレバー	・ドネ	_								
1061											
1120	Retainer 1	ring					l				-
	押之疏							:	ĺ		







ZENZA BRONICA ETR Professional lens hood E Posper Parts No. Price (¥) 単 価 Name Shape Page Ass'y No. Remarks Unit 部品番号 名 状 僧 数 組立番号 Front mask 1741411 前、杨、 Base plate B 1431 基板玉 Base plate A 1.241420 集制方 Filter rest 1440 スルター特 Moving stand 1452 合煙石 Rack 1463 5) - Mir Guide shaft, 1473 每四种 Restriction plate 1480 有いな 事疾 Pinion 1491

Z	ENZA BRONICA	AR.	Prof	essio	nal lens	hood E	
Parts No. 都品番号	Name 名 称	Shape 影 状	Posper Unit 個数	Page	Ass'y No. 組立番号	Price (¥) 単 値	Remarks 備 考
1-241500	Secentric collor	6	2				
1510	Moving stand bearing 可動心難意	5	2				
1520	Set knob 写 強っほりブ						
1531	Clamp knob				,		
1540	Knob stopper ノブストッパ ⁰ ー	· (@					
1550	Spring vin スプリング ピ [®] ン			!			
1560	Hood bellow 虫心 液						
1571	Mask guide がイドレーヤン	<u> </u>	2				
1581	Auxiliary plate (left) 活动 (注: 本族(先)						
1590	Screw がイドレーいではす	©	6				
1600	Auxiliary plate (right) 清酢 壁か 木彫(た)						·

Z	ENZA BRONICA	ETR	Profe	ession	al lens h	ood E	
Parts No.	Name 名 称	Shape 形 状	Posper Unit 個数	Page	Ass'y No. 組立書号	Price (¥)	Remarks 備 考
1-241633	Screw राज विक् प्रति, विकृति	O *	2				
1642	Screw 作礼 Ho for	· •	2				
1671	Adaptor ring gro	nve					
1702	Adaptor fixing r	ing					
1711	Adaptor ring fixing knob dowel						
1722	School 100	9					
1730	Friction spring	9					
1740	Steel ball	. 0					

ZE	NZA BRONICA	ETR	Prof	essio	nal lens l	hood E	
Parts No.	Name	Shape	Posper Unit		Ass'y No.	Price (¥)	Remarks
部品番号	名 称	影 扶	倒数		組立番号	単価	備考
	Set screw						
1-217780		333	2				
	MIZ. CILER		-				
		F					
	<u> </u>						
1-113110	Leatherette	60	2		,		
,,,,,,,,,	革						
							<u> </u>
1-236020	Name plate	ETRI					
	文字板						
1361070	Leatherette						
1-261970	華						
						· · · · · · · · ·	
					.		







Z	ENZA BRONICA	ETR	Exte	neion	Tube E-14		
Parts No. 部品書号	Name 名 称	Shape 影 状	Posper Unit	Page	Ass'y No. 組立番号	Price (¥)	Remarks 備 考
1-281010		0					
1020	の下蔵 E-14 Lens mount Uコズマウント						E-28 E-42
1030	Bayonet ring A バヨネット A						
1060	Operating barrel A イを動わりとで 動わA	0					
1070	Steel ball retainer A ホールギネシA						
1110	Lens lock pin A レンズロ…うピン A						
1230	Lens release button A Lンズ基脱ポタンA	000					
1351	Drive beareing metal A 配動後全身 A	P					
1360	Restrict metal 着脫楔正板	600					E-28 E-42
1370	book pawl ロックベギ	60"	2				
1380	Lock metal						E-28 E-42

ZENZA BRONICA ETR Extension Tube E-14 Posper Parts No. Name Shape Page Ass'y No. Price Remarks Unit 部品書号 名 貅 形 状 無数 頁 組立書号 単 循 S. driving metal E-28 spring 1-281390 E-42 2 **@** 5 駆動全気バネ Safety link spring A 1400 OMO 毎宝5つドネ A Steel ball spacer E-28 1210101 11 E-42 术儿支持强 Lock plate screw 0202 Ø, ロックオ反動 Lock plate 0212 かかれ Spring pawl 0221 OD. ロいつ板の料 Lock plate spring 0233 ロック オをスプリング Bayonet index 0240 0 17日本人琉璃梅 Contacts insulating plate 1-710250 据片绝缘板

z	ENZA BRONICA	etr	Exte	naion	Tube E-1	4	
Parts No.	Name	Shape	Posper Unit	Page	Ass'y No.	Price	Remarks
部品書号	名 称	形状	個數	X	組立番号	半価	個考
1-781040	Rear cover A						
	後校 A						
1050	Front cover A						!
			 				
1130	Lock release plate	-8				İ	
	D-7解標板 A						
1150	Release lever						E-28 E-42
	着敗い~						
1180	Operating ring cover A						-
1100	が事かりょかわに A]	
1240	Operating ring A (front)		-				
1240	〈を勢かりこか A (前の)						
1260	S. driving metal A						
_	5 配勁電度A						j
1330	Operating ring A (rear)						
	5年をかり> 0°A(1本)						
1601	Lens connector set	Self.					
	レンズフラ へな - RLA						
							İ







	ZENZA BRONICA ETR				Extension Tube E-28					
Parts No部品番号	1.5	Shape 形 状	Pospe Unit	Page	Ass'y No. 組立書号	Price (¥)	Remark			
1-282011	Tube E-28 barrel			 		- " -				
·	外筒 E-28									
2020	Bayonet ring B-C						E-42			
	ドヨれトBC									
2050	Operating barrel B									
	うを参かいが 草田 B									
206 0	Steel ball retainer									
_ 	ホール押をB									
2100	Lens lock pin B-C						E-42			
	レスロッピリルと	o D								
2130	Relacse plate bearing	©					E-42			
	解除杨勒曼	رگيري								
2140	Collor B-C	•					E-42			
	しにーアングルカラー おに	⑤	2							
2180	Lens release pin B	7073								
	いる春成也には									
2220	Operating ring B (rear)									
	5年年かり20°B(18)									
2231	Set bearing metal B-C	2				E	-42			
	CL有食息 B.C	6					ļ			
2241	Drive bearing metal B-C	(A)				E	-42			
	型物专家enc	(e)								

Z	ENZA BRON	IICA E	TTR	E	octen	sion	Tube E-	28	
Parts No. 部品書号	Nam 名	称	Shape 形		Caper Unit 圖数	Page	Ass'y No 組立書	(¥)	Remarks 備 考
1-782030	Hear cover								E-42
2040	物板BC Front cove								E-42
2110	Lock releas B+C 口、分解除末				į				E-42
2150	Operating r cover set E 冬を養わりより"れい	3				į		. :	
2190	Operating r B-C S生物トロンリ"も								E-42
2200	S. driving R-() S配動全員		1						E-42
2600	Lens connec		到一种	ķ					
					İ		-		

ET'R Extension Tube 8-28 ZENZA BRONICA Posper Parts No. Name Shape Page Ass'y No. Price Remarks Unit 部品番号 名 貅 形 状 個数 夏 組立書号 Restrict metal nut E-42 1.282250 2 **(**) 機正板ホト Safety link spring E-42 2260 DMD) 安全リンプドネ 日亡 Release restriction 2330 nin B 着股制限 🗠 B Spring E-42 1-253920 (M) スプリング



E-42



ZENZA BRONICA Extension Tube E-42 Posper. Parts No. Name Shape Page Ass'y No. Price Remarks Unit (¥) 単 価 都品番号 名 形 状 倒数 Ţ 組立書号 考 Operating ring cover B-C 1-783060 くを多かりょう カベーセート C Lens connector 3600 set C レンズコネクターセット C Tube E-42 barrel 1-283011 94.3 总化 Operating barrel C 3020 作動いいが動し Steel ball retainer 3030 ホールコアをC Lens release vin C 3050 レンズ 養 膜ボタンと Operating ring C 3060 (rear) 作動いごでは Release restriction 3130 pin C 表胶钠阻贮口

ETP

Z	ENZA BRONICA ET	R	Came	ra b	ody	 	
Parts No. 部品番号	Name 名 称	Shape 形 状	Posper Unit 個数	Page	Ass'y No. 組立番号	Price (¥) 単価	Remark
1-050032	Set lever shaft	A A	1 APP 1 35%	Ą	租业储分	単 価 80	
0053	F-release pin sleeve					25	
0063	下解所ピンスラープ Finder lock bearing アインシーロック事項					50	<u>-</u>
0091	Finder lock stud ファルケーロップを受柱	©				10	
0 10 2	Release lever axle	6 <u> </u>				20	
,112	Fottom cover atud 商業 更に作事。	<u>6</u>	3			15	
							· · · · · · · · · · · · · · · · · · ·
0132	Release relay lever axle	6 1				20	

ZENZA BRONICA ETR Camera body

Parts No.	Name	Shape	Posper Unit	Page	Ass'y No.	Price	Remarks
部品番号	名 称	形 扶	個数	頁	組立番号	単価	備考
1-250161	Dark slide relay lever axle					15	
	31 蓋中級八二事						· -··
0182	Release link spring holder	8 D=				5	
0191	多院D・ハドキ指k Connecting key					5	
,.	spring holder		2			,	
0203	Dark slide pin sleeve					15	
	31 麦麦季的ピースリーフ"						
0212	M switch lever axle	F		-		15	
	アイスハグレルー・動	F					
	M switch lever spring holder	.				5	
	Mスからい-ドネ珠し						_
0231	M switch link spring holder					5	
	M スペラッショバネギト						
0251	Mirror arm axle (left)					70	
	ニラーアーの見由さり		 				
0271	Pinder look spring	t i				20	
	1 4 5 V 4 T 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1						
0280	Sleeve set screw	Org	2			7	
	スルッキピス	- 			ļ		

ZE	ENZA BRONICA	TR	Cam	era b	ody		
Parts No. 部品番号	Name 名 称	Shape 形 状	Posper Unit 個数	Page	Ass'y No. 組立番号	Price	Remarks 備 考
1-251152						450	
1164	Hear light-tight frame 後面應先壁					250	
1210	Light-tight plate axle	D	2		1-751100		
1221	Light-tight plate arm 売 光 年及マーム					35	
				1			
1243	Roller axle 更も初た4月10日由					10	
1270	M guide roller ミラーガイトコウム	•	2			10	
1280	M arm screw (left)	Fur				10	
1290	光 stopper	V.				50	
1311	R adjusting collar	9				25	
1521	Radjusting axle	θ_{xy}				7	

 E^{TR} Camera body ZENZA BRONICA Pos.per Page Price Remarks Parts No. Name Shape Ass'y No. Unit (¥) 単 価 部品番号 名 称 形 個数 頁 組立番号 * 状 3-251460 % arm screw (right) OF S 2 ミラッナームエネジはい 1471 M arm adjusting cam (3) シラーマーム調整から 1501 Operating plate set roller 10 \mathcal{Q} 作動ななしような 1511 operating plate 1-751200 8 roller **@** 2 作動物自己 1561 | Set lever screw 6 セルレバーエオジ 1571 Operating plate stud 6 63 化動物受盐 1581 Bottom light-tight 90 plate 直面惡光板 1601 Cheratina ring 35 spring (right) 化垂からずいず(右) .693 M driving lever 50 spring ミラー無記事のレベードは melease return 1622 20 spring

いいつズ 戻しバネ

Zi	ENZA BRONICA	ETR	Came	era b	ody		
Parts No. 部品番号	Name 名 称	Shape 形 状	Posper Unit 個数	Page	Ass'y No. 組立番号	Price (¥) 単 価	Remarks 備 考
1-251631	Release relay spring レリース" 本糸性 バネ	College	·			15	
1641	Set screw 作動する 西でオン	3			1-751200	15	
1682	Light baffle cover 適比かパー	Est.				40	
1693	Light baffle cover screw 逸 だかい - 取行ネジ					20	
1700	M adjust 0-ring	•				20	
1710	M stopper screw	Φ	2			5	
1740	Adjust cam set screw	Alle				1)	<u> </u>
1751	Sittor holder (right)					15	
1761	Mirror holder (left) ミラーコ等之本及(左)					15	

ZE	ENZA BRONICA	ra	-	Came	era b	ody		
Parts No. 部品番号	Name 名 称	Shape 形	· ·	Posper Unit 個数	Page 頁	Ass'y No. 組立書号	Price (¥) 単 価	Remarks 備 考
1-251800	Frame metal (left)	-	6				55	
	後面患光壁座(左)	6						
1810	Frame metal (right)	6	(6)				55	
·	後回連先壁座(石)	(E)						
1822	Spring						10	
	遠光板甲ドネ	V6						
1840	Light baffle arm roller D	0				-	10	adj. 1-251231
	悲光板下435D		Ø3.5					
1860	Light baffle arm roller E 逸光*&で-4 3つ E	© :	ø3.3				10	adj. 1-251231
						<u>.</u> .		
								,
		<u></u>						

---- 6 ----

Name 名 林 set screw っきれてマーエネン ing collar	Shape 形 状	Posper Unit 個数	Page	Ass'y No. 組立番号 1-752010	Price (¥) 価	用ema	arks 考
set screw うちゅう はっとう はっとう はっとう はっとう はっとう はっとう はっとう はっと	Min.	West SQX	Ą		#* 1m	198	· 考
ing collar	D			1-752010			
ing collar たパネカラー	3				! I		
たいご オカラー	(3)		i İ				
	. 9			11			
e connector		3		1-754200			
13779-					ļ		
ector cover	Si			1-754200			
ソターカバー							
s mount	6				3,500		
Ŀマウント -							
net stopper pin	8				10		
ネットストッパピピン							
ating spring er (right)					6		
サバネ 特に(た)							
ating spring er (left)					6		
m ((注持)(左)				ľ	ĺ		
tton stopper					5		
ウニ <u>す</u> カック。	15						
tton ring E					140		
ゖーポタッングB	WC .						
		T .					
	コマウント net stopper pin ネ, Lストゥハッピー ating spring er (right) カバネ 若 L(た) ating spring er (left) たい スキレ(た) tton stopper	met stopper pin 未, Lストットゥピーン ating spring er (right) 本 ド ネ 技 L (左) ating spring er (left) tton stopper () 生 リンプ tton ring E	met stopper pin 未, Lストットゥピュー ating spring er (right) 本 が 注 L(を) ating spring er (left) な は は は は は は は な な な な な な な な な な な	met stopper pin 未, Lストゥハゥヒゥニ ating spring er (right) ホバネはL(た) ating spring er (left) tton stopper	met stopper pin オュレストゥルゥヒゥニ ating spring er (right) カルドオ だし(た) ating spring er (left) たい オ はし(た) tton stopper	net stopper pin 10 元 L Z L C N C L C C C C C C C C C C C C C C C	net stopper pin 10

ZE	ENZA BRONICA E	TR	Camera b	ody		
Parts No. 部品番号	Name 名 称	Shape 形 状	Posper Unit 個数頁	Ass'y No. 組立番号	Price (¥) 単 価	Remarks 備考
1-252294	Lens release button				20	
2309	Lens button ring				180	
2312	S latch spring S 特人全バネ	20		1-752090	20	
2343	S button lock click ボタンロックフリック	60			15	
2370	S release link			1-752090	10	
2380	Release link set, screw	Ø.		1-752090	10	
		-				
2451	Operating ring stopper 不をきりいプストルペ	Co e			20	

Z	ENZA BRONICA	ETR	Çam	era bo	мy		
Parts No. 部品番号	Name 名 称	Shape 形 状	Pos.per Unit 個数	Page	Ass'y No. 組立番号	Price (¥) 単価	Remarks 備 考
1-252515	Light-baffle frame 画面患艺核		•			110	.
2522)	,		200	
2532		St. Contraction of the state of				50	
2603	Top frame light baffle	Ser Ser Ser Ser Ser Ser Ser Ser Ser Ser	2		,	60	<u>-</u>
2612	Focusing screen guide stud		2			15	·
2641	Screen holder puide 焦実板特えザイド	\$	2			15	
2651	Back coupling spring	- 12 B				50	
2662	AE connector set screw AE 3オフラー生ネジ	(III)				10	
2671	Back counling spring retainer Noon続色N*オ母女オ本	6				30	

Z	NZA BRONICA	ETR		Came	ra bo	ody			_
Parts No. 部品番号	Name 名 報	· 元	Shape 状	Posper Unit 個数	Page	Ass'y No. 組立番号	Price (¥) 曲	Remark 備	ks 考
1-252711	Finder mounti	ng claw		2		1-755200	15		
	プルダー結合	<u>بر</u>	9	 					
2722	Finder mount spring (left) フッインダー統合パ	के(क्रा	13			11	30		
2730	Finder mounting spring (right ファム・ダー 急を合ド)]	000			11	30		
									_
									_
2790	Adjusting liner		5	2			30		
2800	: 		<u>t0.35</u>	 					_
	4	<	t0.2						
2810	"		5						
2026	•		to./						
2820	"	<\s\f	tc.08						_
2830	U	্ঠ	to.es						
									_

Z	ENZA BRONICA	TR	Came	ra boo	dy			
Parts No. 部品番号	Name 名 称	Shape	Posper Unit	Page	Ass'y No.	Price (¥)	Rema	ırk
I-253061		* *	個 数	T T	組立番号	學 個	備	
3074	Battery chamber cover					40		
3141	Back coupling claw		2			35		_
3151	Coupling claw guide	©	4			15		
3161	Eack coupling link バック書 脱りょう	Ment ref				50	- <u>-u</u> .	
³ 181	Dark slide connecting pin 引基連動ビン					20	-	
3210	lafet: lever holder 引蓋中継いで一种心					45		
3221	Dark sline safety latch 引基安全特金	B S				30	•	
3231	Safety latch axla 引蓋安全特全軸	Œ F				10		_

	INZA BRUNICA			,	·		
Parts No. 部品番号	Name 名 称	Shape 影 状	Posper Unit 個数	Page	Ass'y No. 組立番号	Price (¥) 単 価	Remarks 備 考
*/~3240	Speed-grin shutter release rod 逸い-ス特	6.55ED	-			60	
3252	MD connector cover					15	
3270	Tripod socket (†n screw) 三 門和オン			· · · · · · · · · · · · · · · · · · ·	1-755330	120	
3281	Tripod mounting shoe					150	
3293	Battery chamber bottom plate 記述ボックス店存				į	20	
3332	Back coupling link guide だった着用たりょうせんご	#				10	- W
4440	Link collar バック 着脱コーフカラー	9				10	
3350	Battery chamber button spring	C DDDDD				10	
4342	Dark slide safety lever spring ら 基合全レバードネ	9*				10	
3371	Release relay lever	É				10	

Camera body

ZENZA BRONICA

Z	ENZA BRONICA	ETR	Самес	a body		
Parts No. 部品番号	Name 名 称	Shape 形 状	Posper Unit 個数	Page Ass'y No	(*)	Remarks
1=253380	M. switch lever apring Mスックレバードネ				15	· 備 考
3390	Back coupling claw spring	3	2		20	
3401	Back coupling link spring バック高戦リンプバネ	S			10	
3411	Operating ring spring イキをカッシウェバネ	CONTRACTOR C		1-752010	30	·
3421	Lens button safety lever レンズ 金の 谷全レバー				15	
3431	Safety lever axle レンズ 包む容生レバー 動象	P			10	
	M. switch link spring M スペケッンフドオ	COMMIC			15	

ZENZA BRONICA	ЕТи	Camera ecoy

Parts No.	Name	Shape	Posper Unit	Page	Ass'y No.	Price	Remarks
部品番号	名 赫	影 状	個数	頁	組立番号	単価	備考
1-255629	Safety look plate	206				20	
	安全のの受極						
3632	Safety look spring					10	
	レンズ 安全 ロック ドオ						
3704	Shutter speed dial					250	
3713	S. dial lens		-			30	
 	らずイア心管・	A					
3725	AE switch cover					20	
	Aモスかかがー	46				!	
3751	M. switch link guide	₩	2		(8	-
	Mスペチリンクサイド	G			•		
3772	AF changeover rod guide	5W				20	
	AE切換機だれ	9 20		ĺ			
⁴ 782	Switch cover stud A	60	2			15	
	スルチカバー社A						
₹/91	Switch cover stud B					15	
i	スかみかだっ枝B						
3810	Switch lever axle	P				10	
	Aモスからいー軸	U					

Z	ENZA BRONICA	ETR	Came	era b	ody		
Parts No. 部品番号	Name 名 称	Shape 形 状	Posper Unit 個数	Page	Ass'y No. 組立番号	Price (¥) 単 価	Remarks
1=253900	Wire holder	@a		-	wer are see. A	10	備 考
	よれまる。酒		2	į			
<u>39</u> 20	AE changeover rod spring	8				6	_
- <u>-</u>	AE切換構ドネ						
				_			
3951	Lens safety link guide レンス 安全 ツンラガイギ	5				15	
3960	L. button safety link					40	
	レングボタン安全りンク						
	· · · · · · · · · · · · · · · · · · ·						
4012	lens button ring						
4049	Lens button sleeve	A					
\$ 069	Button look soring	**				10	
16:00	レンズボタンロックドオ						
40.80	Lens release but+no レンス 序译 PR ボッタン						
			-				

ZENZA BRONICA ETR Camera boxiy Parts No. Name Shape Posper Page Ass'y No. Price Remerks										
Parts No.	Name	Shape	Posper Unit	Page	Ass'y No.	Price (≆) 単 価	Remark			
部品番号	名 称	形 状	個數	頁	組立番号	単一価	備え			
*-254471	F. release plate collar (upper)	6	2		1-753500	10	:			
4500	F. lever upper equing 日合在P市レバーエバネ	c empro			"	20	<u> </u>			
4541	F. lever lower spring 日色倫 レベー下 バオ	Q			11	ń				
4710	Stormer screw				10	5	.			
	ストッパーキン									
4751	Holding claw spring	CATURAL			н	20				
- - -	下解除、保持心心之									
4790	Upper plate spring	O TOTAL				15				
	下解除板上心子	~				į				
4830	Release plate roller	6	4		н	8				
	奔除核 10	_								
4841	F. release plate	a	2		+1	10				
	解除板 55-1下)									
4852	F. release plate	6	2		11	10				
	谷森 P年、オ阪カラー(上)									
4873	f. release lever axle (upper)	€ P			н	10				
	戸鮮除い(一動(生)	•								
4881	F. release lever	a			11	10				
	下解除小"事的(下)			-						

ZENZA BRONICA ETR Camera body										
Parts No.	1.1.1.1	Shape 形 :	Posper Unit 大 個数	Page	Ass'y No. 組立番号	Price (¥) 填	Remarks 備 考			
1+254892	Winding safety leve: spring 下地に安全レバーバオ				1-753500		, , , , , , , , , , , , , , , , , , ,			
4911	F. release pin					15				
4930	Winding safety lever (upper) F 推上安全レバー(生)				1-753500	25				
4941	Safety lever collar 戸地上寄生レバーカラー	D			11	10	<u>, </u>			
4953	Safety lever upper spring ト権上容全レバー上バネ	L			38	15				

Z	ENZA BRONICA	ETR	Саме	era bo	ody		
Parts No. 部品番号	Name 名 称	Shape 形 状	Posper Unit 個数	Page	Ass'y No. 組立番号	Price (¥) 重	Remarks 備 考
1-255051	Right cover setting stud 右カベー写え付 ギュネン						
5161	Winding main shaft 地上主動				1-753100	80	
5170	Winding cam washer 地上为4座全	0			11	5	
5221	Cam spring holder	₩.			1-753190 1-753100	5	
5230	Cam holding nut				1-753100	15	
5292	Multi-relay lever screw マルイ中急性レバー 北キン	(Secured)			It	15	
5350	Release safety lever (upper) レリース安全レバー(生)				1-753100	20	
5362	Upper safety lever axle 安全しい~(上) 生	6)			п	10	
5371	Multi lever axle マルチレバー連				el		
5402	Setting screw マルチセルトレバー止オジ	∅ *			er .	8	į

Z	ENZA BRONICA	eth [Cane	Camera body						
Parts No. 部品番号	Name 名 称	Shape 影	Posper Unit 個数	Page	Ass'y No. 組立番号	Price (¥) 単 価	Remarks 備 津			
1-255432	Transmission gear 中間数章	The County of th			1-753100					
5440	Connecting gear	STOCK ASSESSED			11	210				
5451	Gear arm collar				11	10				
5462	Connecting gear arm (upper)				P5	20				
5471	Gear arm screw ボヤーアーム 生 オジ	8			it.	10				
5482	Release safety cam いっズ 安全カム	(B)			н	80				
5490	Winding main gear				11	380				
5500 ·	Winding ratchet				**	120				
	H everse stonping claw	(3)				8				
	Main shaft cap				79	50	.			
	Main shaft set screw 主動止オジ	OL.			n	25				

Z	ENZA BRONICA	TTR	Camer	ra bo	d _. y		
Parts No. 部品番号	Name 名 称	Shape 彩 状	Pos.per Unit 個数	Page 頁	Ass'y No. 組立番号	Price /Y) 単 個	Remarks 備 考
	Set cam liner セットヤムライナー	0			1-753100		713
5760	Connecting gear screw 建純ギャー生オジ	Om			rı.	6	
5790	Winding stopper claw spring holder 性止化ドオ特心	© P			1-753100		
5822	Reverse stop claw screw 女主なよべオジ	Ø₽	2		н	6	
5830	Gear friction spring			·	tt ,	15	
5842	Winding stopper lever spring 性止レバードネ	7			10	15	
5852	ficar arm spring 連続ギャーマー4パネ	O TOTAL			11	15	
* # 6 4	Winding stopper claw spring 地上和以子	6			н	15	
587 1	Auxiliary plate apring 充止体的 核ドネ	ê			1-753190 1-753100	30	
न्त ⊹कृदे∜			2				

Z	ENZA BRONICA	ETA	Came	ra bo	ody			
Parts No. 部品番号		Shape 形 状	Posper Unit 個数	Page	Ass'y No. 組立番号	Price (¥) 単 価	Rem 備	marks 考
1~?55890	Heverse stop claw spring 連転比にいう	`			1-753100	20		
5903	Multi link spring	Of The State of th			11	15		
5912	Safety lever (upper) apring 谷全レバー(上)バネ	6,			II .	10		
5922	Multi-operating lever spring マルカケを使わレバードネ	6			BY	10	-	<u></u>
5930	Main shaft thrust washer A	0			11	5		•
5940	Main shaft thrust washer B 主動スラストワッシュー B	0			н	5		•
5950	Spring washer 主軸止ドオ座宝	9			11	5	-	
5960 5970	Main shaft washer A Main shaft washer B 全 動 神之及金 A	0			н	5		
5990	Connecting gear stopper 連続ギャーストッパー	®			*1			

Z	ENZA BRONICA	ETR	Camer	ra bo	Зу		
Parts No. 部品番号	Name 名 称	Shape 影 状	Posper Unit 個数	Page 頁	Ass'y No. 組立番号	Price (¥) 単 価	Remarks 備 考
	Nulti exposure tever	O CO				öU .	
6111	Multi lever ring マルイレバーリング					15	
6150	Name plate カォラ 全名 木友。	W TR		-		40	
6202	near light tight plate 杏面應光板					120	
							_

Z	ENZA	BRON	CA	ETR			Came	ra bo	эdу			
Parts No. 部品番号	名	Name	称	, ,	Shape	· ·	Posper Unit 個数	Page	Ass'y No. 組立番号	Price (¥) 婚	Rem	arks 考
1-256610		releas			0					10		•
6661 9031	S. di	al cove	r (W)		0				1-755500 1-755550	150 200		
	•	al stop			M F ^m	•			1-755500	8		
											•••	
											· <u> </u>	 i
											-	

Z I	ZENZA BRONICA ETR Camera body							
Parts No. 部品番号	Name 名 称	Shape 形 状	Pos.per Unit 個数	Page	Ass'y No. 組立番号	Price (¥) 単 価	Remarks 備 考	
1-257002	Leatherette (right-front) 右カバー草(苦ロ)	To Date of				30		
7010	Leatheratte (right-rear) 右カドー革(後・上)					10		
7020	Leatherette (rear-lower) 右加"-草(後南)					10		
7032	Leatherette (multi-lever link) マルチレバー ツンつ 草	0				10		
7040	Crank base cover クランコ座化粧板		2			60		
7050	Leatherette (left cover) 左bw-革	5 60			1-755500	40		
7060	Leatherette (S. dial cap) らないで		2			10		
		· .						

ZI	ZENZA BRONICA ETR Camera body								
Parts No. 部品番号	Name 名 称	Shape 形 #	Pos.per Unit 相数	Page	Ass'y No. 組立番号	Price 单 ^{¥)} 価	Remarks 備 考		
1-257101	Light baffle pap (right-front) 惠光&は(右衛)	er 🔙	7			50			
7112	Light baffle pap (right-rear) 速光紅(去後)	er				30			
7121	Light baffle pap (right-center) 趣光紙(私中)	er O			1-751200	15			
7141	Light baffle pap (left-front) 速光紙(失聲)	er &	\			40			
7152	Light baffle pape (left-rear) 速光級(左格)	er P				20			
	Bottom light baff (front) 应色表光知(前)	Tle				20			
7171	Bottom light baff (rear) 店面惠公知(物)	Tle	>			25	· · · · · · · · · · · · · · · · ·		
7250	ear light boffle 後面恋光幕					30			

ZE	ENZA BRONICA					
Parts No.	Name	Shape	Posper Unit Pag	ge Ass'y No.	Price	Remarks
部品番号	名 称	形状	個数頁			備考
	1 1 					
	<u> </u>		<u> </u>	<u> </u>		
				•		
			<u> </u>			
	•					
				-		
		i				
			1			
	•					
······· †	· · · · · · · · · · · · · · · · · · ·	-				
				:		
			<u>.</u>			
	•					
	•					
ĺ		1	1 1	I	1 1	

Z	ZENZA BRONICA ETH			Camera body (Ass'y)					
Parts No. 部品番号	Name 名 称	Shape 形 状	Pesper Unit 個数	Page	Ass'y No. 組立番号	Price (¥) 単 価	Remarks 備考		
104.30	Finderlock pin	9			W. 22 W. V	25			
	カイ・ダー解除ピン								
5040	Dark slide safety lever	8				50			
	31董安全中继 LN"一								
0050	Flash synch socket	 ©)\(\)	 	į		210			
<u> </u> 	シンクロッケー						<u>_</u> .l		
0060	M switch lever	5000				80			
<u></u>	M スィッチレバー								
9070	M switch link	000				40			
	M スペッチ リンク				į				
080	ÁE switch lever					50			
	AE スィッチレバー	3							
0090	Helease relay lever					85			
	レリーズ 中冬港レバー	9 1				ļ			
10]0	hirror frame set					950			
· -	ミラー枠 , ta					İ			
1100	Light-tight frame					580	}		
	遮光板机								
1170	M guide plate fright	(See			,	45			
	州作動畫板(名)								
i 160	Il guide plate (left)					45			
	M作動溝板(左)								

ZI	ZENZA BRONICA				Camera body (Ass'y)				
Parts No.	Name	Shape	Posper Unit	Page	Ass'y No.	Price	Remarks		
部品書号	名 称	形状	個数	頁	組立番号	(¥) (¥)	備考		
1-751200	M driving unit	220				520			
	ミラー東記動・ユニット		<u> </u>						
1230	M driving lever	§ 72			1-751200	80			
ļ	ミラー無理動ルバー		<u> </u>						
1250	M operating plate set				н	80			
	55-作動板			 					
1260	Set lever	0 33				150			
	セットハバー								
1290	Release button set					460			
	らボタンセート	1							
2010	Shutter operating ring unit					1,350			
2060 2510	Front cover (W)	TO TO				650			
	前カバー (色) (景.)								
5030	3 latch set					180			
	の抽金を板だか								
2100	S latch base				1-752090	50			
	S掛金受板	(82)							
2110	S latch	9			н	eo			
	全様名		a						
2120	ens release unit								
	012省版二二、	Country of							

	ENZA	BRONICA	ETR	Came	ra bo	dy (Ass	'y)	
Parts No. 部品番号	名	Name 称	Shape 形 状	Posper Unit 個数	Page	Ass'y No. 組立番号	Price (¥) 単 価	Remarks 備 考
1-752130	Lens	eafety lock	5/				45	
·	レンズ	安全ロック	21					
3100	Wind	ing unit					2,600	-
-	捷上	や板ユニット		ļ	i			
3130		rse stop claw t set				1-753100	30	
	走転	- 一						
3170	Wind	ing wheel set				11	300	
···· ,—	推上	· 學倫						
3190	Setti	ng cam unit				н	260	
	セット	カムユ <u>ニット</u>						1
3220	Windi lever 花止		33			97	60	
3230		-relay lever	O'S			n	40	
3240	Multi lever	operating	a rec			10	30	
		-set leve-	3		_	it .	25	
	< (\ 	シャレハー						
	9₽t	base casting					480	
	Pilm w	uinding crank ack)					650	
4	色上つ	ラング(第1)						

ZENZA BRONICA

ETR

Camera body (Assly)

Parts No.	Name	Shape	Posper Unit	Page	· .	Price (¥)	Remarks
部品番号	名	形 状	個数	頁	組立番号	単価	備考
1-753340	Crank ring set					≥50	
· ·	25:33:3 bok		<u> </u>	<u> </u>			
3500						1,000	
		0					
3520	F release lever (upper)				1-753500	30	
İ	下解院(パー(エ)	₽					
3530	F release lever (lower)	&			n.	40	
	日産体 >バ~ (た)			_			
3550	F release plate (lower) 三年時末版(下)	CONTRACTOR OF THE PARTY OF THE			"	60	
3570	F release holding · claw				n	50	
₹ 5 90	F release plate (upper) 日経院末成(上)				11	60	
4600	Winding safety Paver 产丼上安全レバー(下)	हर् <i>व</i>			It	50	
* ****							
			<u> </u>				
							:
						İ	

ZE	ENZA BRONICA	T'R	Camera body (Ass'v)					
Parts No. 部品番号	Name 名 称	Shape 形 状	Posper Unit 個数	Page 頁	Ass'y No. 組立番号	Price (¥) 単 仮	Remarks 備 考	
1-754100	Shutter circuit					3,000		
	シャッター回路ユニット						,	
4120	AE changeover rod					40		
	AEt) 授 桿	P						
4130	Checker contact	(3)				45		
	チェッカー接受台						- 	
4200	Lens connector set	25000		:		. 770		
	プレス 3才28~セット	62						
4 300 4 300	AE connector set	150				400		
:	AGロネフターセット							
4400	Battery chamber					350		
·~	動地ボッフスセット							
4500	M switch set					800		
	M みかせらり							
5200	Top frame					950		
	上井もい	*2000°						
528 0	Pocusing screen holder	,00>				35		
	農気福力	9						
5310	Release lever					70		
	レリース レバー	9					· · · · · · · · · · · · · · · · · · ·	
				ļ	;			
						i		

ZE	NZA BRONICA	ZTR.	Can	era l	oody (Ass	(*y)	
Parts No. 部品番号	Name 名 称	Shape 形 壮	Pos.per Unit 個数	Fage	Ass'y No. 組立番号	Price (¥) 単価	Remarks 備 考
	Hight side cover set " (black) 右カベーセル(意)					850	****
5500 5550	Left side cover set " (black)		:			1,700	
5530	S dial cap るのイアル基	0			······ -	40 0	
55 7 G	S dial knob	(olive)				210	
	R. light-tight plate 左應是板	(ero)				65	
2070	性形形成 Front cover connection plate (right)	NB James					. • • • • • • • • • • • • • • • • • • •
·	前·467-原。但才及 体。		ļ -				
2086	Front cover connection plate (left) 節 かは、語っくで まわけない	AK.					
y-6a	Lens button took						
5330	Bottom cover set					1,200	
					-		

ZE	ENZA BRONICA	ra	Film	back			
Parts No.	Name	Shape	Posper Unit	Page		Price (Y)	Remarks
部品番号	名	形 状	個数	K	組立番号	単一価	備考
4040094	Pilm type indicator Crame インデックス入れ。	Grade CTP			1-761210	25	
0031	Indicator frame base インデックス入れ省	و د د د د د د د د د د د د د د د د د د د			1-761210	45	
0123	Light baffle	r 28 →	2				
	バックモルトプレンス	,				1	
0171	Rear cover leatherette 後蓋革					90	
	12 12 7		 				
0182	Light baffle	€ 73 -→	2				
	後蓋モルトプレン	·					
0200	Light baffle	- 100	2				
0312	Spool holder lock	6				15	
	スプールゼロック	60					
i) 4 3 2	Spool holder base	Se Constitution of the Con				90	
	スプール受査	0					
0541	Base fixing plate					50	
	スプール受押も						
0352	Spool holder spring	0				10	
	スプール受力で	7.4				ŀ	

Z!	ENZA BRONICA	TR	1. 2. 244	hack	·		т.
Parts No. 部品番号	Name 名 称	Shape 形 状	Posper Unit 個数	Page 頁	Ass'y No. 組立番号	Price (¥) 単 価	Remark 備 ≉
-2603-52	Sport holder	712			,		1760
-20075	auxiliary plate	~6	2		1-763400	20	
		5					
	スアール受補的状		<u> </u>	 			
0372	120 film indicator						
	plate			i		40	
	新 · 民 (120)	•					
			† 				
0382	Spool holder base pin	The same of the sa	2		•	10	
	スプール受産時						
	X 1-10 X 4 3-11	<u> </u>					
0411	Spool holder collar	65	2		1-763400		
		(3)				ļ	
	スプールグカラー		ļ				
0452	Pressure plate (120)	Description 0				51 0	
04)2	Treasure prace (120)					710	
	尼枝(120)	•					
0463	Pressure plate pin		2			40	
0407	product product production	6	-			40	
	左移動						
0471	Pressure plate spring					20	
	i						
	正核八字		ļ <u>i</u>				<u> </u>
					ļ		
i 581	Latch guide					40	
1 4:17	LACCH ZUICE	9 3°			j	10	
	基金が行	<u> </u>			ļ		
	· · · · · · · · · · · · · · · · · · ·		†				
0600	Spool holder leatherette	Same S	2			10	
		China a A				Ì	
	Z=+€5		 				
₹610	heft side cover						
	leatherette					20	
	左外盖革	•					

Z	ENZA BRONICA	ETR		Film	back				
Parts No. 部品番号	Name 名 称	Sh 形	nape 状	Posper Unit 個数	Page 頁	Ass'y No. 組立番号	Price (¥) 単価	Remar 備	ks 考
<u> </u>		, no		THEO SEX		MST 117-18E-2	 IIII	TURE .	_
1-260690	Gate roller plat	e 6	<u>.</u>	2			20		
	ゲートローラー押え下		_				<u> </u>		
0700	Spool lock sprin	.					20		
	スア・ルロックバチ								
0790	Gate roller cove	e r		4			10		
	ゲートローラカバー								
0813	Connecting metal (upper)						60		
	バック掛金 (上)・								
0822	Connecting metal		•				60		
	八沙掛金(下)	45							_
0832	Camera opener p	ate 52	25				55		
	後蓋庸用极下	6					!		
0855 9010 ,	Enttom plate (W) " (B) バックエカバー		J.				750		
0861	Gate roller	4 1		2			40		
	ゲートリーラー			_					_
387 4	Gate roller plat	e e	<u></u>	2			20		
, <u>.</u>	+ + p - 5 - 18 (<u>-</u>					_
0882	lark slide click epring	<u> </u>				. •	10		
	引美29.7级								

ZE	NZA BRONICA	ETR	Film	back	: 		
Parts No. 部品番号	Name 名 称	Shape 影 状	Pos.per Unit 個数	Page 頁	Ass'y No. 組立番号	Price (¥) 単 価	Remarks 備 考
	Dark slide guide	<i>⊙</i>				уû	<u></u>
0902	京 <u>差リカバー</u> Light-tight plate	(max or complete on the administration of				20	
0,02	引益日选之极						
0912	Dork alide rignal plate A 引集39寸の扱力	(3)				10	
0921	Bark slide signal plate B 引表シケナン検B					10	
0930	Park slide signal pin 3 ままでも心的					25	
0942	Lighr-toght plate C 引基底之校(<u></u>	-				
0952	F release cylinder A F酶解消力					50	
0961	F release cylinder 9 4新育量 8	£@				35	
0673	Rack cover release button					20	
jao <u>(</u>	F release nin	C _S	2			20	
1001	手資程 (3) Step1 ball 3/32m	0				10	
	3/32數は			 			

ZE	ENZA BRONICA	אי	Film	back	<u> </u>		
Parts No.	Name	Shape	Pesper Unit	Page		Prige (¥)	Remarks
部品番号	名 称	形 扶	個数	頁	組立番号	単価	備 考 ————
1-261014	Front-side back plate バック新校	<u>မြေ န စေ</u> (၂၈၀) (၂၈၀)				300	
1021	Cover release plate collar 後基制用扱カラー	<u>ئۇ</u>	2			10	
1030	Latch plate spring		:			10	
1042	Light-tight plate B					20	-
	引基日連光极日	\$					
1051	Signal plate guide 引生シケナル投か作	6				25	
1062	Release button leatherette 南角っまか革					5	

Z	ENZA BRONICA	'R	Film bac	ek		
Parts No.	Name	Shape	Posper Unit Pag		(¥)	Remarks
部品番号	名 称	形状	個数 頁	組立番号	単価	
1-261240	Wind up gear A	(O)			160	
	八.9格上杰幸A			<u></u>	-	
1252	Wind up gear B	Contraction of the contraction o			240	
	N-1万円に出車B	Proof.				
1261	wind up gear C				200	
	八 介牌上载集C	The control of the co				
1273	Wind up gear D				200	
	ハーク発上式車コ	المحمد المسالة				
1282	Spool metal bearing				220	
	スプール 爪変					
1293	Spool clutch axle	6			40	
	スプールプライ朝	-				
1302	Wind stopper ratchet	6)			140	
	横上演革					
1313	Enool metal	(FOB)			90	
	z mon M	A				
1320	Spool shaft (upper)	69			20	
	スプール 割上	O .				ĺ
+491	Wind stopper mawl	6			10	
	商业制				į	
1443	Dividing plate base	(C)		1-763100	160	
	到水板变					

Z i	ENZA BRONICA	ETR	Film	back			
Parts No. 部品番号	Name 名 称	Shape 形 状	Posper Unit 個数	Page	Ass'y No. 組立番号	Price (¥) 単 個	Remarks 備 考
1-241453	Dividing plate collar 創出板受力5-				1-763100	15	
1463	Counter dial (120) 指数模 (126)					260	
1470	Counter dial stoppe 指数扱ストッパー			-		10	
1552	Dividing plate axle					25	
1663	Cuide screw B	O F	4			8	
1681	Right side cover pillar B たカバー社 B	The state of the s				15	
1702	Spool shaft (right) スプール愛右	0				70	
1721	Counter roller chaft B 謝長10分-納号	8				30	
1733 9040	Manual film winder cover (W) " (B) 様子フまみカバー					120	
1763 9020	F. right side cover (W) "(P) M 方 升 基	20.00				580	

Z6	ENZA BRONICA	TH .	F17	m bac	· K	-	
Parts No. 部品番号:	Name 名 称	Shape 影 状	Posper Unit	Page	Ass'y No. 組立番号	Price	Remark
DO HO THE O	13 174	影 状	個数		町立番り	単 価	(
-261775 9030	M.left side cover(W) "(B) M 左 升 基			:		320	
1782	Light-tight frame (right)					120	
1792	Light-tight frame (left) 左進光极			•		110	
1801	Guide collar B	(5			10	
1812	ガイドカラーB Frame index mark 指 様					8	
 :	指權						
1841	Counter dial stopper pin (120) 指数投ス{ッパーピン	6)				5	
1861	F. release spring					15	
1870	ア解除パネ Starting lever spring			i		15	
	色動しバーバネ			ŀ		Ì	
1882	Spool clutch spring					70	
	スプールクライバネ						
1891	Counter dial spring				1-763100	10	
	Mark St. Car	- Jr					
1900	F. release lever nin spring	Q				10	
	ア酢 除しパーピンパー						

Z	ENZA BRONICA	ETR	Fi ln	bacl	¢			
Parts No. 部品番号	Name ! 名 称	Shape	Posper Unit	Page	:	Price (¥) 単価	Remarks	
1-261921		* *	個数	頁	組立番号	10	備考	
1941	Reverse stopper spring 连轴上八六	0				10		
1951	Auxiliary plate spring 割去精助投产	O TORS			1-763100	25		
1961	Right cover leatherette 右外玉草	O				25		
1970	Film winder leatherette 様子つまみ革				·	5		1
1990	Cover pillar B spring 五九八-柱B八字							
1-160481	Exposure counter lens 中意用:22					40		
					ļ			

ZE	NZA BRONICA E	PH.	Film	back				
Parts No.	Name	Shape	Posper Unit	Page	Ass'y No.	Price (¥)	Rema	ırks
部品番号	名 称	形状	個数	頁	組立番号	単価	備	考
1-262023	Pressure plate (220)					550		
	丘极 (220)	0	_					
2032	i		!			280		
	指教 极 (220)		ļ					
2041	220 film indicator plate	220 p				40		
	转 段 (220)		•					
2060	(aunter didi stopper pin (220)	D.						
	指数校2トルペーピン(220)					-		ļ
2560	Rear cover lock	9						
	後蓋ロックバチ							
2570	Adjusting liner	5						
	梭艺用用双座企	tc.3						
2580	Adjusting liner	/3)					•	
		t 0.2						
2590	Adjusting liner	//						
		to./						
								\dashv
					į	İ		
								ĺ
								

Z.	ENZA BRONICA	ह ास	Fil	n bac	k (158	у)	
Parts No. 部品番号		Shape	Posper Unit	Page		Price (¥)	Remarks
即 明 番 万 1261426	名 称 Orders opener plate	形 状	個数	質	組立番号	単 価	備考
	*** (npper) 後 茅 摩 関 板(上)	3-6-2					
1140 1170 3050	(220, 73	50/1	į			400	
·15.5		Sie de la constant de					
4213	Bear cover and			!		2,100	
	後蓋むい			<u></u>	·-···		
220)	Manual film winder set					410	
	推りつくとセット						
3100 3140	(120)					400	
<u>_</u>	寒。此栖也。(120)						
321 0	Counter driving gear set	O Samuel				400	
	指数极善自己也小	6		-			
331 °	Wind stopper lever	/ 8 =				250	
	港 止レドー	& S					
3400	Spool holder set		2			300	
·	スプロール受						
५ ल्यी सः ।	Spool met consistent					730	
	スコローいが愛セット	3					ľ
381A	Winding most meaning sec					50	
	搭 上進庫受板	0					1
4 72 -	ist timit onver					35	
	右壳比板上划上						

ZE	NZA BRONICA E	TR	Film	back	(Assty)	
Parts No. 部品番号	Name 名 称	Shape 形 状	Posper Unit 個数	Page	Ass'y No. 組立番号	Price (¥) 単価	Remark 備 ⁱ
	F.release shaft set		,		122 200 117 2	1 1-2	
J- 50/1 040	下解除シントセット					50	
4110	N right side plate M も板					200	
4120	Starting lever	1823				50	
	起動ルバー	10		 			
	M left side plate set	(9)				150	
	M左板						
4310	Spool spring roller set		2			80	
	スプールドネロ・ジーセット	ا ا					
4400	Frame counter roller					250	
	現) 提口-5-A			፟ . .			
4410	Roller shaft A					150	
	沙 仮の-5-A 軸	2					
4500	Frame counter roller		 			250	····
	須) 寝,ロ-5-3	<u> </u>				-	
							···

z	ZENZA BRONICA Camera body/Magnifier								
Parts No. 部品番号	Name 名 称	Shape 形 状	Posper Unit 個数	Page	Ass'y No. 組立番号	Price (¥) 単 価	Remarks 備 考		
-258001	3000 frame 7-171-4					1,000			
8010	Top cover 上 蓋	المعالمة المعالمة المعالمة المعالمة المعالمة المعالمة المعالمة المعالمة المعالمة المعالمة المعالمة المعالمة ا				640			
8040	Right plate A 在 板 (A)					95			
6050	night plate B 古 极 (B)				٩	85			
8060	Left plate A 左 极 (A)					95			
8070	Left plate B 方、板 (B)					85			
8090	Rear plate operation plate 後校作動极					11G	ţ		
81 00	mear pinte connecting trate 後載結合板	کشر نے				160			
A***5	% 被作動被軸管					55			
As zij	light-tight class (1994) 遮光板(生)					40			
81 % /	ient-tient water (rient) 逸之极 (右)					40			

ZE	NZA BRONICA	*	Camer	*a. 000	b/Fagnifi	er	
Parts No. 部品番号	Name 名 称	Shape 形 状	Posper Unit 個数	Page 頁	Ass'y No. 組立番号	Price (¥) 単価	Remarks 備 考
1=258140	Ton nover metal (left) 上蓋軸受(左)					50	
8150	Top cover metal (right) 上蓋 棘变(右)					5 0	
8160	Magnifier 0-C lever ルーへ前用ルー					60	
8180	Connecting plate holder A 後載為分板押之(A)					25	
8250	n-c lever screw 剤用バー取付ビス	Q				35	
8320	Nagnifier 0-C axle ルーペ枠前用軸	1.40	3			27	
6 × 3()	oneration plate axle 变成作動板軸	1-26				10	
r-\$40	Top cover 0-1 exte 上菱別甪軸	1:627				10	
8450	Flate axle 方名极軸	à: 36	2			15	
4360	isear plate 0-1 axle 後夜崩崩軸	g=38	3			25	

ZE	ENZA BRONICA	™R	Camer	a bo	dy√inespi ifii	ier	
Parts No. 部品番号	Name 名 称	Shape 形 状	Posper Unit 個数	Page 頁	Ass'y No. 組立番号	Price (¥) 単価	Remarks 備 考
. ^ \$244 410	Top soven 0-0 soring (left) 上蓋期別珠(左)	Sammer.				20	
B ₹80	Top cover G-C spring (right) 上蓋周射(永(左)	Samuel .				20	
8390	Frame C-C spring ルーペ枠 前角だ木	THE REAL PROPERTY OF THE PARTY				15	
8400	Side plate C-C spring (left) 模板前用バネ(左)					10	
8410	Side plate 0-C spring (right) 横板廟別八木佑)	9253				10	
8420	Frame 0-C spring ルベ枠周用いた水	þ				15	
· 440	Top cover leatherette 上麦革	22				40	


ZE	NZA BR	ONICA	Came	Camera body /Magmifier (Ass'y)						
Parts No.		lame	Shape	Unit	Page	Ass'y No.	Price	Rem		
部品番号	名 ————	<u></u>	形	状 個数	Ą	組立番号	単 価	備	考	
- 7560 80	Dever Jever (一) Jever			0			30			
6090	Catch our			9			: :0			
511 0	Magnifie	r frame set					320			
6160	Magnific	r hase set		96			170			
	1- Va 24	オ 長 セット 		 						
6230	Rear pla 後本5七。						180			
		-								
_										


Z	ENZA BRONICA	ETR	Zer	zanor	75mm i*2	.8	
Parts No. 部品番号	Name 名 称	Shape 形 状	Posper Unit 個数	rage	Ass'y No. 組立番号	Price (¥) 単 価	Remarks 備 考
1-210000	Shutter unit #773 >>> + 773					15,000	
0152	Fixing ring シャッター 写マイコンプ	0				150	
0162	A-T click plate てつり、つね					25	
,							
0202	Lock plate axle					15	
0047	ロック特殊					75	
0213	Set ring locking plate せいとう ロック 才友					25	
0221	Lock plate spring holder ロークオ及スプロンク 特に	O *				12	
0233	Lock place spring ロックオをスプリング	√				20	
02HA	Pistance scale ring		•			1,500	


ZE	ENZA BRONICA	H-172	3en	zanon	75mm F2	.8	
Parts No. 部品番号	Name 名 称	Shape 影 状	Posper Unit 個数	Page	Ass'y No. 組立書号	Price (¥) 単 個	Remarks 備 考
1-210475	Preview arm spring A 多量カアームスアリンプ A	Campo				20	
0482	Name ring					1,400	
0512	Leatherette スケール 接。草					50	
0521	Fixing tape 国宅テーフ ^o	0					
0531	Light-tight ring 逸光致	Ø,				90	
0570	Spring guide スプリンプ ガイド					10	
0621	A-T ring lock screw					30	
		,			444		


ZI	ENZA BRONICA	ra	Zenz	anon	75mm F2.	.8	
Parts No. 部品番号	Name 名 称	Shape 影 状	Posper Unit	Page	Ass'y No. 組立番号	Price (¥) 単 価	Remarks 備 考
1-210294	Depth of field scale ring 深度טני					1,500	
0301	Preview lever きゅっトバー					30	
0310	Preview lever axle	0				20	
0324	Front barrel 斯 特	0				720	
0335	Aperture ring 後コッシヴ	0				900	
0342	Preview arm 終ッマーム		2			40	
0372	Front auxiliary barrel 高、米本					900	
0412	Preview arm spring holder 学覧カアーム SP 荘ト	000°				15	
0423	Preview arm screw A 手動ヤーム 気なれる	D				15	
0435	" B 手動下心取付 B	(D)man				15	
0464	Preview arm spring B 手等カアームスプッシューB	∞ -⊃	-			20	


ZE	NZA BRONICA	TR	4enza	unon î	75mm F2.8	ŀ	
Parts No. 部品番号	Name 名 称	Shape 影 状	Posper Unit 個数	Page	Ass'y No. 組立書号	Price (¥) 単価	Remarks 備 考
1-710140	A-T ring T tの報じご記	0				230	
0120	Preview arm set	S				120	
0220	Set ring unit					2,200	
0260	Flexible print A-B					750	
0300 :	Helicoid unit	(G)				4,800	
						_	
· · · · · · · · · · · · · · · · · · ·						ļ	
:							
		·					





























Z	ENZA BRONICA	TR	Spee	d gri	P		
Parts No.	Name	Shape	Posper Unit	Page	Ass'y No.	Price	Remarks
部品番号	名称	形状	個数	页	組立番号	単価	備 考
1-230010	Bottom base plate						
	下极	O COLUMN TO THE PARTY OF THE PA					
0020	Outter grip				ı	380	
	グリッフの(タト)						
0040	Pressure plate	COD.				26	
	押板						
0050	leaf spring		2			10	
	板パネ	<u> </u>					
0060	Lock adjusting ring					45	
	回転子						
0070	Locking lever					45	
·	締付レバー						
0080	Locking lever catch					10	
	光上チ掛						
0111	Base plate		·			60	
	化粧板						
0121	Tripod socket					150	:
	三月中ネジ						
0131	Safety stopper stud					20	
	ストッハ・エネジ			.			
0140	Upper stopper pin	9	2			20	
	ストッパピン(上)						

Z	ENZA BRONICA	<u>rr</u>	Spe	eed g	rip E		
Parts No.	Name	Shape	Posper Unit	Page	Ass'y No.	Price	Remarks
部品番号	名 称	形状	個数	Ą	組立番号	单 (¥) 価	衛 考
1-230150	Stopper pin stud	9	2			20	
	ストッパ・ヒ゜ン(下)						
0160	Base plate stud	9				20	:
	化粧板固定じン						
0170	Grip attaching scre		4			20	
	下板ネジ		3				
0180	Grip coupling screw	O D	3			20	
	色セネジ	_					
0221	Top Plate					15	
	推上化粧板						
0250	Winding lever cover	(°)				10	
	滟 上蓋						
0261	Fixing screw	Ŷ				20	
	先上輪上						
0370	Spiral spring holde	් පු				10	
	地上バネギ					10	
0380	Spiral spring				1-730050	140	
	地上ドネ						
0390	Winding claw spring	<u>_</u> 6	4		1-730050	20	
	地上へバネ						
0400	Winding shaft bearing plate					15	
	推上軸受座押心		1 1	ļ			


ZE	NZA BRONICA ET	R	Spee	Speed grip E				
Parts No. 部品番号	Nam e 名 称	Shape 形 状	Posper Unit 個数	Page	Ass'y No. 組立書号	Price (¥) 単 個面	Remarks 備 考	
1-230422	Joint shaft bearing					60		
	然う幸中受							
0430	Crank catch A 然生 手動由 A			:		150		
0460	Joint guide pin	o	2			8		
	念法チピンカラー							
0470	Crank catch cover					30		
	港 多外 输							
0480	Steel ball bearing					30		
	スチールボール集 A					30		
0495	Steel ball bearing -B					120		
	スチールボール党 B Ball bearing setting screw					20		
0501	スチールボール受ネジ					. 20		
0511	Joint shaft setting screw					20		
	総う輪 A止							
0630	Release pin					20		
	レリーズでン							
0640	Crank A roller レッーズコロ	o D				8		
		,		•			·	


ZENZA BRONICA ETR			Speed grip E				
Parts No. 部品書号	Name 名 称	Shape 形 状	Posper Unit 個数	Page	Ass'y No. 組立番号	Price (¥) 単 価	Remarks 備 考
1-230680	Crank B	2				40	-
	クランクB		<u> </u>				
0690	Release pin guide					40	
	レリーズ'ピンガイド -	~16	ļ <u> </u>			-	
0700	Crank B axle	\$				25	
	クランク8季曲						
0710	Release pin A					30	
	レリース"ピッA	6					
0720	Release pin B					30	
	レリーズ'ピンB						
073 0	Release guide pin	\$				20	
	レリーズガイドピン						
0740	Release guide pin roller	©				8	
	レリーズコロ						
0750	Crank B spring					20	
	クランクBドネ						
0790	Bottom plate 底蓋					160	
0800							
	Shoe mount >>=-/ ≥=-/ >=-/ / >=-/ / >=-/ >=-/ >=-/ >=-/ >=-/ >=-/ >=-/ >=-/					80	i.
0810	Shoe base plate					20	
	シュー化粧座			•			

Z	ENZA BRONICA	ETR	ន្យ	peed é	grip E			
Parts No. 部品番号	Name 名 称	Shape 形 状	Posper Unit 個数	гаве	Ass'y No. 組立番号	Price (¥) 単 価	Remarks 備 考	
1-230840						30		
0850	イヒオ生リング Leatherette グリップペタト革	Q				40		
0860	Grip spacer グリップペタル草 下	0				30		
0881	Contact piece シューラク"木列		2			5		
0890	Shoe mount cover >¬-₹					30		
0911	Strap metal ストラッフo金臭	Q				120		
09 20	Strap metal nut ストラップ・ナント	()				5		
0931	Set acrew	9				5		
0950	Rubber 下板ゴム					20		
0960	Leatherette 推上化粧華					15		
0970	Leatherette					15		

Z	ZENZA BRONICA ETR Speed grip E						
Parts No. 部品書号	Name 名 称	Shape 形 状	Pos.per Unit 個数	Page	Ass'y No. 組立書号	Price (¥)	Remarks 備 考
1-230190	Adjusting ring screw	3	3			8	
	回知子上十岁						
0590]			!	1-730010	90	
	レリーズボタンリング	3					
0600	Button ring nut	(0)			1-730010	15	
	ボタンリングエオジ	***					
0772	Contact base					60	
	接吳極	-01/					
0100	Stopper				1730020	20	
	ストッパー		\perp				
:			1				
		······································					
						١.	
[. <u></u>							

ZE	ENZA BRONICA	ĕ7R	Spe	ed gr	ip (ass	3*y)	
Parts No. 部品番号	Name 名 称	Shape 形 状	Posper Unit 個数	Page 頁	Ass'y No. 組立番号	Price 単 価	Remarks 備 考
1-730010	Inner grip					480	
	7"3",7"(h)						
0020	Safety stopper					60	
	ストッペを放せった		ļ				
0030	Winding lever				; ;	240	
	港上レベーセント						
0040	Joint shaft set	3 D	:		,	420	
	経 守車由セット						
0050	Winding wheel w/spring					540	
	推上輪セル(スプのりが)	· · · · · · · · · · · · · · · · · · ·					
0060	Winding shaft set					1,200	
	推上動たと	E ANNES					
0070	Joint guide	<u> </u>	:			75	
	然をサイドセント						
0080	Release button					40	
	レリーズボタンセット						
0090	Crank A	~25/5°				55	
	クランクA	5					<u> </u>
0100	Hot shoe set				:	80	
	ジー母草ワント						
		4		4 .			
			<u> </u>				







REPAIR MANUAL

ZENZA BRONICA IND., INC.

CONTENTS

1	Detachment of the Right Side Cover	1
	Film Winding Cranks Comes Off	
	Multiple Exposure is not Possible (I)	
	Winding Action does not Stop (I)	
	Winding Crank is Very Loose	
	Winding Action is not Possible	
	Shutter Release Button cannot be Depressed	
	Multiple Exposure is not Possible (II)	
	Exchange of the Film Release Unit	
	Mirror is not Charged	
	Shutter Blades do not Open (I)	
	Adjustment of the Mirror Arm Adjusting Cam	
	Shutter Blades do not Open (II)	
	Detachment of the Left Side Cover, Add Shutter Speed Dial Stopper	
	Shutter Speed Becomes 1/500 Second	
	Relation of the Shutter Speed Dial	
	Detachment of the Lens	
	Lens can not be Detached	
	Shutter Release Button does not Return	
	Film Back can not be connected	
	Action of the Main Switch Set	
	Waist-Level Finder can not be Attached	
	Adjusting the Focus of the Focusing Screen	
	Reflex Mirror Light-Tight Plate	
	Exchange of the Reflex Mirror	
	Adjustment of the Mirror Frame to 45°	
	Wiring Diagram (f) ,	
	Wiring Diagram (II)	
	ETR Electronic Control Circuit Repair	
	Detachment of the Left and Right Magazine Side Cover	
	Spool Holder does not Close	
	Counter Dial does not Advance	
	Adjusting Film Start	
	Counter Dial does not Return	
-	Winding Action does not Stop (II)	
7	Improper Frame Interval,	. 33
	Film is not Advanced	
	Unusual Noise with Winding Action	
10	Others	. 3:
11	Film Gate (I), (II)	. 36
	Shutter Blades do not Open (III)	20
	Preset Action can not be Confirmed	
٤	Exchange of the Shutter Assembly	
	Tool list	4

1. Detachment of the Right Side Cover

How to Detach


- 1) Strip off two crank base covers (A257040) which are fixed to the surface of the crank base casting (A753320) with bonding agent and then loosen four fixing screws (B813605). Finally, detach the parts up to the crank ring set (A753340).
 2) Strip off the leatherette on the multi-exposure lever (A256091), loosen the fixing screw and then detach the multi-exposure
- 3) Strip the leatherette from around four screws or two B813357 and two B813287, loosen these four exposed screws and, finally, detach the right side cover (A755400).

The crank base covers are deformed rather easily and, therefore, it is recommended that spares always be held on hand for exchanging.

How to Attach

- Attachment is in the reverse order of the above, but keep the following points in mind, when doing so: —

 1) The right side cover should be located while depressing the finder locking pin (#2) in order that the pin can be located for coupling with the finder release button (#1).
- 2) The crank ring set must be positioned concentrically with the crank base casting, or with equal spacing all around it, in order to prevent contact with the right side cover which should, in turn, not protrude beyond the base surface (attachment of the film back will help in determining the location at this time and the winding crank should also be revolved to confirm positioning).




2. Film Winding Cranks Comes Off: Crank Shaft Slips Out Easily

The crank shaft (A255692) is securely fixed in position only when the click pin (A255621) is inserted fully in the groove (A) on

the crank shaft.

1) Strip off the two crank base covers (A257040), loosen four fixing screws (B813605) and detach the crank base set (A753310).

Next, bend the crank base spring (A255632) so that it exerts more pressure on the click pin.



3. Multiple Exposure is not Possible

The multiple exposure mechanism is activated by setting the multi-exposure lever (#3) or rotating it in the clockwise direction, which disconnects geers on the body side from those on the film back side, so that the film is no longer advanced with film winding crank action. At the same time, although the film is no longer being advanced, the multiple exposure mechanism stops the film winding and shutter charging action and permits shutter release when operations are completed on the body side only. If multiple exposure is not possible, when set in the above manner, but becomes possible when the multi-exposure lever (#3) is reversed once (to normal single exposure operation) and then re-set for multiple exposure, the movement of the winding auxiliary plate (A753200) even after the shutter is released.

Repair in the following manner:—


Repair in the following manner: -

nepart the renowing matrice.—

1) Detach the right side cover, loosen five B813357 screws and take out the winding unit (A753110).

2) Detach the cam holding out (A255230) and then detach the setting cam assembly (A753190). Finally, replace with a new

When reattaching the winding unit in the body, see that the winding stopper lever (A753220) and #2 engage with the F. (film) release unit. (See Exchanging the Film Release Unit on page 8.)



4. Winding Action does not Stop: Winding Stopper Lever Spring is Unhooked

Load a test roll film in the film back and manipulate the winding crank (and advance the film and charge the shutter) for taking the first frame. Then, detach the film back and check whether the F. (film) release pin (A260990) is protruding up to the front end of the F. release cylinder A (A260952) (see page 33). If the pin is not protruding correctly, correct according to "Film Back — 6. Winding Action does not Stop".


1) Detach the right side cover. If the winding stopper lever spring is unhooked, it will be quite all right to hook it up once more but since it is liable to get unhooked again, it is recommended that the following repair be undertaken.

2) Loosen five B813357 screws and detach the winding unit (A753110).

3) Loosen the winding stopper claw spring holder (A255790) with the special screwdriver (A255790-AJ), take off the snap ring "type E" (B500334) and, then, detach the winding stopper lever (A753220).

4) Obtain a new winding stopper lever replacement part (which has a round opening in the place indicated by the (A) arrow) and assemble it into the body. When using the new replacement part, however, enlarge the opening on the winding base plate assembly, as indicated by (B) arrow, to 2 mm diameter.


5) Refer to page 8 for reattachment of the winding unit.



5. Winding Crank is very Loose: Main Shaft Setscrew is Loose

Strip off the crank base covers (A257040) and check whether the 8813605 screws are loose or not. (See page 1.)

1) If looseness in the winding wheel (A753170) can be corrected by tightening the main shaft setscrews (A255572), detach the setscrew, apply Loc-Tite to the threads and re-tighten the main shaft setscrew securely once more.



6. Winding Action is not Possible: Transmission Gear is Cracked


- If the cracked transmission gear (A255432) is a white-colored plastic one, exchange it for a metal replacement part.

 1) Loosen the connecting gear screw (A255760) and left hand gear arm screw (A255471), detach the upper connecting gear arm (A255461) and exchange the transmission gear.

7. Shutter Release Button cannot be Depressed: Reverse Stopping Claw is Positioned Incorrectly

When the shutter release button is depressed, after completion of the Elm winding crank action, the upper release safety lever (A255350) should fall into the notched section on the release safety carn (A255482) which will release the shutter. In other words, if the lever is not in the notched section but positioned elsewhere, the shutter cannot be released when the shutter release button is

1) Loosen the B823167 screws and adjust the reverse stopping daw mount (A753130) so that the upper release safety lever falls into the notched section on the release safety card. Confirm that the same action also takes place when the winding crank is rotated in the reverse direction, too.




8. Multiple Exposure is not Possible: Setting Screw is Loose

The multi-exposure lever (see page 1) rotates the multi-set lever (A753250) via the multi-lever axle (A255371) and, thereby, pushes the multi-exposure link (#1) forward or in the direction of the lens.

1) The setting screw (A255401) should be fixed securely with Loc-Tite.

2) Exchange the multi-operating lever spring (A255922) when it is unbooked, if its hooking section is deformed.




9. Exchange of the Film Release Unit

- F. release unit with an old type winding safety lever (#1) attached should be exchanged completely for a new type one, in order to prevent deformation of the wind stopper pawl (A261391).

 1) First, detach the winding base plate assembly, then detach the shurter button stopper ring (A252270, B502444) of the shutter release button set (A751290) and the snap ring (B500334) of the shutter release link (A252370), loosen four B813307 screws and, finally, detach the F. release unit (A753500).
- 2) Keep the following points in mind when attaching the winding base plate assembly, after attachment of the replacement F.

- Keep the following points in mind when attaching the winding base plate assembly, after attachment of the replacement F. release unit.
 The upper release safety lever (A255350, see page 7) must fit into (8).
 The multi-operating lever (A753240, see page 7) must engage (C).
 The winding stopper lever (A753520, see page 4) must engage (D).
 The holding claw (A753570) engages the F. release roller (A254810) while the shutter release button is being depressed and prevents the return of the upper F. release plate (A753590) so that there is time for the F. release action to take place. If the holding claw does not engage the F. release roller, then bend the upper F. release lever (A753520) in the arrow-indicated direction.



10. Mirror is not Charged: Bent Mirror Set Lever and/or Faulty Action of the Shutter Latch


- Reflex mirror swings back up immediately upon completing the film winding crank action.

 1) Check action of the shutter latch (#1).

 2) Next, loosen screws B813287, 8813457 and B821207 and then detach the light baffle cover (A251681). (The old type light baffle cover also has a protrusion, as indicated by the broken-line part, and, therefore, it will be necessary to loosen the top frame (A755200), also, in this case. Refer to page 19.)
 - Detach the set lever screw (A251561, which has a left hand thread) and take off the snap ring (B500334) and operating plate set roller (A251501). Finally, exchange the mirror set lever (A751260).
 When exchanging the set lever shaft (A250032) use a part matching the height of the set lever.

CAUTION:

A bent set lever is caused by mistakes made during the insertion of the lens. If the film winding crank action is heavy, when assembling the set lever, therefore, do not force the action. (Refer to page 15" Lens Cannot be Detached".)



11. Shutter Blades do not Open (I)

The shutter blades close down completely when the shutter release button is depressed, while, at the same time, the reflex mirror swings up. Then, the light-tight plate (A751100) also swings up, followed by the shutter blades reopening and, after the required amount of time, closing completely once more. Should the shutter blades not reopen after the light-tight plate swings up, resulting in an unexposed frame, it should be repaired in the following manner.


1) Exchange the right operating-ring spring (A251601) since it has been strengthened by increasing its wire diameter to 0.26 mm.

2) Exchange the shutter operating ring unit (A752010) (see page 11).

12, Adjustment of the Mirror Arm Adjusting Cam (A251471)

When making the repair noted in "11. Shutter Blades do not Open (I)", position the M. (mirror) arm adjusting cam so that the M. operating plate (#1) moves up and down smoothly.

At the same time, the M. arm adjusting cam should not come in contact with the M. driving lever (#2) when the mirror swings up.




13. Shutter Blades do not Open (II): Rotation of the Shutter Operating Ring Unit is Heavy

With lens detached, check rotation of the S. (shutter) operating ring unit (A752010) in the arrow-indicated direction while maintaining pressure on the shutter release button. If the rotation is not smooth but feels tight or seems to be catching, it should be repaired in the following manner:-

- Lossen nine B815405 screws and detach the lens mount (A252227). Since the focus adjustment washers (#1) differ in thickness, they must be properly identified so that they can be returned to their original positions when reassembling.
 Lossen two B813405 screws, three B813607 screws, one B831457 screw and six B813357 screws.
- 3) Detach the left side cover (see page 12), unhook the operating-ring spring (A253411) and exchange the S. operating ring unit. Use a spring with 55 turns, Adjust distance from standard attachment plane (surface) to the star-indicated (*) position on the lens mount to 79 mm ±0.03.

(Use tooling jigs CT-301, 302 and 303.)

Use care when making the exchange, as there are two types of lens mounts with thickness of 9.6 mm and 9.65 mm at point "A".




14. Detachment of the Left Side Cover Add Shutter Speed Dial Stopper

- Strip the shutter dial cap leatherette (A257060) and loosen two B833257 screws. Then, detach the shutter dial cap (A755530) and loosen two more screws (B821207). Finally, detach the shutter dial knob (A755570).
 Strip off enough of the left cover leatherette (A257050) to expose the screws, loosen two B813405 screws and five B813357
- screws and, then, detach the left side cover.
- 3) Place the cable release pin (A755540) aside for safekeeping since it will become loose when the left side cover is deteched.

1) Change one of the setscrews (#1) of the shutter dial cover (A256861) to the shutter dial stopper (A256800) and change the shutter dial knob to part A755570 (which has a stopper pin riveted to it).

Pointers on Assembling

- 1) Do not forget the cable release pin.
- 2) The circuit is grounded (earthed) at two points at the front end and, therefore, the left side cover must be fixed with two chromium-plated screws (B813405).
- As with the right side cover, the left side cover should also not protrude beyond the standard attachment plane (surface).
 Do not cause short-circuits by pinching the wires.



15. Shutter Speed Becomes 1/500 Second

The switch of the shutter circuit (A754100) is ON because the AE changeover rod (A754120) is pressed up by the strength of the AE changeover rod spring (A253920). However, when the AE Finder is attached, the AE changeover rod is pressed down and the switch is turned OFF, with the shutter circuit then becoming inoperational.

1) Is the AE changeover rod protruding 1.5 mm above the top frame?


If not, rehook the spring (A253920) to adjust.

- 2) Is it possible that the switch of the shutter circuit is OFF? Confirm ON/OFF operations of the switch by pushing the tip of the AE changeover rod, If OFF, bend the contact plate (A) to make the necessary adjustment.

 3) Check for defect in the wiring circuit. See page 26,

16. Relation of the Shutter Speed Dial and Shutter Speed Setting

1) Rotate the shutter dial click plate #1 and coincide its brush contact to the 8 second position (see drawing of pattern). Then, attach the shutter speed dial (A253704) with its 8 second setting at the top position.



17. Detachment of the Lens

Detechment of the lens differs with the cameras or, in other words, there are two systems, or 17-1 and 17-2 illustrated below. The two systems are easily differentiated by whether the lens release button has a leatherette covering or not.

17-1 Lens release button has leatherette covering.
Turn the film winding crank fully and charge the shutter. Hotete the lens release button locking ring (A254010) and depress the lens release button (A252293) while keeping the ring rotated. Finally, rotate the lens and detach.


17-2 Lens release button is not covered.

Turn the film winding crank fully and charge the shutter. Rotate and depress the lens release button (A254080). Detech the lens.

CAUTION:

To repair defects in the 17-1 system, change completely to the new 17-2 system.

When the film winding and shutter charging operation is completed, the lens safety lock (A752130) is pushed by the S. operating ring unit. (A752010), with the result that its hook section is then slipped off the lens button latch (#1), thus making it possible to depress the lens release button. When it is not possible to complete the film winding and shutter charging operation in the normal manner, push the lens safety lock with your finger which will make it possible to detach the lens.




18. Lens cannot be Detached

When it is not possible to depress the lens release button, the trouble is due to deformation of the mirror set lever originating from rotation of the film winding crank when the #2 pin is not in the (8) section in the normal manner. The #2 pin will be located in (A) section, at such times.

In order to remove the lens, in this case detach the focusing screen and undertake the following operations from the top of the

- 1) Pull the setscrew (#1) in the arrow-indicated direction. Confirm that the #2 pin returns due to spring tension and enters (B)

- 1) Full the setscrew (#11 in the arrow-indicated direction, commit that the #2 pin retains due to spring tension and enters to section.
 2) Rotate the film winding crank fully, until it stops.
 3) Then, remove the lens according to either 17-1 or 17-2, as explained on the previous page.
 4) If the lens cannot be removed in the above case, use a screwdriver and push #3, while repeating the operations noted above.
 5) If the mirror set lever is bent because of the above trouble, repair as explained on page 9. Or, if movement of the #1 pin is not proper, when checked, exchange the S. operating ring unit (A752010), as explained on page 11.



19, Shutter Release Button does not Return


- The speed-grip shutter release rod (A253240) is jammed in the hole on the bottom cover (A253264).
 The release lever (A755310) is on top of the release rod (A751290) and disengaged.
 The lower F. (film) release plate (A753550) is on top of the release safety lever (see page 8) and, therefore, disengaged.

- Repair

 1) Exchange the MD (motor drive) connector cover (A253252) for a new part in which a protrusion has been added at the section indicated as (A) in the drawing. When making the exchange, however, attach liners with bonding agent, eliminate looseness in the speed-grip shutter release rod and, at the same time, align the rod properly to the hole on the bottom cover.

 2) Bend the tip of the release lever downwards so that it does not become detached from the grooved section in the release rod.

 3) Turn the tip of the release safety lever (see page 8) upwards.




20. Film Back cannot be Connected: Back Coupling Claw is Bent

Back coupling claw (A253141) does not slide laterally and, therefore, becomes bent when pressed by the back coupling link on the film back side.


1) Exchange the back coupling claw the coupling claw guide (A253151). Apply Loc-Tite to the 8813357 screw and fix securely. CAUTION:

When the dark slide is inserted fully into the film back, the dark slide connecting pin (A253181) is pressed by the dark slide, which results in the dark slide safety latch (A253221) pushing the lower F, release plate (A753550) and preventing depression of the shutter release button.



21. Action of the Main Switch Set

- When the film winding and shutter charging operation is completed, the main switch link (A750070) is pushed in the arrow-indicated direction while the main switch lever (A750060) is also moved in its arrow-indicated direction, by the action of the S. operating ring (A752010), as noted on page 11. This results in the main switch becoming ON (the sub-switch remains OFF).
 When the shutter release button is depressed, the AE switch lever (A750080) is pushed in the arrow-indicated direction, through the medium of the release lever (A755310), as noted on page 16, which results in the sub-switch becoming ON. At the same time, the main switch lever is returned to its original position, with the result that the main switch becomes OFF.
 Locate the main switch set (A754500) or bend the contact plates so that the above-mentioned actions are completed in about one-half of the stroke between the time of depressing the shutter release button and the start of the reflex mirror action, (Testing tool A754500-PT)




22. Waist-Level Finder cannot be Attached: Mount Springs are Bent

 The finder cannot be attached because the finder mount spring (A252722) is deformed at point A. Loosen the left and right side covers, detach the top frame (A755200) and exchange the finder mount springs.

CAUTION:


The part of the top frame with numbers engraved on it should not protrude above the standard attachment plane (surface). Align the finder lock pin (A750030), AE changeover rod (A754120) and hole.



23. Adjusting the Focus of the Focusing Screen

- Coincide the reflex mirror to the 45° position (see page 23).
 Adjust the height of the frame gate by increasing or decreasing the adjusting liners inserted below the frame
 Loosen four screws and adjust the height of the frame gate (A252522) by increasing or decreasing the number of adjusting liners inserted under the frame gate.


The 45° position of the reflex mirror and the adjusting liners inserted under the frame gate have already been precisely adjusted in the factory and, therefore, should not require adjustments. Confirm that they are really out of alignment before making the above adjustments.



24, Reflex Mirror Light-Tight Plate

Light to the film plane is shut out by the rear light-tight frame (A251164) and the light-tight plate (A751100).


1) If the leading end of section (A) on the light-tight plate is not contacting the mirror frame, when the light-tight plate is in the up position, then exchange the spring (A251821, see page 10).



25. Exchange of the Reflex Mirror

- 1) Loosen two B811157 screws of the mirror holders (A251751 and A251761) and detach the mirror, (Support the mirror frame
- by its rear surface in order to prevent warping.)


 2) Place the mirror holders against the side surfaces of the mirror and tighten the screws so that lateral looseness or movement in the mirror is completely eliminated. When tightening the screws, however, support the mirror frame (A751020) by its rear surface, with your free hand, in order to prevent warping.
- 3) The bent sections of the mirror holders may also be adjusted, i.e., bent more or bent fess, as illustrated, to prevent warping of the mirror. (Since there will be differences in the focus and the sharpness of the finder image, depending on how much the screw is tightened or loosened, both these points should be confirmed before making it final.)



26, Adjustment of the Mirror Frame to 45°

- The stopping location of the mirror frame can be changed variably, by rotating the mirror adjusting collar (A251311) which will have the effect of moving the mirror stopper (A251290).
 The mirror stopper screws (A251710 x 2) should be tightened when the mirror is properly located at the 45° position. (Do not loosen the mirror adjusting axle A251321.)

 Since the camera is already precisely adjusted, the screws should not be tightened or loosened without good reasons.




27, Wiring Diagram (I)

When three red-colored lead wires are connected to the checker contact case (A754130), the numbered wires should be connected to same numbers in the shutter circuit.


Red Power system
Green Flash synchro system
Black Grounding of body
Blue Grounding of circuit
Yellow Integrating system
Brown Motor drive power system
AE finder
White Aperture ring resistances
Orange Magnet (Mg) output
Violet Memory circuit
Pink AE finder power system

When the AE Finder is attached.



28. Wiring Diagram (II)

When one red-colored lead wire is connected to the checker contact case (A754131), the numbered wires should be connected to same numbers in the shutter circuit (A754111).



ETR Electronic Control Circuit Repair Manual

- 1. When the electronic control circuit is defective, it is possible to consider the following troubles: --
 - Shutter stays open.
- b) Shutter operates at 1/500 sec, at all shutter speed setting and
 c) Shutter stays open or operates at 1/500 sec, on some of the shutter speed settings only.
 2. If the shutter speed settings are not accurate, they can be adjusted with the "shutter speed VR (variable resistor)" in the illustration but a "shutter speed tester" will be required for this purpose.
- Approximate adjustments are, however, possible in the slow shutter speed settings of 1S, 2S and 4S, without such equipment. 3. First, use a tester and check whether the electronic control circuit is working normally or not. If the tester indicates normal operation, there is no reason for exchanging the electronic circuit 733.
- The actual checking procedure of the electronic control circuit, in the above case, is as follows:-
 - Take off the left side cover and remove the lens from the lens mount,
 - Connect point A with point B, with a jumper wire, as shown in Fig. 1

 - Insert the battery into the battery chamber without mistaking the polarity. Set the range of the tester for DC 10V to DC 15V. (Voltage used is 0 to 6V.)
 - Place the red lead on the Mg (magnet output) terminal and the black lead on the ground (earth) terminal, as shown in Fig. 1.
 Without making any change in the above conditions for 5), use a pincer and short-circuit point C and point 8.
- 7) Without making any change in the above conditions for 5, now remove the pincer away from the points.

 The reading on the tester for 61, in the checking procedures above, should be within the range 5V to 6.3V. When the pincer is taken away in 7), in the above procedures, check whether the reading on the tester becomes 0 after an elapse of time equal to that of the shutter speed setting set to the shutter speed dial. Or, in other words, the actual shutter speed will coreespond to the : me it takes for the tester reading to change from 6V to 0, when the C-B short-circuit in 6) is terminated in 7). It can be seen, from the foregoing, that this test is possible only when slow shutter speeds from 15 to 45 are set to the shutter
- spect dial.
 6. If the time-clapse can be confirmed in 5 above, then the 733 electronic circuit can be considered as operating normally.
- 7. In Fig. 1, the top group of resistors from 8S to 500 are the fixed resistors which determine the shutter speed setting. Thus, for example, if the resistor 30, in this group, is detached from the circuit board due to defective soldering, etc. the shutter speeds 1/500 sec. to 1/60 sec. will operate normally but the shutter will stay open at the other settings from 1/30 sec. to 85. In other words, the shutter speeds on the slow side of the resistor detached from the circuit board will all stay open. Thus, for example,
- words, the shutter speeds on the slow side of the resistor detached from the circuit board will all stay open. Thus, for example, should the resistor 500 be in the OPEN condition, the shutter will stay open on all shutter speed settings.

 8. If the 733 electronic circuit is operating normally, it is also possible to consider troubles due to mistaken wire connections, short-circuiting between wires and breakages in the wire and these troubles should be checked according to the following "Attached Sheet" which is also the general procedures followed on the Zanza Bronica assembly line. A so D
- "Attached Sheet" which is also the general procedures followed on the Zenza Bronica assembly line. A to D


 9. If the tester reading for 5 shows an incorrect shutter speed setting and the checking procedures in 4, 5, 6 and 7 indicate that the circuit board is defective, exchange the circuit board.
- If the circuit is then found to be operating normally (with the new circuit board), then check the wiring circuit as noted in 8.


 10. The wiring diagram shown in Fig. 1 may or may not have the "breakdown prevention condenser" or the "pull-up resistor", which are additional parts which have been added for preventing the following specific troubles.
 - a) Breakdown prevention condenser:
 - The shutter remains open at all shutter speeds or at the slow 1S to 8S speeds when the shutter is released with the electronic flash unit connected to the camera but returns to normal operation upon detaching the electronic flash unit.
 - The breakdown prevention condenser is not supplied for repair purposes but the circuit board can be exchanged completely. Defects run about one per thousand.
 - b) Pull-up resistance 8.2 kilo ohms:
 - Voltage is about 6.3V when the battery is still new. The shutter remains open while the battery voltage is high but returns to normal operations when the voltage falls to 5V.
 - The pull-up resistor is also not supplied for repair purposes but the circuit board can be exchanged completely. Defects run about one per 150.

CAUTION:

If the shutter remains open even when the electronic flash unit is disconnected and/or when the battery voltage falls to 5V, the origin of the defect cannot be considered as being the same as for the above two defects. Therefore, the circuit should be checked as per 4 to 8 for other reasons.

11. When checking the wiring circuit according to page 28, the reading should be less than 0.1 ohm. However, this cannot be measured and, therefore, simply check for continuity or whether the scale reading is almost 0 or not,





Checking Continuity and Insulation in the Wiring.

Step 1 - Use a digital multi-tester that can measure up to 0.1 ohm.

Brob.	Oac a digitor mante touter	
Step 2 -	Test in the following sear	Jence.

Sequence	Test Point (1)	Test Point (2)	Checking Points
1	A-1	B-1	Continuity less than 1 ohm.
2	A-2	B-4	ditto
3	A-3	B-2	– ditto –
4	A-4	€.4	ditto
5	A-5	C-2	- ditto
6	A-6	8-3	- ditto -
7	A-6	C-1	Must be insulated.
8	A-6	€-6	Continuity less than 1 ohm
9	8-5	E-5	- ditto -
10	B-6	E-3	- ditto -
11	B-7	E-2	– ditto –
12	D-1	D-2	Must be insulated
13	D-1	E-2, E-3	Continuity less than 1 ohm
14	D-2	E-6	- ditto -

Continuity in all instances is less than 1 ohm, If more than 1 ohm, check very carefully for poor soldering connection or for a break in the wire.

1. Detachment of the Left and Right Magazine Side Covers

- 1) Strip off the film winder leatherette (A261970), loosen the right hand screw (8023102) and detach the manual film winder (A762200).
- 2) Strip off the right cover leatherette (A261960) sufficiently to expose the screws, then loosen two 8813357 screws and three 8873357 screws and, finally, detach the M. (megazine) right side cover. The M. left side cover (A261773) should also be detached in similar manner.

- Pointers on Attachment
 1) In order that the section indicated by the wavy
- In order that the section indicated by the wavy line does not protrude, locate the left and right M, side covers while attached to the film gate (see page 36).
 Washers B511202 may have to inserted in order to prevent contact with the rear cover (A761200, see page 37).
 Do not mistake the type and length of screws. × 2 13813457 B873257 A 261773 A269030 BLACK A260610 Leather Ø A160481 *B511212 *2 A261762 A 26 9020 0 BLACK G. A 261960 Leather 0 A261731 A269040(BLACK B831257 B813357 85112 12 ×3 A 762200 B023102 ď A261970 B873357 Leather

2, Spool Holder does not Close: Spool Holder Auxiliary Plate is Detached

- Exchange the M. left side plate set (A764200).


 1) Detach the M. left side cover.

 2) Loosen two B813257 screws and detech the left light-tight plate (A261792).

 3) Loosen four B893457 screws and take out the M. left side plate set, in the new M. left side plate set, the spool holder spring (A260351) is already riveted to the M. left side plate (#1) and, therefore, does not require bonding of the spool holder auxiliary plate (A260361) to the spool holder (A763410).

 Loosen two B823457 screws and locate the spool holder base (A260331) so that the spool holder does not hit (A) section on the M. left side plate (#1) and the detection of the spool holder base (A260331) so that the spool holder does not hit (A) section on the M. left side plate during its opening/closing actions.

 41 Change and attach the film plate indicator plate (A260372) to match the film insert.



3. Counter Dial does not Advance

Exchange in the following manner, when the pin (#1) of the counter roller shaft A (A764410) is broken.

1) Confirm broken pin by detaching the M. right side cover (see page 29).

2) Loosen the four 8062066 setscrews of the frame counter roller A (A764400).

3) Loosen four B893457 screws and detach the right light-tight cover (A763830).

4) Take out and exchange the counter roller shaft A.

Pointers on Assembling the Counter Roller Shaft A


1) Tighten four 8062066 setscrews at the height required for properly engaging the pin (#1) and geer (#2) of the counter lever (A763210).

4. Adjusting Film Start

Distance from start-mark to the first frame:—
120 roll film 205 to 235 mm
220 roll film 215 to 255 mm Adjusting the location of the counter dial stopper (A261470)

Movement in A direction — Delays appearance of the first frame.

Movement in B direction — Speeds up appearance of the first frame.




5. Counter Dial does not Return

- 1) If the counter dial returns when the M. (magazine) right side cover (see page 29) is detached, then attach washers (B511212/B511222) with bonding agent, as explained in "1. Detachment of the Left and Right M. Side Covers" on page 31.

 2) Check rotation of the gears on the counter lever (A763210) and, if not smooth, exchange, (See page 33.)

 3) Check whether there is dirt or other foreign particles caught in the gear teeth and, if so, clean.

 4) Reverse the counter dial (A261463) slightly with a pincer, from its stopping position. If the counter dial spring (A261891) should move, with the operation, the counter lever spring (A261921) is in contact with the counter dial and, therefore, the dividing plate set (A763100) should be exchanged. Exchange the dividing plate set for one in which the hooking point of the counter drive gear C (A763131) is a groove instead of the previous hole. When making the exchange, edjust the position of the wind stopper name (A261391) as explained on page 35. wind stopper pawl (A261391), as explained on page 35.



6. Winding Action does not Stop

The film back signals the body when to stop the winding action by protruding the F. (film) release pin (A260990) 4 to 4.3 mm above the standard attachment plane (surface) (height of the F. release cylinder A is 4 mm). Therefore, detach the film back from the body and check height of the F. release pin.

- If not 4 mm, detach the M, right side cover and repair in the following manner:—

 1) If the dividing plate (#1), dividing auxiliary plate (#2) and wind stopper pawl (A261391) are deformed, exchange the dividing plate set (A763100) and wind stopper pawl.
- 2) If the F. release shaft B (#3) is caught on the F. release cylinder B (A260961), then round the tip of the F. release shaft B, or if the hole is too tight, then slim the shaft down.
- 3) If the F, release shaft (A763840) is too short, loosen the F, release shaft nut (#4) and adjust the length of the F, release shaft A (#5) by screwing it out. Tighten the nut securely after making the adjustment.


7. Improper Frame Interval

The rotation of the counter roller shaft A (A764410) is in proportion to the advance of the film. Therefore, a line extended from the two pins on the counter roller shaft A must always be constant in its position between the dividing plate exis (C) and the wind-up gear D exis (D).

1) If the extended line from the two pins is not directed (not located) between points C and D, adjust by moving the wind stopper

- pawf in the arrow-indicated direction at (B).

 2) If the extended line from the two pins is directed (located) between points C and D but its location or direction is not constant, then exchange the dividing plate set as the grooves #1 and #2 may be deformed.
- 3) If the wind stopper pawl is contacting the outer rim of #2, adjust the location of the wind stopper pawl in the arrow-indicated direction at (A) so that the F. (film) release pin protrudes 2 to 2,3 mm from the standard attachment plane (surface). (do not change the length of the F. release shaft when undertaking this adjustment.)



8. Film is not Advanced: Spool Clutch Spring is Broken

The wind-up gear A (#1) rotates even when the spool metal (A261313) is prevented from rotating.

13 Open up the bottom of the spool holder on the left side of the film back and detach the upper spool shaft (A261320) by stopping rotation of the wind-up gear D and, at the same time, rotating the upper spool shaft to the right.

2) Then, rotate the spool clutch axle (A261293) to the right, too, and detach.

- Wind the replacement spool clutch spring (A261882) around the spool clutch axie so that it does not overlap itself.
- 4) Assemble the spool clutch spring so that it is hooked on the grooves of the wind-stopper ratchet (A261302) and the spool metal and, then, tighten the upper spool shaft.

CAUTION:

Hold the wind-stopper ratchet from rotating and rotate the wind-up gear A (#1). The upper spool shaft should rotate but the spool metal should not, in this case. If the latter also rotates at the same time, the trouble may be due to:—

Deformed grooves of the dividing plate and dividing auxiliary plate.

Bent wind stopper pawl.


3) Broken pin of the counter roller shaft A, etc.

9. Unusual Noise with Winding Action: Grease has Dried Up in the Spool Clutch Axle

- 1) Noise caused by abrasion of the spool clutch axle and spool clutch spring is heard when the winding stopper lever
 - Apply Liqui-Moly on the spool clutch axle and spool clutch spring.
 - Liqui-Moly is a molybdenum disulfide lubricant evailable from Lockrey Co., Ltd., U.S.A.

CAUTION:


The wind-up gear bearing plate should be fixed with two B825307 screws at the position in which rotation of the wind-up gear train is smooth.




Spool metal bearing set


10. Others

- Exchange all plastic wind-up gear B's (A261252) for metallic parts.
 Pressure plate (220) (A262023) is stepped on both sides.
 The exchange of the pressure plate to which the pressure plate pin (A260463) is riveted also requires exchange of the pressure
- plate pin.
 4) Assembly of the pressure plate with its top and bottom sides reversed will result in contact with the frame counter roller A and B (A764400 and A764500) and, therefore, it should be assembled properly.



Film Gate I





11, Film Gate Set

- Exchanging the rear cover (A761200) for one that will double-lock (has a safety lock) means that the rear cover on page 38 will be changed to that on page 39.
 When attaching the top cover (A761140) and bottom plate (A260856), attach so that they do not protrude beyond the standard attachment plane (surface) (the *-marked surface of A260804).
 The top cover numbers should be unified at M52 ---, for 120 roll film, and M53 ---, for 220 roll film.
 The bottom plate should be located so that F. release pin (A260990) moves lightly when it is attached.
 The gate roller plates (A260874 x 2 and A260690 x 2) should be fixed in locations which will permit the two gate rollers (A260861) to rotate smoothly and thus prevent scratches to the film.

The 75 mm F2.8 Zenzanon-E Lens is representative of the five lenses (40 mm, 50 mm, 75 mm, 150 mm and 250 mm) presently available for the Zenza Bronica ETR single lens reflex camera. The other lenses can be repaired in practically the same manner. Troubles occurring in the lens may actually be due to reasons on the camera body side and, therefore, it is important that the proper repairs be made in such instances. A simple method of checking the actual origin is to attach the saim lens to another camera body and/or attach another lens to the original camera body and see whether the defects still occur.

(1) Shutter Blades do not Open (when the Shutter Release Button is Depressed)


Check rotation of the setting ring unit (A710220). After setting the unit, press the locking lever (A210213) on the side of the bayonet mount and then return the setting ring unit. If it feels tight or seems to catch, then it should be exchanged. Repair in the following manner:—
1) Loosen six B833407 screws.

- Loosen four B893307 screws and detach the printed circuit board (#1).

 Attach the printed circuit board to the replacement setting ring unit with the four B893307 screws which were detached in 2) above.

 Align the lever sections (#2) of the setting ring unit to the grooves of the shutter assembly.

 Repeat the setting and releasing actions and check the movement.



(2) Preset Action cannot be Confirmed (when Preset Lever is Pressed)


The shutter assembly is manually stopped down, by pressing preset lever (A210301) which, in turn, pushes preset arm set (A710120). Repair in the following manner (when the preset arm set does not move):—

1) Loosen three B853557 screws and detach the aperture ring block (#1).

2) Check movement of the preset arm set (A710120). If it does not move, then—

3) Loosen A210423 and A210433 screws and detach the preset arm set.

- Since a change has been made in the surface painting of these three parts (in 3, above), they should all be exchanged for new replacement parts, in this case.
- Assemble the aperture ring block while carefully checking alignment with the shutter actuating lever of the shutter assembly, the position of the time exposure lever and the positions of two aperture setting arms.



(3) Exchange of the Shutter Assembly

Disassemble the setting ring unit and aperture ring block, based on instructions in 1 and 2 preceding.

1) Detach light baffle ring (A210531) carefully so that it is not deformed. (Pull it out slowly as it is attached with bonding agent.)

2) Disconnect the six lead wires soldered to the printed circuit board.

3) Loosen two 8063026 setscrews of the fixing ring (A210152) and revolve the fixing ring. The lens and shutter assembly will come out together, in this case.


Revolve the locking ring on the outside of the lens which will permet detachment of the lens.

Detach the time exposure click-plate (A210162) from the detached shutter assembly and attach it on the replacement shutter assembly.

CAUTION:

- Direction on the process of the adjustment liners (A210171) even when the shutter assembly is exchanged. The interval between lens elements is determined by the thickness of the shutter assembly. Therefore, screw in the lens element to its end so that there is no apparent clearance between the lens element and the shutter assembly.

 Lens elements are only supplied with front and rear groups as a set, with the adjustment liners also specified at the
- time of exchange.



	· · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·
1-255670-AJ Screw driver	8 0	1-255670 for Crank catch setting screw.
1.256593-AJ Screw driver	97 5	1-256593 for Cabłe release socket.
1-255790-AJ Socket driver	123 depth 1	1-255790 for Winding stopper claw spring holder. 1-230700 for Crank axle B (Speed grip).
1-250160-AJ Socket driver	0 depth 1.5	1-250160 for Dark slide relay lever axte.
1 · 255230 · AJ Wrench ·	5.12	1-255230 for Cam holding nut.
1-250130-AJ Socket driver	97 depth 1.5	1-253561 for Bayonet pin spring holder 1-253772 for AE changeover rod guide.
1-252391-AJ Socket driver	δή δ depth 1	1-750050 for Flash synchro socket (old ty pe).
1-252394-AJ Screw driver	88	for Flash synchro socket (new type).
1-261550-AJ Screw driver	1 4.6	1-261552 for Dividing plate axle.

1-250211-AJ Socket driver	S. 1 1 3	1-250211 for M switch lever axle.
1-256060-AJ Screw driver	000	1-256060 for Button ring nut.
1-253951-AJ Socket driver	depth 5	1-253951 for Lens safety link guide.
1-251280-AJ Screw driver	FI 03:50	1.251280 for Mirror arm setting screw.
1144-AJ Free size wrench	20-50	
1-210180-AJ-3 Wrench	30.	for 75 mm Front lens ring nut.
1-210180-AJ-4 Wrench	30,	for 75 mm Rear lens ring nut.
1-210482-AJ Rubber barrel	85.4	for Lens name ring.

1-260961-AJ Screw driver	\$15 P	1-260961 for F release cylinder B.
1-261611-CT Stroke adjusting tool	2)	1-261600 for F release shaft A.
CT-301 -302 -303 Camera length standard	CT302	1-252227 Lens mount (Use with surface plate and dial gauge) Set dial gauge "0" with total length of 3 tools, then put carnera body on the CT-301, and put CT-302 on the lens mount (1-252227) of the body, CT-303 is taken out. See dial gauge meter and adjust the length of the carnera body.
	CT 303	
	CT 301	

1148-AJ-1 Wrench	15 D	for 250 mm
1148-AJ-2 Wrench	5	for 250 mm
1·252280·AJ Wrench	\$9.8 \$\infty\$	1-252280 for Shutter button ring. 1-254010 for Lens button ring.
· 1-254080-AJ Wrench	068	1-254080 for Lens release button.
1-253571 Wrench	2.2.80	1-253571 for Lens button shaft
CT-318-1 -2 -3 Back relay action testing tool	CT318-1 B CT318-1	(Set CT-318-1 to camera body, and insert CT-318-2 and CT-318-3 to hole A or B.) CT-318-2, 9.5 mm Winding is stop, also release button is depressed. 8.5 mm Winding is not stop, also release button is not depressed. CT-318-3, 9.2 mm Back release button is depressed, also release button is not depressed. 6.2 mm Back release button is not depressed, also release button is not depressed.
	95 CT318-2 92 7B 92 7B	

1-754500-PT M switch set adjusting tool	Red lamp Green lamp Yellow lamp	1-754500 for M switch set M switch set is adjusted following manner. (Set to camera body with battery.) When winding is charged, the red lamp is ON, and half depressing of release button, the red lamp is OFF, next the green lamp is ON, the yellow lamp is ON during the shutter is open.
1-210150-AJ-2 Wrench	as of	1.210150 for shutter unit fixing ring.
CT-321 Winding stroke inspecting tool	C D A B D C C Shutter operating ring pin (#1)	(Set CT-321 to camera body without lens) 1) When mirror is upper position, the pin (#1) situates intervals A. 2) When winding is starting, the pin is reached line B simultaneously. 3) When winding is stop, the pin situates intervals C. 4) The pin is not over run line D under any conditions.




AE FINDER E

ZENZA BRONICA IND., INC.

Use of the VOM (Volt-Ohm-Milliammeter) Tester


- In general, the tester is used for four types of measurements of (a) DC current, (b) AC voltage, (c) DC voltage and (d) resistances,
- Measurements of (c) DC voltage and (d) resistance are undertaken in the repair manual,
- When messuring (c) DC voltage and (d) resistances, as indicated in (2), the reading must always be made between two points. One of the points (base) must always be P-9 (GND) when measuring DC voltage or, in other words, measurements are based on the ground (earth) point. Furthermore, the black-colored minus (-) test lead must always be used on the grounding terminal, in this
- (5) In the illustration of the tester range, measurements of DC voltage must always be made within the DCV range and measurements
 - The numerals 250, 50, 10, etc., in the DCV range, show the maximum reading that is possible at that setting. When checking the AE circuit of the ETR camera, however, only the three settings 10, 2.5 and 0.5 are used.
- The resistance settings shown as x100, x1K, etc., indicate the multiplications that must be made on the indicated reading and should be read as "times one hundred", etc. In other words, the reading must be multiplied by 100 which means that a reading of 10, when set to the x100 range, will be 1,000 ohms which is equivalent to 1 kiloohm. Or, in other words, the reading will be 1, in the same case, if the tester were to be set to the x1K range.

 Before making the resistance test, always be sure to calibrate the
- tester's circuit or, in other words, touch the two test prods together and adjust the knob (with the $\,\Omega$ indication) to get a zero reading.




CAUTION


Extra care is required on handling of Main Circuit (A222040) such as solder iron and working bench should be properly grounded.



ASA Base Plate (Mark: A)



(The above figure shows ASA100 setting)



Note: (P-8) represents point 8 of Main Circuit (P), and as is the same manner (C-5) represents point 5 of AE contact pin base plate (C).

AE Contact Pin Base Plate (Mark: C)





Fig-1








Fig-3


(1) Checking the Power System




(2) Checking the Power System




(3) Checking the AUTO Exposure System







(5) Checking the AUTO Exposure System



Note: (Resolder the green lead wire A-3-1 to the ASA base plate unit at A-3, upon completing the measurements.)

(6) Checking the AUTO Exposure System





Adjustment of the Exposure at the Film Plane

In addition to the AE Finder and ETR camera body, it will also be necessary to use the 75 mm Zenzanon-Elens, a VR adjusting driver, an EE Camera Tester (Model ST-70B1) or

equivalent and either battery or voltage regulator. Attach the AE Finder to the ETR body, as well as lens to the body, insert battery or connect the voltage regulator, etc., and adjust the exposure at the film plane, in the following manner:

(1) Set conditions to ASA 100, LV 11 and F8. Rotate VR4 and adjust to get exposure tolerance within

Clockwise rotation EV minus (-) direction.
Counter-clockwise rotation . . . EV plus (+) direction.
(2) Set conditions to ASA 100, LV 15 and F11 (1/250 sec.).

Check whether exposure is within ±0.3 EV.
(3) Set conditions to ASA 100, LV 7 and F8 (1/2 sec.).

Check whether exposure is within ±0.3 EV

(4) Set conditions to ASA 3,200 LV 7 and F8 (1/60 sec.). Confirm whether exposure is within ±0.5 EV.

NOTE:

If adjustments are not possible to the limits specified for the conditions noted for (2) and (3), after adjusting to zero EV (0 EV) under conditions specified for (1), then adjust by revolving VR2. However, in this case, alternate adjustments under conditions specified for (1) and (2). If, in the same manner, adjustments are not possible to the limit specified for the condition noted in (4), adjust by revolving VR3, If (1) is 0 EV and (4) is a +EV, in this case, revolve VR3 counter-clockwise.

If (1) is 0 EV and (4) is a -EV, revolve VR3 clockwise.

Adjustment of the LED Display Indications

The following adjustments must be made after completing adjustment of the exposure at the film plane, as otherwise

the display indications may not be correct. In addition to the AE Finder on the ETR body, adjustments will also require the 75 mm Zenzanon-E lens, a adjusting driver, an EE Camera Tester (Model ST-7081) and either battery or voltage regulator, in the same manner as for the previous adjustment.

(1) Set conditions to ASA 100, LV 7 and F8. Revolve VR6 and coincide the LED shutter speed indication to "2" when the display button is depressed.

(2) Set conditions to ASA 100, LV 11 and F8.

Revolve VR7 and coincide the LED indication to "30".

(3) Set conditions to ASA 100, LV 15 and F8. Confirm that the LED indication is "500", when the display button is depressed.

NOTE:

Should "250" or the over-exposure (>) mark appear in the case of (3), after the adjustments for (2) have been made as above, then revolve VR8 and adjust so that the LED indications for (2) and (3) are "30" and "500"

(4) Set conditions to ASA 100, LV 4 and F8 confirm that the LED indications is "4S".


(5) Set conditions to ASA 3,200, LV 4 and F8 and confirm


that "8" is displayed.
(6) Finally, confirm that the LED indication is "8" when

conditions are ASA 100, LV 9 and F8 and "4" when conditions are ASA 50, LV 9 and F8.

NOTE:

If the above LED indications do not appear when the display button is depressed, then revolve VR5 for making the appropriate adjustments.





1. Winding is not Possible


Strip off the winding lever cover leatherette (A230970) and winding lever cover (A230250) and tighten the exposed fixing screw (A230261, which is a left hand screw). (When tightening the fixing screw, hold the winding connector which couples with the film winding crank on the camera body.) If winding is possible with the winding lever (A730030), then undertake the following repair:


1) Take off the winding lever by loosening four 8813407 screws.

2) Loosen the three B893307 screws and detach the speed grip top plate (A230220).

- Since the winding claw (#1) of the winding wheel (A730050) is riding on the wind-stopper ratchet (#2), in this case, loosen the fixing screw (A230261) and then press on the part indicated as A, in the drawing, so (AZ3UZ01) and then press on the part indicated as A, in the drawing, so that the winding claw (#1) catches the wind-stopper ratchet teeth. (This operation should be undertaken without detaching the winding wheel, or in the condition shown in Fig. 2.)

 4) Apply Loc-Tite to the fixing screw (AZ3U261) and screw it in securely. 5) If the winding wheel is loose in the vertical direction, adjust with washers (B53U211).






2. Release Action is not Possible

- Check in the following manner:

 1) See whether the release pin (A230710) extends 3 mm more than the upper stopper pin (A230140), (If extension is insufficient, take off the bottom plate (A230790), loosen the release pin fixing screw (B813227) and then screw in release pin B(A230720) sufficiently to extend the release pin (A230710) the required amount. See page 4.)
- 2) Attach the Speed Grip to the camera body, without locking it. Next, push the Speed Grip towards the camera body or in the arrow-indicated direction in the drawing. If release action is possible, in this case, the stopper plate is loose with the result that the Speed Grip is away from the camera body and the release stroke is not long enough.

- Repair as follows:—
 1) Loosen two B833257 screws and two stopper pins (A230140) and take off the base plate (A230110). The stopper (#1) should be pushed down, when detaching the base plate.
- 2) Exchange the safety stop (A230100, #1) if its edge is rounded. Then retighten B825357 and A230130 screws.



3. Flash Synch is not Possible

1) The synch connector pin (#1) is not extended up to 6 mm from the stopper pin (#2) and, therefore, is not in contact with the camera body.

Repair as follows:

The connector pin (#1) is insert-molded in the new contact base (A230772) and, therefore, cannot slip out.


- a) Loosen two B815457 screws and detach the contact base.
- b) Disconnect the green-colored wire which is connected to the old connector pin (#1) and connect it to the new contact base, when making the exchange.
- 2) If continuity does not exist between the connector pin (#1) and the accessory shoe contact pin (#3), when tested, then -

 - a) Losen two B815457 screws of the contact base and check connection of the connector pin (#1) and the green-colored lead wire. If disconnected, re-solder properly.
 b) Pull out the accessory shoe base plate (A230810), loosen four B893457 screws and take off the accessory shoe mount (A230800). Pull up the contact pin (#3) slightly and check connection of the contact ring (#4) and the green-colored lead wire. If disconnected, re-solder, If the nut (B410057) is loose, the contact pin (#3) and contact ring (#4) will not contact
- while. It disconnected, re-solder, it has not contact and, therefore, the nut should be tightened strongly, too.

 3) When continuity does not exist between the accessory shoe mount (A230800) and the pressure plate (A23040), then —

 a) Loosen two B833257 screws and two stopper pins (#2), take off base plate (A230110) and check connection of #5 and the black-colored wire. If connected, re-solder properly.


 - b) Next, detach the accessory shoe mount and check connection of #6 and the black-colored lead wire. Re-solder if disconnec-



4. Disassembling the Grip Section

- Unscrew six 8833257 screws and detach the bottom plate (A230790).
 Unscrew three B823357 screws and detach the release pin guide (A230690).
 Detach spring A230750, take out crank B shaft (A230700) and then take out the crank B (A230680).
- Unscrew two A230170 screws.
- 5) Detach parts up to the winding wheel (A730050), as per instructions on
- page 1.
 6) Of the four setscrews fixing the winding shaft holder base (A730060),
- unscrew two and loosen one.

 7) Unscrewing the three A230180 screws will permit detachment of the grip section. However, since steel balls are inserted for smooth revolution, the side indicated with the star (*) (in the illustration) should always face





PARTS LISTS & REPAIR MANUALS

ZENZA BRONICA IND., INC.

- CONTENTS -

ETR/MOTOR DRIVE	
PARTS LIST .	
REPAIR MANUAL	
ETR/ZENZANON lens	es
75mm	Repair Manual41
40 · 50 · 150mm	Parts List & Repair Manual79

ETR / MOTOR DRIVE

Parts List & Repair Manual

MOTOR DRIVE Pcs.per Page Ass'y No. Price Remarks Parts No. Name Shape Unit 形 個数 頁 組立番号。 考 名 部品番号 1-231011 Main M.D. M·D 本体 1021 Battery box 1 バッテリィボックス 1031 Grift (left) グリップ(な) 1041 Grip (right) グリップ(右) 1060 Switch mounting plate スペッチ取付板 108! Switch nameplate スィック銘板 1090 Strap metal 2 ストラップを具 1100 Battery box fix plate バーテリーボンス国定板 1152 Face plate 化粧板 1161 Stopper ストッパ 1171 Locking shaft 締付軸

ETR

MOTOR DRIVE Posper Parts No. Name Shape Page Ass'y No. Price Remarks Unit 部品番号 称 形 個数 組立番号 単価 # 1-23/18/ Battery box cover fixing screw 1 転地 盖エネジ 1200 Battery box cover ・バッテリィボックス基、 1210 Locking lever 縞付しバー 1271 Release rod stopper いべ棒髪 1280 Release roller guide しり-ズコロ がてド 1300 Damper plate 緩衝板 1310 Damper member 緩衝体 1320 Damper rubber 緩衝でし 1330 Release rod レリーズ棒 1340 Release rear rod いぶ移棒 1390 R. button base) plate 尺ボタン地板

2

ETR

MOTOR DRIVE Posper Page Shape Ass'y No. Remarks Parts No. Name Price Unit 超立番号. 部品番号 名 称 . 形 個 数 頁 単 価 ŧ 1-231420 R button ring Rボタンリング" R. button ring stopper ボタンリンフ"よ 1440 Release button Rボタン /450 R. button axis A 1 アボタン韓中人 1460 R. button axis B ١ Rボタン軸 B 1470 Internal base plate 内地板 1500 G2 base plate Gz地板 1510 Gl gear G. #7 1520 G2 small gear Gzhf? 1530_{G2 large gear} Gz スギア 1541 Spring bearing バネ受りニグ

ETR

MOTOR DRIVE Posper Parts No. Name Shape Page Ass'y No. Price Remarks Unit 部品番号 名 秼 . 形 抺 倜数 頁 祖立番号。 単 価 # 1-231601 G2 bearing 2 Gz軸受 1611 G4 bearing 2 G4軸受 Windinglahaft ball bearing 捞上轴受 1630 Winding gear 捲上臨車 1641 Winding gear shaft 搭上船舶 165 Winding ratchet wheel 捲上爪車 1661 Winding shaft nut (large) 捲ヒナルス /67/ Winding shaft nut (small) 捲上がトル 1680 Belleville spring 7 ベルビルスプリンク" 1691 Winding shaft 搓上軸 1710 Wind stopper pawl 1 枪止肌

ETR

ZENZA BRONICA ETR MOTOR DRIVE

Parts No.	Name	Shape	Posper Unit	Γ	Ass'y No.	Price	Remarks
部品番号	名 称	形状	個数	頁	組立番号	単 価	備考
1- 231 720	Set cam	(0)	t				
	セットカム	<u> </u>					
1731	Coupler ring 経身精	000	1				
1750	Winding eccentric collar - 後上(隔ぐわう-	8	1				
1772	Coupler face ring 維手化布翰		t				
1791	Set rod 七小棒	9					
1820	Setting groove plate, セット作動活動物		1	-			
1830	Solenoid guide holder ソレノイドガイド 受						
1840	Set rod axis holder セオ棒軸受		ı			·	
/850	Solenoid stopper		•				
1- 23 2030	Reset lever			-			
. 2051	Winding shaft bearing 楼上動変	Person	ŀ				

ZENZA BRONICA MOTOR DRIVE Posper Parts No. Page Name Ass'y No. Price Remarks Shape Unit 部品番号 名 秼 形 状' 個数 組立番号 1-232061 Reset cam holder ١ リセット加押エ 2072 Reset lever holder リセットレベー 押エ 2/60 Circuit board collar 基板がっ 2170 Shoe plate 1 シュー台 2/80 Drive button Ι. 送りボタン 2190 Drive button collar 送りボタンカラー 2211 Release eccetric collar 解除偏心がっ Z221 Grip leatherette グリップ良 2231 Front cover leatherette 前加心皮 2240 Bottom rubber 店ゴム 2250 Hand strap ハンドストラッフの

MOTOR DRIVE Posper Page Ass'y No. Price Remarks Parts No. Name Shape Unit 状 租立番号 個 数 頁 単価 ħ 部品番号 名 林 1-232280 Selftap screw 4 セルフタップネジ 229/ Face plate pillar 化桁板柱 2300 Motor モーター 2310 Solenoid ソレノイド 2370 Power switch 電源スペケ 2330 Limit switch 3 りミットスイッチ 2360 EXT B. socket EXT. B. Yryh 2370 R.C. socket REMOTE YTYL 2390 LED board LED基板 1-232740 Release rod spring holder し)一大棒バネ受 1-236160 Tripod screw socket 三脑冲沙及

ETR

Pcs.per Page Shape Ass'y No. Price Remarks Parts No. Name Unit 形 租立番号 倒 数 頁 単価 #; 部品番号 状。 1-251460 M. arm screw (right) Į ミラー アーム 止ネジ (な) 5881 Wind stopper pawl spring 2 茶ン 爪ょ鉢 1-157500 Battery label В 電池ラベル 1-730040 Pressure plate 押板 0051 Leaf spring 2 柿べえ 0060 Lock adjusting ring . 回戰子 0080 Locking lever Z catch 卷上午掛 ooq Stopper plate ストッパ杯 0/40 Stopper pin Upper 2 ストッパピンよ 0/50 Stopper pin 2 lower ストッヘッセッド 0180 Grip coupling 合セネジ

ETR

MOTOR DRIVE

ZENZA BRONICA ETR			MC	MOTOR DRIVE								
Parts No.	lo. Name		Shape		Posper Unit	Page	Ass'y No.		Prioe		Remarks	
部品番号	名	称	形	I	数	Ą	組立番	号	車	価	備	考
1-230190					3							
	回転3ネジ		-			· 	-					
0430 Crank catch 能多種		<u>SU</u>	S	i								
	सह ज्या	~						_				
0460	Joint gu roller 経子ピ				2							<u> </u>
0800	Shoe mou				ţ		-					
	-22	(42										 -
0810	Shoe bas シューイ	se plate 比米压材		3	-							
0820	Shoe insplate	sulator 3条表本	E		\							
0831	Shoe compoint				ł			į				
0876	Shoe in: collar 含一紀	sulator 発力ラー	0		I							
088	Shoe lud	-	6	9	1		,					
0890	 	unt cover			 .				-		 	
	3-2-7	<u>k</u>	- Consultation		•							
0160		ate stud	0		l							
	化粧木	スペンズ屋あみ				ĺ	<u> </u>					

Parts No. Name Page Ass'y No. Shape Price Remarks Unit 部品番号 貅 形 個数 組立番号 1-731390 Release operating plate set しりース、作動板セット 1400 Release guide plate set レリーズがイドネ友でっ人 1430 Release plate set レリース板セット 1440 Release base plate set レリーズ地板をい人 1470 Medium base plate set 中地板也水 1480 Set crank set セットクランクセッ人 1490 M arm set MIT-ムセット 1500 Y arm set YP-ムセット 1510 Operating element set 作動片セット 1520 Release, lever set 解除しがしもっか 1530 Set connecting plate set

ETR

MOTOR DRIVE

MOTOR DRIVE Pcs.per Shape Page Ass'y No. Price Parts No. Remarks Name Unit 個数 頁 租立番号 部品番号 単 価 考 1-731540 G4 gear set GA FREGL 1550 G3 gear set Gヨギアセット 1560 Outer base plate set 外地板も小 1570 Reverse ring set 逆転輪もった 1590 Reset cam set りセットカムセット 1610 Winding base plate set 港业地板电水 1620 Switch holder plate set 3 スイッラ押工板も小 Winding stop lever set 槎止ルバーセット 1670 Winding ring set

ETR

ETR ZENZA BRONICA MOTOR DRIVE Posper Page Parts No. Shape Ass'y No. Name Price Remarks Unit 形 部品番号 組立番号 単 価 名 個数 頁 備 考 1-731340 Contact plate set 接兵板セット 1350 Battery case (left) バッテッソーケース(左) 1360 Battery case (right) バッテリケーケース(右) 1370 Battery cover set 電池蓋セル 1-732340 LED set (red) LDEEnst 2350 LED set (green) LDEEDL 2404 MD printed circuit board MD基板 1-731650 Winding gear set 境上電車でいた

Posper Shape Page Ass'y No. Price Remarks Parts No. Name Unit · 影 祖立番号 単 価 部品番号 個数 Ŧ, 名 称 5-0/3/5/Operating plate stopper 2 作動极止X 0/4082 Operating element stopper 作物片止义 014107 Grip stopper グリップ企× 023832 Set rod fixing screw セット福止メネジ 024236 Coupler ring stopper 維生輸止メ 063066 Ml.7 set screw Θ HI.7セットビス 31163||Guide roller ガイドコロ 312321 Set operation roller セット作物コロ 312351 Operating plate 2 roller 作動板コロ 376022 Widing axis collar 換上軸ガラー 4600/7 Fixing nut 固定ナル

ETR


MOTOR DRIVE

MOTOR DRIVE Posper Page Price Remarks Parts No. Shape Ass'y No. Name Unit 単 価 考 形 個数 頁 組立番号 部品番号 名 秼 状 5-504064 E ring (E-32) モリング (モ-32) 504164 Spring washer 3 スプリングワッシャ 54102|Winding axis washer 捣 · 軸 在金 60790 M arm spring **CWWWW** M丁ームペネ 6/0800 Solenoid spring CWWWD ソレノイドベネ 610810 Operating plate CWWWWD S spring 作動板バネ 620290 Release rod **WWW** spring ひかな棒べる 620300 Solenoid set **WWM** spring ソレノイド セ・トベネ 620310 Release spring A WWW. い)ーズバネ A 620320 Release spring B い)-ズベネB 631560 Release arm spring ١ 解除アームべネ


ETR

MOTOR DRIVE Posper Parts No. Shape Page Ass'y No. Name Price Remarks Unit 部品番号 名 称 彤 個数 頁 状 組立番号 単 価 考 5-631570 Winding spring 捻上用バネ 631580 Release plate spring い)-ズ板バネ 631590 Set crank spring セットクランク用バネ 63/600 Operating element spring 作動片バネ 631610 Reset spring りセットベネ 63/620 Damper spring 緩倒水水 620010 Spring スプリーグ

ETR









€ 8-833201 + 2


5-420075 E-420016 🕏 5-610 810 MATERIAL . 1-731390 \$-312351×2 | \$ ਊ 5-633307×2 F1-731400 5-8 23407×2 5-61081J 5-923187 **×2** 1-231300 5-813187 ×2 € € 15-013151 x2 **3** 5-500334 1-231330 5-4200161 6 **5**-8131**87**×2 1-231280 1-231271 1-231240 **№** 5-813157 × 2 1-232740 5-825357×4 @ 1-731440 <u>— 18 —</u>

ETR MOTOR DRIVE






Peel off the grip leather (1) (1-232221). Remove the shoe face plate (2) (1-232810), and then remove two screws, (3) (self tap screw, 1-232280), and one self tap screw (4) (5-873407). Refer to the following diagram for position. Remove a screw (5) (M4 screw 1-232710) at the right side of grip and 3 screws (6) (M4 screw 1-232720), and then remove the grip right (7) (1-231041) in the direction of an arrow. Use a Philips type screw driver of No. 2 for screws (5) and (6).




Remove 2 selftap screws (1) (1-232280), and 1 selftap screw (2) (5-873407), and the shoe base (3) (1-232170). The drive button set (4) (1-732180), and LED set (5) (1-732200) can be detached. Remove two selftap screws (6) (5-883407) and (7). Remove (2) selftap screws (8) (5-885507) and (9). Remove 1 M2 screw (10) (1-825357). Remove the screw (11) (5-014107) at the front of grip left with a minus screw driver, and remove 4 M2 screws (12) (5-825507) at the front and rear of grip. As to the above, refer to the following diagram. Raise the grip left (13) (1-231031) in the direction of arrow (A) and then remove it in the direction of arrow (B)




HOW TO REMOVE THE BATTERY BOX

- Remove 2 screws ② (5-833257), and 2 stopper pins ① (1-230140), and remove the face plate ③ (1-231152).
- 2. Peel off the front cover leatherette (4) (1-232231), and remove 6 screws 5 (5-833307) and then remove the battery box cover (6) (1-232200).
- 3. Remove the bottom rubber \bigcirc (1-232240) and a screw \bigcirc (5-835357), and then remove the battery box fixing plate \bigcirc (1-231110).
- 4. Remove 3 screws (0, (1) and 4 screws (2), and remove the battery box (3) pulling it downward.



THE RESET LEVER IS NOT PROPERLY RETURNED. (HOW TO REMOVE THE RESET LEVER)


- Remove 2 screws (1) (5-815307), and then remove the coupler face ring (2) (1-231772), washer (3) (5-520631), coupler wheel (4) (1-230430) and coupler pin collar (5) (1-230460) in order.
- Remove the screw (a) (coupler wheel stopper 5-024236), washer (7) and (10) (5-560101), and winding axis collar (11) (5-326022).
- 3. Remove a screw (1) and reset lever holder (8) (1-232072) with spring attached.
- 4. Remove a screw 1 and detach reset lever 9 (1-232030).
- 5. In case the reset lever cannot be smoothly returned due to the narrow gap of the base plate, insert an adjusting washer (2) (5-511461) at the position of Fig. 1 and install (9).
- 6. In assembling, wind the spring (8) up to such a degree that the position of hook is set at the position shown in Fig. 2. In installing (2), it should be adjusted to the red mark at the position where the set cam fell.



ADJUSTING METHOD OF THE POSITION OF WIND STOP SWITCH (1)

ADJUSTING OF POSITION AT WIND WHEEL SIDE

- In case the wind wheel cannot be returned upon completion of winding, or the wind wheel is stopped at the overload position due to no reversing of wheel. (the wind stop pawl at the camera side is not released.) The reason is that the wind stop switch is released too early.
- 1-1 Remove (1) through (5) at the wind wheel side.
- 1-2 Loosen 3 screws (7) (5-826307), and (8), and rotate the wind wheel (9) (1-731670) counterclockwise (in the direction of A, slower side, in Fig. 1) against the coupler ring (10) (1-231731) by means of the wind eccentric collar (6) (1-231750). Upon completion of adjustment, apply screw-lock to screw (7) and (8) (4 places).
- 1-3 In installing the wind face firmg (2) (1-231772), adjust the red mark to the position where the wind stop switch falls.




- In case the returning motion of the wind wheel is strong at the completion of winding, or the wheel is stopped due to overload. The reason is that the wind stop switch is released immediately before or after the wind stop position.
- 2-1 Remove (1) through (5) at the wind wheel side.
- 2-2 Loosen 7 and 8, and rotate 9 clockwise against 10 (in the direction of 8, faster side) by means of 6 Upon completion of adjustment, tighten 7 and 8 with screw lock.
- Confirmation of adjustment

Adjustment is properly accomplished if the wind wheel is reversed slightly after MD has been once operated for winding using 7V external power source.

ADJUSTING METHOD OF THE POSITION OF WIND STOP SWITCH (2)


Adjusting of position at wind stop switch base plate side (This adjustment is to be performed when the amount of adjustment at the wind wheel side is inadequate.)

- 1. Remove the grip right and grip left.
- 2. Loosen 3 screws (1) (5-823307), and make adjustment by deviating the wind stop base plate (1-232000). Move (2) further in the direction of (A) (Fig. 1) in case the amount of adjustment in the direction of (A) is inadequate at the wind wheel side. Move 2 further in the direction (B) in case (B) is inadequate.
- 3. Upon completion of adjustment of 2, confirm that the switch 3 is not pushed by undue force when 6 pushes 5, and the switch element is securely pressed. If the switch 3 is pushed by undue force, adjust the position of switch 3 by means of screw 4 or 1.



THE SHUTTER IS RELEASED WHEN THE RELEASE BUTTON IS PUSHED BUT THE WIND WHEEL IS STOPPED AT OVERLOAD POSITION UPON COMPLETION OF WINDING


- When the coupler wheel fail to stop after making one turn as the contact pin is short-circuit with the base plate at + side. Remove the grip right and causes (A) and (B) shown in Fig. 1 to short-circuit. When external power source is used, touch A with a finger.
- 1-1 Remove the grip right and grip left.
- 1-2 Check whether the microswitch ③ (1-232330), is operated or not when the wind stop pawl (1) (1-231710) pushes the wind stop lever ④ (1-731630) to its extreme position after the wind axis has been rotated. If it is not pushed, adjust the position of the switch by means of a screw 5. In this case, ④ should not push ③ with undue force (Fig. 2). The motor should stop when the switch ③ is once pushed and then released.
- 1-3 After 1-2 adjustment, if the motor fail to stop even if the contact pin and base plate (printed board) at + side are caused to short-circuit, check wirings and printed board. (refer to the section of electric components)



- The coupler wheel stops after making one turn when the contact pin is caused to short-circuit with side of the printed board.
- 2-1 Timing of the wind stop switch (4) is slow. As to its adjustment, refer to the adjustment of wind stop switch.


ADJUSTING METHOD OF STROKE OF RELEASE ROD

- 1. Adjustment of the protruding amount of release rod.
- 1-1 Remove the grip right and grip left.
- 1-2 Fix the release rear rod ① (1-231340), and loosen the M17 nut ② (5-420016). The rear rod ② is fixed by using lø hole. (Fig. 2)
- 1-3 When the protruding amount of ① is small, rotate the slot of ① clockwise, and when it is large, rotate it counterclockwise. At this time, ② should be kept fixed. (1 moves 0.35mm by a turn.) After adjustment, tighten nuts ② and ⑦ securely and apply screwlock.
- 1-4 (A) should be adjusted to about 2.5mm when the release operating plate (3) (1-731390) is at the position shown in Fig. 1.
- 2. Adjustment of retired position of release rod
- 2-1 When the position of release rod is protruded than the lins (B) (Fig. 3), move the release rod spring holder (B) (1-232740) in the direction of arrow (refer to Fig. 1). It should not be protruded outside line (B).



THE SHUTTER IS NOT RELEASED ON CAMERA SIDE WHEN THE RELEASE BUTTON IS PUSHED


- In case the red LED is lighted (for about 0.2 sec.) but the release pin is not caused to operate when the release button is pushed by MD single unit (after alined red marks).
- 1-1 Remove the grip right, and remove the screws, M 1.7, of the circuit printed board.
- 1-2 Remove the release arm 4 (5-731320), in the direction of arrow, check the movement of solenoid axis (i) (1-232310) with the release operating plate kept in disengaged condition. It is in good condition if the plunger which is attracted by a magnetic screw driver temporarily, is released by the force of a spring when the release button is pushed. If it is not released, check the portion of Afor sliding condition (Fig. 2).
- 1-3 When the plunger is found to be smooth in sliding, move the position of @ in the direction of arrow (Fig. 3) by loosening the screw of release eccentric collar ③ (1-232211). At this time, the amount of adjustment of ③ should be kept minimum at which the release operating plate can be released by the solenoid spring. (Be sure to confirm that release operating plate can be set by @.)
 - 1-4 If the solegoid is not released by the test of Par. 1-2, check (1) for broken wire or short-circuit. (Refer to the section of electric circuits.)
 - 2. When the red LED is not lighted as the release button is pressed.
 - 2-1 Check printed board and LED, etc. (Refer to the section of electric circuits.)




THE OPERATION OF MD SIDE CANNOT BE STOPPED EVEN IF FINGER IS FREED FROM THE RELEASE BUTTON (SINGLE FRAME PICTURE TAKING CANNOT BE MADE.)

- In case the release operating plate cannot be set even if the reset lever has been set.
 (The release pin is protruded as the reset lever is moved back.)
- 1-1 Remove the grip right.
- 1-2 Aline the wind wheel to the red mark. (At the position where the set cam falls.)
- 1-3 Set the plunger of colenoid (1) (1-232310) by pushing it inward with a screw driver.
- 1-4 Under the condition of 1-3, check the engaged amount of the release arm ② (5-731230), and release operating plate ③ (1-731390). If ③ is not engaged with 2 when the reset lever is set, increase the amount of engagement by moving the position of release eccentric collar ④ (1-232211) in the direction of arrow. (Fig. 1)
- 1-5 Set the set cam (8) (1-231720) at the position where it pushes up the set crank \bigcirc (1-731485) at its uppermost position. (Fig. 2)
- 1.6 At this time, adjust the position of (1) so as to obtain a gap (1) of 1 to 1.2mm of solenoid set rod (5) (1-231792). In case this gap is absent, the talease operating plate is released ismediately effect working has been completed since the setting of solenoid is one properly performed by the notation of the wind wheel. (Fig. 1)
- 1-7 The position of solenoid can be adjusted by means of screw (5) after removing grip left and the wind stop switch base place.
- 2. In case the release operating place is not as the relat lever to set.
- 2-1 When the release operating plate is set with the power switch kept off, and it is not set when the switch is on, thack the solenoid for its wirings and printed board.


 (Refer to the section of electric circuits.)







MOTOR DOES NOT STOP WITH AN OVERLOAD APPLIED. (IN DRIVING FILM, THE MOTOR DOESN'T STOP EVEN IF THE FIRST FRAME IS FED.)

- 1. Remove the grip right, grip left and printed board.
- 2. Remove 2 screws ① (5-024032) and 4 screws ② (5-825357) and then remove the outer base plate ③ (1-731560).
- 3. Remove E ring of the wind axis 4 (5-504064) and pull out the wind gear set 6 (1-731650).
- 3-1 When built-in jigs are used for the wind gear set (Fig. 2)
 In Fig. 2, remove a winding small nut (8) (1-231670) tighten the large winding nut (9) (1-231660) so as to cause the wind gear (1) (1-231630) to slide at a pressure of 18 to 21 kg·cm when the wind pawl (13) (1-231650) is fixed. Tighten (8) with (9) held in position, and then fix (8) and (9). Be sure to coat screwlock at nuts.
- 3-2 No jigs are available. Replace (6).
- 4. In assembling this parts, coat grease containing MoS_2 to the gear teeth of new gear wheel





- 1) Remove battery box side (Refer to a separate diagram.)
- 2) Slide the tightening lever (1-231210) so as to have 3 rotor screws (1-230190) seen through those of 12 holes of the MD main unit, (1-231000).
- 3) Remove the rotor screws by inserting a screw driver through the hole of MD, and make adjustment by changing the position of holes of rotor (1-230060) in relation to the tightening lever. The degree of tightening becomes stronger as the position of hole is shifted in the direction of A side as shown in the above diagram. It becomes weaker in sequence as the lever is moved in the direction of (B) side.
- 4) Insert a tripod shoe of ETR camera and see how tight it is. If tightening is weak, make adjustment by moving a tightening hole in the direction of (A) side by using a pincettes after removing rotor screws. Tighten rotor screws with care as they are self-tap screws.



Control Circuit of MD

(Theory)

The time at which an ETR camera equipped with MD film is desired to be at such a time immediately after the shutter has been closed. As the lens shutter is closed, the power source of the ETR camera is turned OFF.

A signal generated by the turn OFF of power source is transmitted to its MD through a contact point pin, and is used as a timining signal to cause the wind motor to become ON.

The ETR camera does not generate a signal informing the completion of winding operation.

However, a winding of film is accomplished by a full turn of the crank wheel. Consequently, it is designed to stop the motor by detecting a point where the crank wheel completes a full turn at the MD side.

The shutter is released by the release pin which is pushed by the spring which has been set simultaneously at the time of film winding.

F.F. Circuit

Upon receiving a signal from the camera informing the closure of shutter, MD causes the motor to become ON and then to become OFF after the wind wheel makes a full turn. Therefore, MD is required to keep the motor ON for a certain period of time from it is turned ON until it become OFF. For this purpose, MD utilizes a flip-flop circuit (FF circuit).

The FF circuit is reset as R input enters, and Q becomes low level and \overline{Q} becomes high, and then Q becomes high level and \overline{Q} becomes low level when S input enters.

In addition to ON and OFF control of the motor, the FF circuit is also used to maintain film driving condition when the drive switch is pushed and also keep the overload lamp ON.

Description of Operation of Circuit

A signal informing the closure of sector of shutter from terminal (Mg), enters the shutter closure detection detection circuit (A), through contact point PIN. Upon detecting the closure of shutter the detection circuit (A) sets the motor control FF circuit B causing the motor drive circuit (C) to become ON and the motor starts to operate.

As the wind wheel makes a full turn by the rotation of motor (immediately before the red mark of coupler wheel is alined), the wind stop switch is turned ON (at the time when the knob of switch is protruded, other switches are ON with their knobs recede.) and FF(B) is reset.

By the reset of (B), the motor drive circuit (C) is turned OFF causing the brake circuit to become ON and motor will be stopped with brake applied.

The release control circuit (E) causes a current to flow through the solenoid (F) and the red (G) for about 0.2 second when the release switch is turned ON with FF(B) kept reset, or when FF(B) is reset with the release switch is kept ON. The solenoid (F) keeps to attract the plunger with its built-in permanent magnet.

As the magnetic force of the permanent magnet is negated when a current flows through the solenoid, the plunger is pulled out by the force of a spring.

By the action of plunger, the pawl of a spring which pushes out the release pin is released.

MD has a driving mechanism for driving the leader tape portion of a roll of film.

As the drive switch is turned ON, the drive control FF(H) is set and then the motor feed control FF(B) is set. In Other words, the motor is turned ON.

The wind stop switch which is turned ON by a full turn of the wind wheel attempts to reset FF(B), but a signal from the wind stop switch is disregarded by FF(B) which is supplied with the output of FF(H).


The camera stops to wind when the first frame of film is fed to the designated position after the leader portion of a roll of film has been wound. After that the motor becomes overload condition as it attempts to rotate further, and by this, the overload detection circuit starts to operate and reset FF(H) and FF(B) and then set the overload display FF(J). By the reset of FF(H) and FF(B), the motor becomes OFF.

By the set of FF(J), the overload display circuit is caused to operate and causes LED (G) to light.


LED(G) keeps to light until FF(J) is reset. The reset of FF(J) is accomplished by the release switch.

All FFs are reset by the OFF + ON operation of power source.

The battery checker circuit (L) is caused to operate when the drive switch is turned ON with the power switch kept OFF, and it causes LED(N) to light when it has a power voltage of more than 7 to 8V.



«CIRCUIT CHECKING METHOD»



ETR / ZENZANON 75mm Lens

Repair Manual

[5] TROUBLESHOOTING

	Trouble		Cause		Remedy	
1	Poor synch conductivity	(1)	Shutter green cord is poorly soldered.	0	Resoldering	P14
		(2)	Contact piece, insulating plate are poorly connected.	0	Replace contact piece and insulating plate set.	P13,14
		(3)	Shutter green cord is broken.	0	Replace shutter	P9 ∿ 12 (S)
2	Synch is poorly insulated	(1)	Flux was incompletely wiped when contact piece and insulating plate set and shutter were soldered.	0	Wipe flux with lens cleaning paper or simi- lar articles using ether-mixed alcohol and coat silicon varnish.	P14
		(2)	After wiping flux, silicon varnish was not coated.	0	Wipe lightly with in ether-mixed alcohol and coat silicon varnish.	P14
		(3)	Shutter itself is poorly insulated.	0	Replace shutter.	P9 ∿ 12 (S)
		(4)	Contact piece and in- sulating plate set itself is poorly insulated.	0	Replace contact piece and insulating plate set.	P13,14
3	Diaphragm resistance value insecure	(1)	Warped printed circuit (FCB) board of dia- phragm resistance.	0	Replace shutter	P9 ∿ 12 (S)
		(2)	Dirty back of printed circuit board of diaphragm resistance.	0	Clean back of printed circuit board with ether-mixed alcohol.	P17
		(3)	Broken brush legs of printed circuit board of diaphragm resistance.	o	Replace shutter	P9 ∿ 12 (S)
		(4)	Poor connection of contact piece and insulating plate set.	0	Replace contact piece and insulating plate set.	P13,14
		(5)	Improper angle of brush at the back of printed circuit board of diaphragm resistance.	0	Correct brush angle	P17

(1) Note: (s) indicates satudard manual.

	Trouble		Cause		Remedy	
4	Diaphragm resistance value is not shown	(1)	Dirty contact piece and insulating plate set and shutter contact.	0	Clean with ether- mixed alcohol solution	P13
		(2)	Broken wire in contact piece and insulating plate set.	0	Replace contact piece and insulating plate set.	P13,14
		(3)	Broken wire in shutter white cord.	0	Replace shutter.	P9 ∿ 12 (S)
5	Short circuit of diaphragm resistance	1	Short circuit in shutter white cord.	0	Replace shutter.	P9 ∿ 12 (S)
	value	(2)	Short circuit in contact piece and insulating plate set.	0	Replace contact piece and insulating plate set.	P13,14
6	Diaphragm resistance values become im- proper values.	(1)	Short circuit in contact piece and insu- lating plate set.	0	Replace contact piece and insulating plate set.	P13,14
		(2)	Short-circuit of wirings inside the shutter.	0	Replace shutter.	P9 ∿ 12 (S)
7	Shutter releasing speed skips inter-	(1)	Deformed base plate of set ring.	0	Replace set ring unit.	P10
	mittently.	(2)	Poor movement of set ring unit.	0	Replace set ring unit.	P10
		(3)	Dirty contact piece and insulating plate set and shutter contact.	0	Clean with ether-mixed alcohol.	P13
		(4)	Poor connection of contact piece and insulating plate set.	0	Replace contact piece and insulating plate set.	P13,14
		(5)	Defective shutter.	0	Replace shutter	P9 ∿ 12 (S)
8	Shutter speed of one second is variable.	(1)	Defective shutter.	0	Replace shutter.	P9 ∿ 12 (S)
9	Shutter speed, 1/250, 1/125 slightly slow or faster.	(1)	Defective shutter.	0	a) Volume adjustment inside shutterb) If impossible, replace shutter.	(S) 23,24

	Trouble		Cause		Remedy	
10	Shutter speed skips.	(1)	Poor soldering of shutter and contact piece insulating plate set.		Resoldering etc.	P14
		(2)	Short-circuit of wiring inside the shutter.	0	Replace shutter	P9 ∿ 12 (S)
		(3)	Sticky operation of set ring unit.	0	Replace set ring unit.	P10
		(4)	Deformed set ring base plate.	٥	Replace set ring unit.	P10
		(5)	Poor connection of contact piece and insulating plate set.	0	Replace contact piece and insulating plate set.	P13,14
		(6)	Dirty contact piece and insulating plate set and shutter contact.	O	Clean contact with ether-mixed alcohol.	P13
11	Shutter speed, 1/250, 1/125 are variable.	(1)	Defective shutter	0	a) Volume adjustment inside shutter.	(S) 23,24
					b) If impossible, replace shutter.	P9 ∿ 12 (S)
12	Shutter speed 1/500 slow, fast or varies	(1)	Defective shutter	0	Replace shutter	P9 ∿ 12 (S)
13	Shutter speed skips every other time	(1)	Defective shutter	0	Replace shutter	P9 ∿ 12 (S)
14	Poor feeling in moving out or in of helicoid, unstable	(1)	Poor tightening of set screws in installing helicoid and scale.	o	Redo tightening of set screws.	(S) 29,30
	rotation	(2)	Poor tightening of scale ring after mechanical focus adjustment.	0	Redo tightening of scale ring.	(S) 28
		(3)	Poor installation of straight plate.	0	Correct installation of straight plate.	P15,16
			Defective straight plate.	0	Replace straight plate.	P15,16
		(5)	Poor helicoid at lead screw portion	0	Replace helicoid.	P9 ∿ 12 (S)
15	moving out or in		Por helicoid at lead screw portion.	o	Replace helicoid	P9 ∿ 12 (S)
	helicoid. o Uneven rotation	(2)	Foreign matter in lead screw of helicoid.		Clean lead screw portion	P15,16

	Trouble	Cause Remedy	<u> </u>
16	Poor feeling in moving out or in helicoid. o Loose rotation	(1) Poor installation of straight plate. (2) Defective straight plate. or Correct installation of straight plate. or Replace straight plate.	P15,16
17	Poor feeling in moving out or in of helicoid. o Slant rotation	(1) Due to incorrect tightening of scale ring after mechanical focus adjustment, helicoid and scale ring are slightly expanded and cause bayonet ring to slant.	(S) 28
18	Poor feeling in moving out or in of	(1) Helicoid is poor at lead screw portion.	P9 ∿12 (S)
	helicoid. o Rough rotation	(2) Foreign matter insert- ed at lead screw portion of helicoid.	P15,16
19	Poor return of manual diaphragm	(1) Manual lever axis floats due to shallow countersink. o Additional machining of countersink for manual lever, or replace.	P10
		(2) Manual lever axis slightly hits groove inside helicoid due to deep countersink.	P10
		(3) Manual arm of front frame frame unit is poor in movement due to incomplete painting and deformation.	P10
		(4) Defective shutter. o Replace shutter.	P9 ∿ 12 (S)
20	T change-over shutter does not operate.	(1) Poor connection of T change-over arm of front frame unit and shutter.	(S) 12,13
		(2) Defective shutter. o Replace shutter.	P9 ∿12 (S)
21	MG display keeps to light or lighted while in winding, while M switch is being inspected by timing gauge.	(1) Defective shutter. o Replace shutter.	P9 [∿] 12 (S)

	Trouble	Cause	Remedy	
22	Shutter blades do not open at winding.	(1) Defective shutter.	o Replace shutter.	P9 ∿ 12 (S)

6. DISASSEMBLY OF 75mm LENS

1) Replacement of 75mm lens elements

[Step 1]

Remove the name ring \bigcirc with a name ring installing jig \bigcirc .

[Step 2]

Remove the front lens group 2 with a pin face jig 5.




Fig. 1

[Step 3]

Remove the rear lens group 6 with a pin face jig 7.

[Step 4]

Screw in a new front lens group 2 and rear group 6 into respective screw portions with grease (ROJIMORU #4019) coated by using pin face jigs 7 and 5.

(Note)

- In case either front or rear group is required to be replaced, a set of front and rear group should be replaced.
- In replacing lens elements, select a lens which conforms with a washer used between the shutter and helicoid.

Lens color indication	Washer for adjustment
Orange	0.8 (mm)
Blue	0.0 (mm.)
Yellow	0.7
Green	0.5
Purple	0.3
Red	0.1

- 3. Be sure to make mechanical focus adjustment after replacing lenses.
- 4. In replacing a front group of lens, be sure to install a rear cap (8).

8	1-242602	Rear cap
7	1-210180-AJ	Lens rear group pin face
6	1-210180	Lens rear group
5	1-210180-AJ	Lens front group pin face
4	1-210482 - AJ	Name ring installing jig
3	1-710100	Helicoid installed with front and rear frame
2	1-210180	Front lens group
1	1-210482	Name ring




Fig. 2

6. 2) Replacement of shutter

[Step 1]


Remove the name ring and lens first as described in 6.1).

[Step 2]

Remove a leatherette ring 3.

[Step 3]

Loosen set screw (5) and pull out the helicoid scale (2).



6	1-242602	Rear cap		
5	5-063026	Set screw		
3	1-210512	Leatherette		
2	1-210284	Helicoid scale		
1	1-710010	Helicoid with lens assembled		

[Step 4]

Remove screw (14).


[Step 5]

Remove the front frame unit (1), depth of field scale ring (2), manual lever set (13).

[Step 6]

Remove the light-tight ring 4 with care exercised not to bend it as it was adhesive fixed. If it is hard to remove, apply small amount of amyl acetate and remove it after a little while.

[Step 7]




[Step 8]

Detach the shutter cord soldered to the contact piece and insulating plate set (1) by using a soldering iron.

[Step 9]

Set the helicoid with shutter installed 7 in the helicoid inner cylinder assembling jig (18) and remove the ring for installing shutter (21) by using a wrench for ring for installing shutter (19).



22	1-710300	Helicoid unit		
21	1-210152	Ring for installing shutter		
20		Spanner pin for ring for installing shutter		
19	1-210152 AJ	Spanner for ring for installing shutter		
18	1-210013 AJ	Helicoid inner cylinder assembling jig		
9	1-710210	Shutter unit		

[Step 10]


Remove the shutter unit 9 from the helicoid unit 2.

[Step 11]

Replace the shutter unit 9 with a good one.

[Step 12]

After replacing a shutter unit 9, perform adjustment in accordance with the procedure set forth in the standard work instruction manual, 6-30 (excluding 8, 4 and 15).



23	1-210610	Washer for adjustment t 0.	4
23	1-210600	n 0.	3
23	1-210590	" 0.	2
23	1-210171	٠ ، ،	1
22	1-710300	Helicoid unit	
21	1-210152	Shutter installing ring	
9	1-710210	Shutter unit	

6. 3) Replacement of contact piece and insulating plate set

[Step 1]

Remove the set ring unit by the procedure of 7 and 8 of Par. 6. 2), and disconnect the contact piece and insulating plate set(1) and shutter cord.

[Step 2]


Peel off the contact piece and insulating plate set 1 from the helicoid inner cylinder (3).

[Step 3]

Attach a piece of flexible fixing tape (2) to the contact piece and insulating plate set (1) by the procedures shown in Fig. 1 and 3.

[Step 4]

Attach the contact piece and insulating plate set 1 to the helicoid inner cylinder 3 by means of flexible fixing tape 2. At this time, they must be fixed with the center of a straight plate 5 adjusted to No. 2 contact of contact piece and insulating plate set 1. Care should be exercised to maintain a proper gap between the contact piece and insulating plate set 1 and the helicoid inner cylinder.



7	1-210121	Shutter contact
6	1-710300	Helicoid unit
5	1-210142	Straight plate
4	1-210152	Shutter installing ring
3	1-210015	Helicoid inner cylinder
2	1-210521	Flexible fixing tape
1	1-710260	Contact piece and insulating plate set

Fig. 3

Fig. 3

[Step 5]

Place preliminary solder at 6 contact points of the contact piece and insulating plate set (1).

[Step 6]

Solder each cord of shutter to each contact of the contact piece and insulating plate set 2. At this time connect each cord with the contact piece and insulating plate set 1 as shown in Table 1 and care should be exercised not to have cords overlapped.

[Step 7]


After soldering, clean flux with ether-mixed alcohol, dry it by hot air, apply silicon varnish with a brush and then dry soldered portion naturally.

Information: Silicon varnish (KR 114 manufactured by Shinetsu Kakagu Co.)
Solvent, RIGURO IN (Nippon Sekiyu)

Silicon varnish: solvent = $1 : 10 \sim 20$

Color of shutter cord	Contact No. of contact insulat- ing plate set
Black	11
Green	2
Yellow	3
Blue	4
Orange	5
White	6

Table 1



6	1-710300	Helicoid unit
1	1-710260	Flexible print board A-B

6. 4) Disassembly and reassembly of helicoid

a) Procedure for disassembly

[Step 1]

Remove the screw (16) and then remove the straight plate (15).

[Step 2]

Remove the helicoid inner cylinder. (Right-handed screw)

[Step 3]

Remove a scale ring fixing screw (1) and then remove the helicoid scale ring.


[Step 4]

Remove the helicoid intermediate cylinder. (Left-handed screw)

Note)

- o The grease to be used for helicoid lead screw portion is ROJIMORU #74075
- o In applying this grease, do not apply too much. Much grease may be squeezed out.
- o Lead screw portion must be protected from dust, etc. Such foreign matters may worsen the movement of helicoid.

-		
16	1-813307	Screw
15	1-210142	Straight plate
14	1-210035	Lens bayonet
13	1-210240	Bayonet ring index
12	1-210720	Stopper calking pin
11	1-210710	Bayonet ring stopper
10	1-210042	Bayonet ring
9	5-811357	Screw
8	1-210022	Helicoid intermediate cylinder
7	1-210015	Helicoid inner cylinder
6	5-831257	Screw
5	5-063026	Set screw
4	1-210261	Helicoid stopper
3	1-210252	Helicoid scale ring
2	5-511421	Washer
1	1-210272	Scale ring installation



6.4)

b) Procedure for assembly

[Step 1]

Install an index (13) and bayonet ring stopper on the bayonet ring.

[Step 2]

Install the bayonet ring (10) on the lens bayonet (14).

[Step 3]

Screw in the helicoid intermediate cylinder (8) into the lens bayonet (14) until it comes to a stop and then rotate it by an angle of 90° to the right.

[Step 4]

Set the helicoid scale ring 3 with helicoid stopper 4 installed on the helicoid for which steps up to 3 have been done, and rotate the helicoid stopper 4 and bayonet ring stopper 1 until they stop and fix them with the scale ring set screw 1.

[Step 5]

Rotate the helicoid scale ring (3) to the left until it stops, and at the position, screw in the helicoid inner cylinder (7) into the helicoid intermediate cylinder (8). (Right-handed screw)

Note) Adjust the inscribed character of 58¢ on the bayonet to (A) of the helicoid inner cylinder (7), and then screw it from the position.

[Step 6]

Rotate the helicoid inner cylinder (7) slightly back from its completely screwed in position and then install the straight plate (15).

Note) At the time, the overall length of the helicoid which is completely receded must be 38.4mm ± 0.4.

If this dimension is not obtained, change the screwed in position of the helicoid inner cylinder (7) described in Step 5 pitch by pitch until the above dimension is obtained.


[Step 7]

Check the helicoid to see if it can be moved out or moved in smoothly and make adjustment if it is not smooth.

(Information)

Helicoid inner cylinder M 66.4 P = 1.25 L = 20Helicoid intermediate cylinder $\{\begin{array}{ll} Inner \\ Outer \end{array}\}$ M 66.4 P = 1.25 L = 20 P = 1.0 L = 4 Left-handed screw Lens bayonet M 70 P = 1.0 L = 4 Left-handed screw

5. OTHERS



JOB : Installation of shutter to helicoid unit

[Step 1]

Set a shutter unit 1 on the helicoid inner cylinder assembly jig 7.

[Step 2]

According to the color display of flange focal distance of lens, place a washer for adjustment with its share drop faced downward (2) on the shutter unit (1). (Refer to Table 1)

[Step 3]


Place a helicoid unit 3 on it.
As shown in Fig. 1, thread cords of shutter 1 through a vinyl tube and place it through the hole for shutter cords 3.

[Step 4]

Set (A) of the helicoid unit (3) to the helicoid inner cylinder assembly jig (7) as shown in Fig. 2.

[Color chart for flange focal length]

Color	Washer for adjustment			
Orange	0.8			
Blue	V.8			
Yellow	0.7			
Green	0.5			
Purple	0.3			
Red	0.1			




2	1210610	Washer for adjustment	0.4	7	1-210013AJ Helicoid inner cylinder assembly jig
2	1210600	11	0.3	6	Spanner pin for installing shutter
2	1210590	11	0.2	5	Spanner for ring for installing shutter
2	1210171	11	0.1	4	Shutter installing ring
1	1710210	Shutter un	ít	3	Helicoid unit

JOB : Installation of shutter to helicoid unit

[Step 5]

To fix the helicoid unit 3 set on the helicoid inner cylinder assembly jig 7 and a shutter unit 1, tighten the shutter installing ring 4 with a spanner for shutter installing ring 4 as shown in Fig. 2. Tighten it securely. Do not damage the shutter installing ring 4. Make adjustment by means of an adjusting nut 5 so as not to have a spanner pin for shutter installing ring come off through the guide hole of shutter installing ring 4.



JOB : Soldering of shutter and contact piece and insulating plate set

Color of shutter cord	Contact No. of plate
Black	1
Green	2
Yellow	3
Blue	4
Orange	5
White	6

[Step 1]


Place preliminary solder on each of 6 contacts of the contact piece and insulating plate set (2).

[Step 2]

Solder each cord of the shutter to each contact of the plate 2. Arrange cords to respective contacts as shown in the drawing and care should be exercised not to overlap cords.

[Step 3]

After soldering, wash flux with ethermixed alcohol and dry it by hot air, apply silicon varnish with a brush all over the soldered portion and dry it naturally.



Information) Silicon varnish (KR 114 manufactured by Shinetsu Kagaku Co.) Solvent RIGUROIN (Nippon Sekiyu)

Silicon varnish: solvent = 1 : $10 \sim 20$

2	1710260	Contact piece and insulating plate set	
1	1710300	Helicoid unit	

JAMA

PROCESS: Assembly of helicoid installed with front rear frame

JOB : Assembly of set ring unit

[Step 1]


Tighten 6 terminals of the contact piece and insulating plate set 4 through the set ring base plate 3 by using 4 selftap screws 2. Do not tighten these screws too tight as they may be damaged.

[Step 2]

Thread the leg A of the set ring set (3) through the groove B of the shutter unit (6) installed on the helicoid (5) and tighten it with 6 screws (1). Tighten screws with a constant torque not to have the set ring unit (3) floated.

(Note)

Prior to installing the set ring unit 3, check to see if its legs A move smoothly, there is a uniform gap between the unit and helicoid and it is not bent.




6	1710210	Shutter unit	
5	1710200	Helicoid with shutter installed	
4	1710260	Contact piece and insulating plate set	
3	1710220	Set ring unit	
2	5893307	Screw (selftap)	
1	5833407	Screw	

: Installation of light-tight ring JOB

[Step 1]

Install the light-tight ring (1) on the helicoid with shutter installed. (3) As shown in Fig. 2, have the rise portion of the light-tight ring slide into the guide groove of the helicoid's straight plate and set the ring so as to have its side B hit side A of the helicoid and those contacted surface should be adhered to each other with adhesive (bond). Their direction must be as shown in Fig. 1, and a rear cap (4) should be applied to protect the contact piece and insulating plate set others.



5	1210142	Straight plate	
4	1242602	Rear cap	
3	1710200	Helicoid with shutter installed	
2	1710210	Shutter unit	
1	1210531	Light-tight ring	

coat

grease

PROCESS: Assembly of helicoid installed with front rear frame

JOB : Installation of front frame unit and depth of field scale ring

[Step 1]

Apply a rear cap 6 to the helicoid with shutter installed for the purpose of protection.

[Step 2]

Set the manual lever set (13) at the side hole of a depth of field scale ring (2).

[Step 3]

Install the above unit on the helicoid with shutter installed (5). At this time, place the manual lever axis of the lever set (13) in the groove of the helicoid (5).

[Step 4]

Apply grease to the protion of manual arm C (15) of front frame unit (1) where it contact with the manual lever set (13). Fig.A.

[Step 5]


Lastly set the front frame unit

1) to the helicoid which has been assembled up to the stage of Step 3. At this time, adjust T change-over ring (8) to shutter AT change-over lever

11), diaphragm arm (9) to shutter diaphragm ring 10 and manual arm (8) (7) to shutter diaphragm lever (12) respectively. Tighten the unit with 3 screws


14) by applying locktite.

Note: Do not tighten them too tight.




8	1210351	T change-over ring	1			
7	1210392	Manual arm B	1	15	1210403 Manual arm C	1
6	1242602	Rear cap	1	14	5853559 Screw	3
5	1710200	Helicoid with shutter installed	1	13	1710170 Manual lever set	1
4	1210531	Light-right ring	1	12	Shutter diaphragm lever	1
3	1710210	Shutter unit	1	11	Shutter AT change-over lever	1
2	1210295	Depth of field scale ring	1	10	Shutter diaphragm ring	1
1	1710110	Front frame unit	1	9	1210342 Diaphragm arm	1

JOB : Installation of front frame unit and depth of field scale ring



PROCESS: Inspection of helicoid installed with front rear frame

JOB : Diaphragm resistance value M switch timing check



5	MG display lamp
4	ETR standard body
3	Digital multitester (sanwa)
2	(1754500-CT)M switch timing gauge
1	Helicoid installed with front and rear frame 1710100

ORDER NO.

PROCESS: Inspection of helicoid installed with front rear frame

JOB : Diaphragm resistance value M switch timing check

[Step 1]

Set an M switch timing gauge 2 on the standard body 4.

[Step 2]

Set the helicoid with front and rear frame installed \bigcirc on the standard body \bigcirc 4, and confirm that it performs functions as listed in Table 1 by releasing the shutter at slow speed (1 to 1/2 second) several times.

Note: o A unit of helicoid which is completely recorded and causes display lamps to light is judged to be defective. Such a helicoid installed with lens mechanically focus adjusted is judged to be perfect if it does not cause display lamps to light under completely receded condition.

o A unit which causes MG display lamp (5) to light when it is wound will be judged as defective.

Table 1

Condition of body and lens	Gauge display
Winding complete	Red 1 (ME) light ON
By about 1/2 stroke until shutter is released.	Red 1 (ME) light ON, Green 1 (S) is light OFF
S is pushed. Shutter open.	ME light OFF, S, MG light ON
S button is released (return)	ME, S light OFF, MG light ON
Shutter closes	ME, S, MG light OFF

PROCESS: Inspection of helicoid installed with front rear frame

JOB : Diaphragm resistance value M switch timing check

[Step 1]

As shown in Fig. 1, connect the M switch timing gauge (2) to a digital multi-tester (3) and set the range of the tester at $2K\Omega$.

[Step 2]

Rotate the aperture ring (7) and read out each resistance value at click position.

The range of diaphragm resistance values is as shown in Table 2.

[Step 3]

Confirm that relationship between the position of inscribed marks of the aperture ring 7 and that of depth of field scale ring 6 is on the datum line shown in Fig. 2. If they are deviated in position, adjust them to the datum line by bending 2 aperture arms 9 by the same amount.

[Refer to Standard work instruction sheet No. 13]

[Step 4]

Check the aperture ring (7) if it rotate smoothly.




Table 2

Diaphragm	Diaphragm resistance value
F 2.8	1330 ∿ 1470 Ω
4	1140 ∿ 1260
5.6	950 ∿ 1050
8	760 ∿ 840
11	570 ∿ 630
16	380 ∿ 420
22	190 ∿ 210


7	1210335	Aperture ring					
6	1210295	10295 Depth of field scale ring					
1	1710100	Helicoid with front and rear frame installed	1				

PROCESS: Inspection of helicoid installed with front rear frame

JOB : Shutter inspection

[Step 1]


Set the helicoid with front and rear frame installed on the standard body and check the operation of shutter by releasing it five times each at a speed of 1/8 to 1/30 with an aperture of F22 with the helicoid extended and receded respectively.




- 1. Shutter vane (6) and diaphragm iris (5) must be smooth in movement.
- 2. The aperture of iris diaphragm 5 must be the same as standard aperture. Aperture must be accurate without variation.



Set the T change-over lever of the helicoid with front and rear frame installed at the position shown in Fig. 1, and cause the shutter to operate, and after that put the lever back to the position shown in Fig. 2.







- (1) When the shutter is pushed with T change-over lever (4) set at the position of Fig. 1, the shutter vane (6) must be held raised with diaphragm iris kept in the condition of Fig. 1. That is, the condition of Fig. 1.
- (2) When the T change-over lever (4) is set at the position of Fig. 2, the shutter vane (6) of Fig. (2) must be lowered. That is, the condition of Fig. 2.
- (3) T change-over lever (4) must be smooth in operation, and click movement must be made.
- (4) Change-over of inspection items from 1 to 2 must be smooth and the operation of shutter vane (6) must be swift and stable at the time.

[Step 3]

After satisfying the above items of inspection, T lever lock(3) is tightened ant T change-over lever(8) is fixed.

4	1210362	T change-over lever	8	Inscribed character A on depth of field scale ring
3	1210621	T lever lock	7	т т
2	1210295	Depth of field scale ring	6	Shutter vane
1	1210324	Front frame	5	Shutter diaphragm iris





(S)

PROCESS: Inspection of helicoid installed with front rear frame

500 V 100MA

JOB : Inspection of synch, conductivity and insulation

[Step 1]

Set the helicoid with front and rear frame installed on the standard body.

[Step 2]


Insert the synch plug 10 of a conductivity meter (1) into the synch socket (10) of the standard body. At this time, connect the synch cord (9) to the synch cord terminal (4).


[Step 3]

Turn the switch (2) ON.

[Step 4]

Set the shutter speed at 1/500 and confirm that the display lamp (3) is caused to light positively when the shutter is pushed and repeat this test more than 2 times.





MΩ

5	Insulation meter 500V/200MΩ	10	Synch plug
4	Synch cord terminal	9	Synch cord
3	Display lamp	8	Indicator needle
2	Synch conductivity meter switch	7	Insulation meter
1	Synch conductivity meter	6	Switch

ORDER NO.

PROCESS: Inspection of helicoid installed with front rear frame

JOB : Inspection of synch, conductivity and insulation

[Step 5]

Disconnect the synch plug 10 of the conductivity meter 1 from the synch socket of the standard body, and set the synch plug 10 of the insulation meter 5 into the synch socket of the standard body.

[Step 6]

Open the switch 6 of the insulation meter 5.

[Step 7]

Set the shutter speed at 1 sec., and confirm that the indicated values of the needle (8) within the insulation meter (7) must be as follows:

Before shutter is pushed Insulation resistance more than $50\text{M}\Omega$ ($50\text{M}\Omega\text{-}\infty$) While shutter in operation " $0\text{M}\Omega$

After shutter operated

50MΩ (50MΩ~∞)


[Step 8]

Confirm that the needle (8) of the insulation meter (5) is between $50M\Omega$ and ∞ when the helicoid with front and rear frame installed is moved forward or backward.

Note: o Use a conductivity meter manufactured by Bronica.

o Use an insulation meter of 500V, 100M (200MΩ) manufactured by Yokogawa.

PROCESS: Inspection of helicoid installed with front rear frame



9	Measured value display window		Connection cord
8	Switch		Standard pulse generator for shutter speed
7	Switch	16	Lens shutter inspection jig terminal
6	Shutter tester Model KS202B	15	Guide hole
5	Guide hole	14	Mark
4	Minimum aperture ring	13	Operating lever
3	CT-354 Lens shutter speed inspection jig B	1.2	CT-354 Lens shutter inspection jig A
2	Calibrate adjusting screw	11	Calibrate display lamp
1	Shutter tester Model KS202B	10	Switch

PROCESS: Inspection of helicoid installed with front rear frame

JOB : Inspection of shutter speed

[Step 1]

Turn the power switch 5 and 10 of the shutter tester Model KS202B 1, 6 ON.

[Step 2]

Install a lens shutter speed inspection tool 3 on the shutter tester 1, and set a minimum opening aperture ring 4 in the tool.

[Step 3]

Place a lens shutter speed inspection tool (12) over the lens shutter speed inspection tool (3) and at this time use the guide hole (15).

[Step 4]

Connect group of connecting cords (18) of a shutter speed standard pulse generator (17) to terminals (16) of the lens shutter speed inspection tool (12) in such a manner blue to blue, black to black, yellow to yellow and red to red.

[Step 5]

Set the switch 7 to the left, switch 8 to downward, switch 19 to the right, and switch 21 on.

[Step 6]

Move the operating lever (13) of the lens shutter speed inspection tool (12) in the direction of A to its extreme end, set the helicoid with front and rear frame installed, with its index mark adjusted to the mark (14) of the lens shutter speed inspection tool (12).




Fig. 2

Table 1

Shutter speed	Range (m sec.)
1/500	2.67 ∿ 1.43
1/250	5.34 ∿ 2.86
1/125	10.7 ∿ 5.72
l sec.	1366 ∿ 732

23	Foot switch				
22	2 Voltage display meter				
21	Switch		26	Lens release	
20	Speed indicating dial	1	25	Speed adjusting screw	1
19	Switch		24	Shutter unit	1

ORDER NO.

PROCESS: Inspection of helicoid installed with front rear frame

JOB : Inspection of shutter speed

[Step 7]

Set the diaphragm of the helicoid with front and rear frame installed at the full opening (In the case of 75mm standard lens, F 2.8).

[Step 8]

Move the operating lever (13) to the position of A, and cause the calibrate display lamp (11) to light by rotating the calibrate adjusting screw (2).

[Step 9]

In the subsequent operations, cause the shutter to operate by shifting the operating lever (13) in the direction of A or B.

[Step 10]

The measurement of shutter speed is performed at 4 types of speed, 1/500, 1/250, 1/125 and 1 sec. At this time, set the speed indicating dial 20 to each of those speeds and the shutter must be operated more than 3 times at each speed, and confirm that measured values are within the range shown in Table 1. At this time, the voltage display meter (2) should indicate 6V. Measured values are digitally indicated in the display window (9).

[Step 11]

The voltage display meter (2) indicates 4V when the foot switch (23) is pressed. Confirming it indicates 4V, make measurement in the same manner as Step 10 and confirm shutter speeds.


[Step 12]

In case a high speed shutter is deviated from the range, it can be somewhat adjusted by rotating the speed adjusting screw (25). In this case, speed becomes faster when rotated to the right, and becomes slower when turned to the left.

Note: The screw should be lightly rotated to the left or right without applying undue force.

PROCESS: Assembly of lens (1)

JOB : Mounting of front lens group, rear group and name ring



5	1-210180AJ Lens front group pin face				
	1-210482AJ Name ring installing jig	1			
3	1710100 Helicoid with front and rear frame installed		8	1242602 Rear cap	
2	1210180 Lens front group		7	1-210180AJ Lens rear group pin face	1
1	1210482 Name ring		6	1210180 Lens rear group	

PROCESS: Assembly of lens

JOB : Mounting of front lens group, rear group and name ring

[Step 1]

Check the front lens group 2 and rear group 6 for any scratch, air bubble, dirt, stain, etc. and clean them with ether-mixed alcohol.

[Step 2]

Apply grease at the threaded portion (B) of the front lens group (2) and screw it securely into the helicoid with front and rear frame installed (3) by using a pin face wrench (5).

Note: At this time, be sure to install a rear cap (8) on the lens.

[Step 3]

Apply grease to the threaded portion (A) of the name ring (1) and then screw the ring securely into the helicoid with front and rear frame installed (3) by using a jig for mounting name ring (4). Fig. 1

[Step 4]

Apply grease to the threaded portion © of the rear lens group 6 and then screw it into the helicoid with front and rear frame installed 3 by using a pin-face wrench 7. Fig. 2

Note: o In screwing the rear lens group, 6 care should be exercised not to damage the threaded portion of both lens side and shutter side since they are made of aluminum.

o The lens must be securely screwed into the position with designated grease coated on its threaded portion.

As grease for the lens, ROJIMORU #4019 should be used.




Fig. 2

Fig. 1


PROCESS: Mechanical focus adjustment of assembly of lens (1)


JOB : Mechanical focus adjustment

[Step 1]

Install the helicoid with lens assembled 2 on the mount for measuring FB(1). In this case, first adjust the index mark 8 of the helicoid 2 to the mark 7 of the mount (1), and then set the helicoid by turning it counterclockwise.

[Step 2]





9	1210272	Scale ring set screw				
8	1210240	Bayonet ring index	17	1210022	Helicoid intermediate cylinder	
7		Mark	16	1710141	T change-over ring	
6		Collimator mount	15	1210335	Aperture ring	
5	<u>.</u>	Tripod pan head	14	1210531	Light-tight ring	
4		Light source	13	1710210	Shutter unit	
3		Collimator	12	1210295	Depth of field scale ring	
2	1710010	Helicoid with lens	11	1710170	170 Manual lever set	
1	CT351	Mount for measuring FB	10	1210252	Helicoid scale ring	

PROCESS: Mechanical focus adjustment of assembly of lens (2)

JOB : Mechanical focus adjustment

[Step 3]

Turn the switch of light source (4) on and then adjust the pan head (5) so as to have the center of mount for measuring FB (1) come to the light axis of the collimator (3) and fix it.

[Step 4]

Apply lightly a loupe (22x) against the ground glass of the mount for measuring FB, and adjust the helicoid scale ring (10) to a position where No.4 can be seen most clearly by rotating it together with the intermediate cylinder of the helicoid while lightly holding it.

[Step 5]

After adjusting it to No.4 rotate the helicoid scale ring (10) alone counterclockwise until it comes to a stop, and then tighten and fix scale ring mounting screws (9), and then confirm again that it is adjusted to No.4. After that, lightly apply screwlock (three-bond) over the portion of A in Fig. 3.

Note: o In fixing the helicoid scale ring, 10 care should be exercised not to warp the ring or not to tighten it too hard.

o Such units which are hard to be mechanically focus adjusted by means of collimator should be treated as poor resolution unit.




Fig. 4

PROCESS: Completed 75mm lens (1)


: Mounting of helicoid scale and leatherette

[Step 1]

Rotate the helicoid scale ring (4) counterclockwise until it comes to a stop, and at that point, install a rear cap (6) over the unit.

[Step 2]

Have the helicoid scale (2) slid into between the depth of field scale ring and helicoid scale ring (4) and adjust them so as to have the center of infinite mark on the helicoid scale (2) and the green line of F2.8 of depth of field scale ring aligned with the datum line as shown in Fig. 2, and fix them lightly at one point by means of a set screw (5). At this time, apply locktite to the set screw. (The screw must be slightly below the surface.)



5	5063026	Set screw	3				
4	1210252	Helicoid scale ring	1				
3	1210512	Leatherette	1	8	1210335	Aperture ring	1
2	1210284	Helicoid scale	1	7	1210295	Depth of field scalr ring	1
1	1710010	Helicoid with lens mounted	1	6	1242602	Rear cap	1

ORDER NO.

PROCESS: Completed 75mm lens

JOB : Mounting of helicoid scale and leatherette

[Step 3]

Drill 2 holes large enough to accommodate the tip of set screw 5 on the helicoid scale with the tap hole of the helicoid scale ring used as guide by using a hand drill of which blade angle is 90°.

[Step 4]

Tighten set screws (5) at 2 places with locktite applied with care exercised not to deform the helicoid scale (2).

[Step 5]

Place a piece of leatherette over the groove of the helicoid scale ring 4 with care exercised not to have the edge of leatherette 3 extended from the helicoid scale ring 4.


[Step 6]

Lightly paste together the leatherette 3 and the helicoid scale ring 4 wind bond (diabond 1880C). Bond should be spread over the entire circumference.

ETR / ZENZANON Lenses


40 · 50 · 150mm

Parts Lists & Repair Manuals



Index	Parts No.	Parts Name	Q'ty
1	1145-6	Name ring	1
2	1145-2	Front lens holder	1
3	G-1	Lens	1
4	1140-5	Gl·2 spacer ring	1
5	G-2	Lens	1
6	1140-6	G3 holder	1
7	G-3	Lens	1
8	1145-3	G3·4 spacer ring	1
9	G-4·5	Lens	1
10	1145-1	Front lens frame	1
11	1145-817	Shutter	1
12	1144-36	Filter ring	1
13	1PM 1.7 x 4	Pan head small screw	4
14	3PM 1.7 x 3	Pan-head small screw	4
15	1144-3.8	Diaphragm fork	2
16	1145-8	Aperture ring	1
17	1144-34	T lever axis	2
18	1142-32	T change-over fork	1
19	1144-16	Relay ring	1
20	1144-31	Manual lever axis	1
21	1144-30	Manual lever	1
22	1144-26	Opening spring	1
23	1144-24	Spring axis	2
24	1144-28	Lever base plate	. 1
25	1144-29	Lever holding plate	1
26	3PM 1.7 x 4	Pan-head small screw	2
27	1144-17	Lever	1
28	1144-23	Lever axis	1
29	1144-27	Auxiliary spring	1
30	1144-20	C lever	1
31	1PM 1.7 x 3	Pan-head small screw	4
32	1144-25	Light-tight plate	1
33	1FM 1.7 x 3.5	Countersunk small screw	3
34	1145-10	Depth of field scale ring	1
35	1145-5	Shutter washer	1
36	1144~5	Inner cylinder	1
37	1145-7	Distance ring	1

Index	Parts No.	Parts Name	Q'ty
38	1144-11	Washer	. 3
39	1PM 1.7 x 3	Pan-head small screw	3
40	1144-12	Cover plate	1
41	1144-58	Таре	1
42	1144-13	Rubber knurling ring	1
43	1144-6	Helicoid female	1
44	1144-7	Master screw	1
45	NV 1.7 x 2.5	Fixing screw	1
46	1144-9	Stopper	1
47	1144-8	Key	2
48	1PM 1.7 x 3	Pan-head small screw	6
49	1PM 1.4 x 3	Pan-head small screw	4
50	1145-9	Bayonet ring	1
51	1144-43	Bayonet ring index	1
52	1144-41	Bayonet	1
53	1PM 1.7 x 4	Pan-head small screw	4
54	1144-51	Lock leaf spring	1
55	1144-50	Spring holder screw	1
56	1144-48	Set ring lock plate	1
57	1144-49	Lock plate axis	1
58	1144-52-53	Flexible printed board	1
59	1144-45	Set ring holder	1
60	1144-46	 Set ring	1
61	1101-49	Steel ball	85
62	1144-54	Contact piece insulating plate	1
63	1144-44	Set ring base plate	1
64	1PM 1.7 x 3	Pan-head small screw	6
65	1FM 1.7 x 3	Countersunk small screw	4
66	B-tight 1FM 1.7 x 3	Countersunk small screw	4
67	1144-15	Shut clamp ring	1
68	1145-4	Rear lens frame	1
69	G6	Lens	1
70	G-7	Lens	1
71	1140-8	Rear lens spacer ring	1
72	G-8	Lens	1
73	1140-9	Rear lens holder	1



Index	Parts No.	Parts Name	Q'ty
1	1144-40	Name ring	1
2	1144-2	Front lens holder	1
3	G-1	Lens	1
4	1139-5	G1, 2 space ring	1
5	G-2	Lens	1
6	1139-6	G2, 3 space ring	1
7	G-3	Lens	1
8	1139-7	G4 holder	1
9	G-4	Lens	1
10	1144-1	Front lens frame	1
11	G-5 · 6	Lens	1
12	1144-3	G6 holder	1
13	1144-816	Shutter	1
14	1144-36	Filter ring] 1
15	1144-39	Limit plate	1
16	1PM 1.7 x 4	Pan-head small screw	4
17	3PM 1.7 x 3	Pan-head small screw	4
18	1144-38	Diaphragm fork	2
19	1144-37	Aperture ring	1
20	1144-34	T lever axis	2
21	1144-32	T change-over fork	1
22	1144-16	Relay ring	1
23	1144-31	Manual lever axis	1
24	1144-30	Manual lever	1
25	1144-28	Lever base plate	1
26	1144-29	Lever holding plate	1
27	3PM 1.7 x 4	Pan-head small screw	2
28	1144-26	Opening spring	1
29	1144-24	Spring axis	2
30	1144-17	Lever	1
31	1144-20	C lever	1
32	1144-23	Lever axis	1
33	1144-27	Auxiliary spring	1
34	1PM 1.7 x 3	Pan-head small screw	4
35	1144-25	Light-tight plate	1
36	1FM 1.7 x 3.5	Pan-head small screw	3
37	1144-14	Depth of field scale ring	1

Index	Parts No.	Parts Name	Q'ty
38	1144-5	Cylinder	1
39	1144-10	Distance ring	1
40	1144-11	Washer	3
41	1PM 1.7 x 3	Pan-head small screw	3
42	1144-12	Cover plate	1
43	1144-58	Таре	1
44	1144-13	Rubber knurling ring	1
45	1144-6	Helicoid female	1
46	1144-7	Master screw	1
47	1144-9	Stopper	2
48	1344-8	Key	2
49	1PM 1.7 x 3	Pan-head small screw	6
50	1144-42	Bayonet ring	1
51	1144-43	Bayonet ring index	1
52	1PM 1.4 x 3	Pan-head small screw	4
53	1144-41	Bayonet	1
54	1PM 1.7 x 4	Pan-head small screw	4
55	1144-51	Lock leaf spring	1
56	1144-50	Spring holding screw	1
57	1144-48	Set ring lock plate	1
58	1144-49	Lock plate axis	1
59	1144-52 • 53	Flexible printed circuit board	1
60	1144-45	Set ring holder	1
61	1144-46	Set ring	1
62	1101-49	Steel ball	85
63	1144-54	Contact piece insulating plate	1
64	1144-44	Set ring base plate	1
65	1PM 1.7 x 3	Pan-head small screw	6
66	1FM 1.7 x 3	Pan-head small screw	4
67	B-tight 1FM 1.7 x 3	Pan-head small screw	4
68	1144-15	Shutter clamp ring	1
69	1144-4	Rear lens frame	1
70	G-7 · 8	Lens	i
71	1139-10	Rear lens space ring	1
72	G-9	Lens	1
73	1139-11	Rear lens holder	1

o 40mm F4 Zenzanon shutter unit replacing procedure

[Step 1]

Remove the name ring (2) with a name ring mounting jig (1).

[Step 2]

Remove the front lens (3) with a flexible pin-face wrench.

[Step 3]


Remove 3 screws 9 and then remove the front frame unit (4).

[Step 4]

After removing 4 screws (8), remove the light-tight plate (5) and depth of field scale ring (6).

Note: In performing the above work, be sure to place a rear cap (7) over the unit to protect the shutter contact and contact piece insulating plate from damage.

9	1FM 1.7 x 3.5	Countersunk small screw
8	1PM 1.7 x 3	Panheas small screw
7	1-242602	Rear cap
6	1144-14	Depth of field scale ring
5	1144-25	Light-tight plate
4		Front frame unit
3		Front lens
2	1144-40	Name ring
1	1-210482AJ	Name ring mount- ing jig



[Step 5]

After removing 6 screws (1), remove the set ring unit (2).

[Step 6]

Remove the rear lens 4.

[Step 7]

Remove solder of the contact piece insulating plate (3) and shutter.

[Step 8]

After removing the shutter clamp ring (5), remove the shutter.

[Step 9]

After replacing the shutter, assemble the unit in performing steps in reverse order.


[Step 10]


Upon completion of assembly, remove the rubber knurling ring (8), tape (7) and cover plate (6) and loosen screws 9 and perform mechanical focus adjustment of the unit.

[Step 11]

After completing mechanical focus adjustment, install the rubber knurling ring (8), tape (7) and cover plate (6) and complete the work.

9	1PM 1.7 x 3	Pan-head small screw
8	1144-13	Rubber knurling ring
7	1144-58	Таре
6	1144-12	Cover plate
5	1144-15	Shutter clamp ring
4	· · · · · · · · · · · · · · · · · · ·	Rear lens
3	1-710260	Contact piece insulating plate set
2		Set ring unit
1	1PM 1.7 x 3	Pan-head small screw





Index	Parts No.	Parts Name	Q'ty
1	1147-19	Name ring	1
2	1147-2	Front lens holder	1
3	G-1	Lens	1
4	1143-5	Front lens space ring	1
5	G-2	Lens	1
6	1143-6	G3 holder	1
7	G-3	Lens	1
8	1147-3	G3, 4 space ring	1
9	G-4	Lens	1
10	1147-1	Front lens frame	1
11	1147-818	Shutter	1
12	1147-17	Filter-ring	1
13	1144-39	Limit plate	1
14	1PM 1.7 x 4	Pan-head small screw	4
15	3PM 1.7 x 3	Pan-head small screw	4
16	1147-18	Diaphragm fork	2
17	1144-37	Aperture ring	1
18	1144-34	T lever axis	2
19	1147-16	T change-over fork	1
20	1144-16	Relay ring	1
21	1144-31	Manual lever axis	1
22	1144-30	Manual lever	1
23	1144-26	Opening spring	2
24	1144-24	Spring axis	1
25	1144-17	Lever	1
26	1144-15	Interconnected arm	1
27	1144-23	Lever axis	1
28	1144-27	Auxiliary spring	1
29	1144-28	Lever base	1
30	1144-29	Lever holding plate	1
31	3PM 1.7 x 4	Pan-head small screw	2
32	1PM 1.7 x 4	Pan-head small screw	4
33	1FM 1.7 x 3.5	Countersunk small screw	3
34	1147-14	Depth of field scale ring	1
35	1147-7	Shutter printed circuit board	1
36	1147-8	Helicoid male	1

1147 (F4 / 150mm)

Index	Parts No.	Parts Name	Q'ty
37	1PM 1.7 x 3.5	Pan-head small screw	4
3 8	1147-12	Distance ring	1
3 9	1144-11	Washer	3
40	1PM 1.7 x 3.5	Pan-head small screw	3
41	1144-12	Cover plate	1
4 2	1147-34	Tape	1
43	1147 -13	Rubber knurling ring	1
44	1147-9	Helicoid female	1
45	1147-10	Master screw	1
46	1147-11	Key	2
47	1PM 1.7 x 3.5	Pan-head small screw	6
48	1147-20	Connecting ring	1
49	1FM 1.7 x 5	Pan-head small screw	4
50	1PM 1.4 x 3	Pan-head small screw	4
51	1147-33	Bayonet ring	1
52	1144-43	Bayonet index	1
53	1144-41	Bayonet	1
54	1144-48	Set ring lock plate	1
55	1144-49	Lock plate axis	1
56	1PM 1.7 x 4	Pan-head small screw	4
57	1144-52	Flexible printed circuit board	1
58	1144-51	Lock plate spring	1
59	1144-50	Spring holding screw	1
60	1147-30	Lead wire	1
61	1FM 1.7 x 3	Countersunk small screw	4
62	1147-23	Pole holder	1
63	1101-49	Steel ball	83
64	1147-26	Set ring plate	1
65	1FM 1.7 x 3	Countersunk small screw	4
66	1147-25	Set ring	1
67	1101-49	Steel ball	91
68	1147-22	Set ring holder	1
69	1147-24	Set ring knock plate	1
70	1FM 1.7 x 3	Countersunk small screw	4
71	1144-54	Contact piece insulating plate	1
72	3PM 1.4 x 2	Pan-head small screw	4

1147 (F4 / 150mm)

Index	Parts No.	Parts Name	Q'ty
73	1147-31	Light-tight plate	2
74	1147-21	Set ring base plate	1
75	1PM 1.7 x 3	Pan-head small screw	6
76	1FM 1.7 x 3.5	Countersunk small screw	4
7 7	B-tight 1FM 1.7 x 3	Countersunk small screw	4
78	1 144-15	Shutter clamp ring	1
79	1147-5	G5 holder	1
80	G5	Lens	1
81	1147-4	Rear lens frame	1
82	G-6	Lens	1
83	1147-6	Rear lens holder	1

o 150mm F4 Zenzanon shutter unit replacing procedure

[Step 1]

Remove the name ring 2 with a name ring mounting jig(1).

[Step 2]

Remove the front lens 3 with a flexible pin-face wrench.

[Step 3]

Remove 3 screws (5) and remove the front frame unit (4).

Note: At this time, be sure to put a rear cap 6 over the unit to protect the shutter contact and contact piece insulating plate from damage.

	Ø
CONTANT PROPERTY.	2
	3
	æ
	4
The second secon	6

6	1-242602	Rear cap	
5	1FM1.7 x 3.5	Countersunk small screw	
4		Front frame unit	
3		Front lens	
2	1147-19	Name ring	
1	1-210482AJ	Name ring mounting jig	

[Step 4]

After removing 6 screws \bigcirc , remove the set ring unit \bigcirc .

[Step 5]

Remove the rear lens (4).

[Step 6]

Remove solder connecting the shutter cord and flexible printed circuit board (AA) (3).

[Step 7]


Loosen the shutter clamp ring (5) and take the shutter out and replace it.

[Step 8]

After replacing a shutter, check the unit it if properly assembled. If it is deviated partly, remove the rubber knurling ring (8), tape (7) and cover plate (6). After that, loosen screws (9) and perform mechanical focus adjustment of the unit. Upon completion of adjustment, tighten those screws securely.

Note: Assembly of shutter unit can be accomplished by performing the above steps in reverse order.

9	1PM1.7x3.5	Pan-head small screw
8	1147-13	Rubber- knurling ring
7	1147-34	Tape
6	1144-12	Cover plate
5	1144-15	Shutter clamp ring
4		Rear lens
3	1-710490	Flexible printed circuit board A
2		Set ring unit
1	1FM1.7x3	Countersunk small screw



4)